

Aeitto B0H1WKBQ4X

Aeitto Cold Press Juicer Instruction Manual

MODEL: B0H1WKBQ4X

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Aeitto Cold Press Juicer. Please read all instructions carefully before first use and retain this manual for future reference.

The Aeitto Cold Press Juicer is designed to extract juice from various fruits and vegetables, utilizing a slow masticating process to maximize nutrient retention and minimize oxidation. Its large feed chute and pre-cutting technology simplify preparation, while its integrated design ensures easy assembly and cleaning.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- The juicer machine features a safety design that automatically stops operation if the hopper cover is opened. Do not attempt to bypass this safety mechanism.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Always place the juicer on a stable, dry, and level surface during operation.
- Children should be supervised to ensure they do not play with the appliance.



1

Safety Design

It will **stop** automatically when the cover is **opened**

2

Anti-drip Design

Keep the table clean



3

One-Button Operation

Easy to operate & Reverse Function prevent clogging



The juicer includes a safety design that stops operation if the cover is opened, an anti-drip spout, and a simple one-button control.



Safety Design

The machine will stop working automatically when the cover is opened

The machine automatically stops when the cover is opened, enhancing user safety.

Product Components

Familiarize yourself with the parts of your Aeitto Cold Press Juicer:

- **Motor Base:** Contains the motor and control knob.
- **Juicing Bowl:** Collects the juice and pulp.
- **Auger:** The spiral component that crushes and presses ingredients.
- **Filter/Strainer:** Separates juice from pulp.
- **Hopper/Feed Chute:** The opening where fruits and vegetables are inserted. Features a 4.9-inch wide opening.
- **Hopper Cover:** Secures the feed chute and activates the safety switch.
- **Pulp Outlet:** Discharges dry pulp.
- **Juice Outlet with Anti-drip Cap:** Dispenses fresh juice and prevents drips.
- **Pusher:** Used to gently guide ingredients into the feed chute.
- **Cleaning Brush:** For thorough cleaning of the filter and other parts.
- **Juice Cup & Pulp Cup:** Containers for collecting juice and pulp.

4.9 INCH Extra Large Feed Chute

No Cutting, Less Oxidation



The 4.9-inch extra large feed chute accommodates whole fruits and vegetables, reducing preparation time.



Anti-drip



One-Button Operation



Multi-Layer Filter



Suction Cup Base

Key components include the anti-drip spout, one-button control, multi-layer filter, and a stable suction cup base.

Setup and Assembly

Follow these steps to assemble your juicer before use:

1. Place the motor base on a stable, flat, and dry surface.
2. Align the juicing bowl with the motor base and rotate it until it locks into place.
3. Insert the auger into the center of the juicing bowl.
4. Place the filter/strainer over the auger, ensuring it is seated correctly.
5. Attach the hopper cover, aligning the arrows and rotating until it clicks securely. The juicer will not operate if the cover is not properly locked.
6. Position the juice cup under the juice outlet and the pulp cup under the pulp outlet.


Easy to Assemble




STEP 1



STEP 2



STEP 3



STEP 4

Visual guide for easy assembly of the juicer in four steps.

Operating Instructions

Prepare and juice your ingredients with these steps:

1. **Ingredient Preparation:** Wash all fruits and vegetables thoroughly. For ingredients that fit the 4.9-inch feed chute, no pre-cutting is necessary. For smaller or fibrous items, ensure they are prepared to fit comfortably. The juicer's built-in blades will pre-cut ingredients before cold pressing.
2. **Power On:** Plug the juicer into a suitable power outlet. Turn the control knob to the 'ON' position.
3. **Juicing:** Slowly feed ingredients into the feed chute. Use the pusher only if necessary to gently guide ingredients. Do not force ingredients into the chute.
4. **Anti-drip Function:** Close the anti-drip cap on the juice outlet to prevent drips between juicing sessions or when changing juice cups. Open it to release the juice.
5. **Reverse Function:** If ingredients become jammed or the juicer stops, turn the control knob to the 'REV' (Reverse) position for a few seconds to clear the blockage. Then, switch back to 'ON' to resume juicing.
6. **Completion:** Once juicing is complete, turn the control knob to 'OFF' and unplug the appliance.

Upgraded Pre-cutting Technology



Automatically cut fruits and veggies into pieces



Multi-Stage auger makes juicing more efficient



The juicer features upgraded pre-cutting technology and a multi-stage auger for efficient juice extraction.



Pre-cutting & Cold Press Technology



Automatically cut fruits and veggies into pieces



Multi-Stage auger makes juicing more efficient

Pre-cutting and cold press technology work together for optimal juicing results.

98%
High
Juice Yield

Purer Juice, Drier Pulp



The slow cold press method ensures a high juice yield and drier pulp.



The juicer produces drier pulp and purer juice, indicating efficient extraction.

Official video demonstrating the Aeitto 4.9" Feeding Chute Cold Press Juicer in operation.

Maintenance and Cleaning

Proper cleaning and maintenance ensure the longevity and performance of your juicer:

1. **Disassembly:** After use, turn the juicer off and unplug it. Disassemble the parts in reverse order of assembly. The hopper and screen have an integrated design for fewer parts and easier disassembly.
2. **Rinsing:** Rinse all detachable parts (juicing bowl, auger, filter, hopper cover, juice/pulp cups) under running water immediately after use to prevent pulp from drying and sticking.
3. **Cleaning:** Use the provided cleaning brush to remove any residual pulp from the filter and other components. All detachable parts are hand wash only. Do not use abrasive cleaners or scourers.
4. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water.
5. **Drying and Storage:** Ensure all parts are completely dry before reassembling or storing the juicer. Store in a clean, dry place.

Easy to Clean



Wash easily with water



Equipped with brush

Cleaning the juicer is easy with water and the included brush.

Troubleshooting

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; hopper cover not securely locked; power outage.	Ensure the power cord is securely plugged in. Check that the hopper cover is fully locked into place. Verify power supply.
Juicer stops during operation.	Hopper cover opened; motor overload; ingredients jammed.	Ensure the hopper cover remains closed. If overloaded, turn off, unplug, clear ingredients, and restart. Use 'REV' function to clear jams.
Low juice yield or wet pulp.	Ingredients fed too quickly; filter clogged.	Feed ingredients slowly and steadily. Clean the filter thoroughly after each use.
Excessive noise or vibration.	Improper assembly; hard ingredients.	Disassemble and reassemble all parts, ensuring they are correctly aligned and locked. Avoid juicing excessively hard items without proper preparation.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Brand:** Aeitto
- **Model:** B0H1WKBQ4X
- **Color:** Black
- **Product Dimensions:** 7"D x 7"W x 13"H
- **Recommended Uses:** Fruits, Vegetables
- **Unit Count:** 1 Count
- **Voltage:** 120 volts
- **Special Features:** High Juice Yield, Pre-Cutting Blade, No Clogging, Easy to Assemble, Fits Whole Fruits and Vegetables
- **Product Care Instructions:** Hand Wash Only

Compact Size

Fits for kitchen & small spaces



The juicer features a compact design, suitable for various kitchen spaces.

High Power Juicing



Efficient Juicing



55db Quiet Motor



50RPM Slow Cold Press



The juicer operates with a 55db quiet motor and a 50 RPM slow cold press for efficient juicing.

Warranty and Support

Aeitto provides comprehensive after-sale service for your cold press juicer:

- **Warranty:** We offer 12 months of repair and replacement services from the date of purchase.
- **Customer Support:** For any product issues or inquiries, please utilize our 7*24 hours online consultation services.

Please retain your proof of purchase for warranty claims. Contact information for support can typically be found on the product packaging or the official Aeitto website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question