

JFN01

Generic JFN01 App-Controlled Wearable Device User Manual

Model: JFN01

1. INTRODUCTION

Thank you for choosing the Generic JFN01 App-Controlled Wearable Device. This manual provides essential information for the safe and effective use of your device, including setup, operation, maintenance, and troubleshooting.

Please read this manual thoroughly before using the device and retain it for future reference.

2. PRODUCT FEATURES

- **App Control:** Connects via a mobile application for remote operation and customized settings.
- **Wearable Design:** Compact and designed for discreet, comfortable wear.
- **Multiple Frequency Modes:** Offers a variety of vibration patterns for diverse experiences.
- **Ultra-Quiet Operation:** Designed to operate below 40dB for discretion.
- **Compact Size:** Small dimensions for portability and ease of use.
- **Magnetic USB Charging:** Convenient and fast charging via magnetic contact.
- **100% Waterproof:** Suitable for use in wet environments and easy to clean.



Figure 2.1: The JFN01 device offers 12 distinct frequency modes, providing a range of powerful vibration patterns for varied user preferences.



Figure 2.2: The JFN01 device features an ergonomic design engineered to conform closely to the body, ensuring a comfortable and secure fit during use.



Figure 2.3: The JFN01 device operates at an ultra-quiet level, below 40dB, allowing for discreet use in various environments without disturbance.



Figure 2.4: With dimensions of approximately 1.37 x 3.07 inches, the JFN01 device is designed to be compact and easily portable.

3. PACKAGE CONTENTS

Please check the package contents upon receipt. If any items are missing or damaged, contact customer support.

- 1 x Generic JFN01 App-Controlled Wearable Device
- 1 x Magnetic USB Charging Cable
- 1 x User Manual (this document)

4. SAFETY INFORMATION

For your safety and to ensure proper device function, please observe the following:

- Do not use the device if it appears damaged or faulty.
- Keep out of reach of children.
- Clean the device thoroughly before and after each use as described in the "Maintenance and Care" section.
- Do not use with petroleum-based lubricants, as these may damage the silicone material. Use water-based lubricants only.
- If you experience any discomfort or irritation, discontinue use immediately.
- Do not attempt to disassemble or modify the device. This will void the warranty and may cause damage or injury.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

5. SETUP

5.1 Initial Charging

Before first use, fully charge the device. Connect the magnetic USB charging cable to the charging points on the device and plug the USB end into a compatible power source (e.g., wall adapter, computer USB port, power bank).



Figure 5.1: The JFN01 device utilizes magnetic USB charging, compatible with various power sources including car chargers, power banks, laptops, and wall chargers.

The indicator light on the device will typically blink during charging and become solid when fully charged. Charging time may vary but usually takes 1-2 hours.

5.2 App Download and Pairing

1. Scan the QR code provided in the product packaging or search for the official app name (e.g., "Magic Motion" or similar) in your mobile device's app store (App Store for iOS, Google Play Store for Android).
2. Download and install the application.
3. Ensure your device is charged and powered on (refer to Section 6.1).
4. Enable Bluetooth on your mobile device.
5. Open the app and follow the on-screen instructions to pair your JFN01 device. The app will typically detect nearby devices automatically.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

- **To Power On:** Press and hold the power button on the device for approximately 2-3 seconds until the indicator light illuminates and the device vibrates briefly.
- **To Power Off:** Press and hold the power button for approximately 2-3 seconds until the indicator light turns off.

6.2 Mode Selection (Manual Control)

Once powered on, short press the power/mode button to cycle through the available vibration modes. Each press will switch to the next mode. Refer to Figure 2.1 for an illustration of various modes.

6.3 App Control

For advanced control and customization, use the dedicated mobile application:

1. Ensure the device is powered on and successfully paired with the app (refer to Section 5.2).
2. Open the app on your mobile device.
3. Within the app interface, you can select from various vibration patterns, adjust intensity levels, and explore additional features such as long-distance control (if supported by the app).

7. CHARGING

When the battery is low, the indicator light may flash or the device's performance may decrease. Recharge the device using the provided magnetic USB cable.

- Connect the magnetic end of the cable to the charging contacts on the device.
- Plug the USB end into a standard USB power source (5V/1A recommended).
- The indicator light will typically blink during charging.
- Once fully charged, the indicator light will become solid. Disconnect the charger.

Do not overcharge the device. Avoid leaving it connected to power for extended periods after it is fully charged.

8. MAINTENANCE AND CARE

8.1 Cleaning



Figure 8.1: The JFN01 device is 100% waterproof, allowing for easy and thorough cleaning under running water.

The JFN01 device is 100% waterproof for easy cleaning.

1. Before and after each use, clean the device with warm water and a mild, toy-safe soap or specialized toy cleaner.
2. Rinse thoroughly to remove all soap residue.
3. Pat dry with a lint-free cloth or allow to air dry completely before storage.
4. Do not use harsh chemicals, alcohol, or abrasive cleaners, as these can damage the material.

8.2 Storage

Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep it separate from other materials that might react with silicone.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully (refer to Section 7).
Device does not turn on.	Power button not pressed correctly.	Press and hold the power button for 2-3 seconds.
Device not connecting to app.	Bluetooth is off on mobile device.	Ensure Bluetooth is enabled on your phone.
Device not connecting to app.	Device is not powered on.	Power on the device.
Device not connecting to app.	App not updated or installed correctly.	Reinstall or update the app. Ensure app permissions are granted.
Charging indicator not working.	Cable not properly connected.	Ensure magnetic contacts are clean and cable is securely attached. Try a different USB port or power adapter.

10. SPECIFICATIONS

- **Model:** JFN01
- **Brand:** Generic
- **Color:** Purple
- **Material:** Body-safe Silicone
- **Dimensions:** Approximately 1.37 x 3.07 inches (3.48 x 7.8 cm)
- **Noise Level:** <40dB
- **Charging:** Magnetic USB
- **Waterproof Rating:** 100% Waterproof
- **Control:** App-controlled, Manual button control
- **Modes:** Multiple frequency modes (e.g., 12 modes as per image)

11. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the packaging or contact the seller directly. If you encounter any issues or have questions regarding your Generic JFN01 device, please contact the seller or manufacturer's customer support for assistance.

Please have your purchase information and model number (JFN01) ready when contacting support.

