Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KEPLUG zh188 US M

KEPLUG Sunrise Alarm Clock Sound Machine User Manual

Model: zh188 US M

Introduction

Thank you for choosing the KEPLUG Sunrise Alarm Clock Sound Machine. This device is designed to enhance your sleep and wake-up experience with its natural sunrise simulation, soothing sleep sounds, and versatile lighting options. Please read this manual carefully to understand its features and ensure proper operation.



KEPLUG Sunrise Alarm Clock simulating a sunrise wake-up.

Setup

Package Contents

- 1 x KEPLUG Sunrise Alarm Clock with Sleep Sound Machine
- 1 x Type-C Charging Cable
- 1 x Power Adapter
- 1 x User Manual

Power Connection

The KEPLUG Sunrise Alarm Clock is powered via USB. Connect the provided Type-C charging cable to the clock and plug the power adapter into a standard electrical outlet. The device requires continuous power to function normally.

For battery backup, insert 2 AAA batteries (not included) into the battery compartment. These batteries preserve time settings during a power outage but do not power the alarm clock for normal operation.



The alarm clock requires continuous power via USB; batteries are for backup only.

Initial Time Setting

Upon first power-up or after a power outage without battery backup, you may need to set the current time. Refer to the 'Operating Instructions' section for detailed steps on setting the time and date.

Your browser does not support the video tag.

Video demonstrating the basic functions and light display of the KEPLUG Sunrise Alarm Clock.

Operating Instructions

Button Functions

The KEPLUG Sunrise Alarm Clock features intuitive buttons for easy control. Familiarize yourself with the layout:



Overview of the control buttons and their functions.

- **Snooze/Nightlight On/Off:** Activates snooze during an alarm or turns the nightlight on/off.
- **RGB Light:** Cycles through RGB light colors.
- **Alarm 2:** Sets or activates Alarm 2.
- **Time:** Enters time setting mode.
- **Alarm 1:** Sets or activates Alarm 1.

- **Light Dimmer:** Adjusts the brightness of the main light.
- **Timer:** Sets the sleep timer duration.
- **Sleep Sounds:** Cycles through available sleep sounds.
- **Setup/Volume+/Next Sound:** Used for setup, increasing volume, or selecting the next sound.
- **Setup/Volume-/Previous Sound:** Used for setup, decreasing volume, or selecting the previous sound.
- **Display Dimmer:** Adjusts the brightness of the time display.


Setting Alarms and Sunrise Wake-Up

The clock features a dual alarm system, allowing you to set separate alarms for weekdays and weekends, or for different users.

1. Press the **Alarm 1** or **Alarm 2** button to select an alarm.
2. Use the **Setup/Volume+** and **Setup/Volume-** buttons to adjust the alarm time.
3. Press the **Alarm** button again to confirm and move to the next setting (e.g., alarm sound, volume, sunrise duration).
4. The sunrise simulation can be set to gradually brighten over 0-60 minutes before your alarm time.
5. Choose from 7 alarm sounds or set it to mute for light-only wake-up.



Dual alarm settings for customized wake-up routines.



Gentle sunrise wake-up light simulation.

Your browser does not support the video tag.

Video demonstrating the sunrise simulation feature of the alarm clock.

Using the Sound Machine

The clock offers 30 soothing sleep sounds to help you relax and fall asleep. These include 10 white noise options and 20 nature sounds.

1. Press the **Sleep Sounds** button to cycle through the available sounds.
2. Use the **Setup**/**Volume+** and **Setup**/**Volume-** buttons to adjust the volume (16 levels).



Selection of 30 soothing sounds for sleep.

Adjusting Light and RGB Night Lamp

The main light has 0-20 dimmable brightness levels, and there are 8 RGB night lamp colors to choose from.

1. Press the **Light Dimmer** button to adjust the brightness of the main light.
2. Press the **RGB Light** button to cycle through the 8 available colors for the night lamp.
3. The night light can be controlled independently.



8 colors night light for creating ambiance.



Infinite adjustable brightness display for optimal comfort.


Your browser does not support the video tag.

Video showcasing the various light colors and brightness adjustments.

Customizable Sleep Timer

Set a sleep timer to gradually fade out light and sound, promoting a peaceful transition to sleep. Available durations are 15, 30, 60, 90, 120, and 180 minutes.

1. Press the **Timer** button.
2. Use the **Setup/Volume+** and **Setup/Volume-** buttons to select your desired duration.
3. The light and sound will gradually decrease and turn off after the set time.



Auto-off timer options for sleep.

Maintenance

To ensure the longevity and optimal performance of your KEPLUG Sunrise Alarm Clock, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface.
- **Storage:** When not in use for extended periods, store the alarm clock in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts.
- **Power:** Always use the provided power adapter and cable. Do not attempt to use incompatible power sources.

Troubleshooting

If you encounter any issues with your KEPLUG Sunrise Alarm Clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	No power connection or faulty adapter.	Ensure the USB cable is securely connected and the power adapter is plugged into a working outlet. Try a different USB port or adapter if available.
Alarm does not sound or light up.	Alarm not set correctly, volume too low, or light brightness set to 0.	Verify alarm settings (time, sound, light duration). Increase alarm volume and light brightness.
Time display is incorrect.	Time not set after power interruption or incorrect setting.	Reset the current time using the 'Time' button. Ensure AAA backup batteries are installed if frequent power outages occur.
Sound quality is poor or no sound.	Volume too low or speaker obstruction.	Increase the volume. Ensure the speaker is not covered.

Problem	Possible Cause	Solution
Light is not changing colors.	RGB mode not activated or specific color selected.	Press the 'RGB Light' button to cycle through colors or activate color-changing mode.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	KEPLUG
Model Number	zh188 US M
Color	Light Gray
Display Type	Digital
Product Dimensions	5.47"W x 6.3"H
Power Source	Corded Electric (USB)
Battery Backup	2 AAA batteries (not included) for time settings only
Special Features	Dual Alarms, Sunrise Simulation (0-60 min), 30 Soothing Sounds (16 volume levels), 8 RGB Night Light Colors, 20 Light Brightness Levels, Customizable Sleep Timer (15/30/60/90/120/180 min), Dimmable Display
Room Type	Bedroom, Baby Room, Dorm, Living Room, Home Office

Warranty Information

KEPLUG products are manufactured with high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. Specific warranty duration and terms may vary by region and retailer. For detailed warranty information, please refer to the documentation included with your purchase or contact KEPLUG customer support.

Support

For further assistance, product inquiries, or technical support, please visit the official KEPLUG store or contact our customer service team:

- **KEPLUG Store:** Visit KEPLUG on Amazon
- **Customer Service:** Refer to your product packaging or the KEPLUG store page for contact details.

© 2023 KEPLUG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H25CKG48

More documents and user manuals: **https://manuals.plus/**