Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MXV TS08

MXV 70-Inch Fireplace TV Stand with 36-Inch Electric Fireplace User Manual

Model: TS08 | Brand: MXV

1. Introduction

Thank you for purchasing the MXV 70-Inch Fireplace TV Stand. This product combines a stylish media console with a functional 36-inch electric fireplace, offering both aesthetic appeal and practical heating. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand and electric fireplace.

2. Safety Information

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in fire, electric shock, or injury.

General Safety Precautions:

- Keep all packaging materials away from children.
- Ensure the product is assembled on a flat, stable surface.
- Do not overload the TV stand. Refer to specifications for weight limits.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not block air vents of the electric fireplace.
- Unplug the fireplace from the power outlet before cleaning or maintenance.
- This product is for indoor use only.
- The electric fireplace is CSA, ETL, and UL-certified for safety.

3. Package Contents

Your MXV Fireplace TV Stand ships in two separate packages (Box A and Box B), which may arrive at different times. Please ensure all parts are present before beginning assembly.




Figure 3.1: Electric Fireplace and TV Stand Components with Packaging Information.

Included Components:

- Electric Fireplace Insert (Box A)
- TV Stand Panels and Hardware (Box B)
- Remote Control for Fireplace
- Illustrated Assembly Manual

Note: Refer to the separate assembly manual included in Box B for a detailed list of all panels and hardware specific to the TV stand structure.

4. Setup and Assembly

Assembly typically takes about 2 hours with 1-2 people. Follow the step-by-step instructions provided in the separate illustrated manual. Ensure you have a Phillips head screwdriver and a hammer (not included) for assembly.

Key Assembly Features:

- **Pre-drilled Holes:** All panels come with pre-drilled holes for easier alignment.
- **Numbered Parts:** Components are clearly numbered to match the assembly guide.
- **Cable Management:** The back panel includes pre-cut holes for organizing cables.



Figure 4.1: Cable Management Hole for organized wiring.

After assembling the TV stand structure, carefully insert the electric fireplace into its designated opening. Ensure it is securely seated and all connections are made according to the fireplace's specific instructions.

5. Operating Instructions

5.1 Electric Fireplace Operation

The 36-inch electric fireplace can be operated using the control panel on the unit or the included infrared remote control.




Figure 5.1: Electric Fireplace Features and Controls.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Temperature Control:** Adjust the temperature from 60°F to 99°F (15°C to 37°C). The fireplace heats areas up to 400 sq. ft.
- **Heating Modes:** Select between 750W (low heat) and 1500W (high heat) settings.
- **Flame Colors:** Choose from 12 different flame colors to match your mood.
- **Flame Brightness:** Adjust the flame effect brightness with 5 available levels. The flame effects can be used independently without heat.
- **Timer Function:** Set the automatic shut-off timer from 0 to 8 hours.
- **Safety Features:** Includes auto shut-off and overheat protection.

5.2 LED Mood Lighting Operation

The TV stand features an independent RGB LED strip and double LED lights for ambient lighting.



Figure 5.2: 12-Color LED Light Strip for ambient lighting.

- **Color Selection:** Choose from 12 backlight colors for the LED strip.
- **Control:** The LED lights can be adjusted using the remote control.

5.3 Storage and Cable Management

The TV stand is designed with practical storage solutions and cable organization.



Figure 5.3: Overview of TV Stand Storage and Design Elements.

- **Side Cabinets:** Two side cabinets with high-gloss doors provide enclosed storage.
- **Open Cubbies:** Central open cubbies are ideal for media devices.
- **Adjustable Shelves:** Shelves within the cabinets may be adjustable to accommodate various item sizes.
- **Cable Holes:** Use the integrated cable management holes on the back panel to route and conceal wires.

6. Maintenance

Regular maintenance will help prolong the life and appearance of your TV stand and electric fireplace.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners that may damage the high-gloss finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, dry cloth to wipe the exterior. Do not spray water directly onto the unit.

- **Ventilation:** Periodically check that the air intake and exhaust vents of the fireplace are clear of dust and obstructions.
- **Remote Control:** Replace batteries as needed (typically 2x AAA, not included).

7. Troubleshooting

If you encounter issues with your MXV Fireplace TV Stand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power switch off, remote batteries dead.	Check power cord connection, ensure wall outlet is functional, turn on main power switch on fireplace, replace remote batteries.
No heat output.	Heat function not activated, thermostat set too low, overheat protection activated.	Activate heat function via control panel or remote, increase thermostat setting, unplug unit for 5-10 minutes to reset overheat protection.
Flame effect not working.	Flame function not activated.	Activate flame effect via control panel or remote.
Remote control not responding.	Dead batteries, obstruction, remote out of range.	Replace batteries, ensure clear line of sight to fireplace sensor, operate within recommended range.
Unusual noise from fireplace.	Dust in fan, minor expansion/contraction.	Ensure vents are clear. If noise persists or is loud, discontinue use and contact support.



Figure 7.1: The electric fireplace is designed for low-noise operation.

8. Specifications

Feature	Detail

Feature	Detail
Brand	MXV
Model Number	TS08
Overall Dimensions	70 x 13.7 x 22.2 inches (L x W x H)
Fireplace Dimensions	36 inches (width)
Color	Black + Black
Material	P2-grade Eco-friendly MDF, FSC-certified board, Acrylic Columns
Item Weight	87 pounds
TV Size Compatibility	Up to 80 inches
Desktop Weight Capacity	Up to 300 lbs
Shelf Weight Capacity	Up to 33 lbs per shelf
Fireplace Heating Area	Up to 400 sq. ft.
Fireplace Power Modes	750W / 1500W
Temperature Range	60°F – 99°F
Flame Colors	12 options
Flame Brightness Levels	5 options
LED Backlight Colors	12 options
Timer	0-8 hours
Certifications	CSA, ETL, UL




Figure 8.1: TV Size Compatibility for the MXV Fireplace TV Stand.

9. Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact the retailer. If you require assistance with assembly, parts, or troubleshooting beyond this manual, please contact MXV customer support.

Customer Support: Please visit the MXV official website or contact your point of purchase for support contact details.

© 2026 MXV. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H2DTK5H4

More documents and user manuals: **https://manuals.plus/**