Vongrasig 5YTBSF-DB

Vongrasig 5-Piece Outdoor Sectional Furniture Instruction Manual

Model: 5YTBSF-DB

1. Product Overview

The Vongrasig 5-Piece Outdoor Sectional Furniture set is designed for versatile outdoor living spaces such as patios, porches, backyards, balconies, and poolside areas. This set features a sturdy, rustproof, powder-coated steel frame and hand-woven resin wicker, ensuring durability against various weather conditions. The design allows for flexible arrangement of its components to suit different seating or lounging needs.



Image 1.1: The Vongrasig 5-Piece Outdoor Sectional Furniture set in a typical outdoor arrangement.

2. Package Contents

Before beginning assembly, please verify that all components listed below are present in your package. The set ships in multiple boxes; do not be concerned if not all boxes arrive simultaneously.

- 2 x Corner Chairs
- 2 x Armless Chairs
- 1 x Coffee Table with Tempered Glass Top
- Cushions for all seating pieces
- Assembly Hardware (screws, washers, Allen wrench)



Image 2.1: Detailed dimensions and individual components of the furniture set.

3. Setup & Assembly

Assembly is required for this furniture set. It is recommended to have at least two people for easier and quicker assembly. Ensure you have enough space to lay out all components before starting.

1. **Unpack Components:** Carefully remove all parts from the packaging. Keep the packaging materials until assembly is complete to ensure no small parts are discarded.
2. **Identify Parts:** Refer to the included instruction manual and diagrams to identify each piece (corner chairs, armless chairs, coffee table, cushions, hardware).
3. **Assemble Chairs:** Follow the specific instructions provided in your manual for assembling the corner and armless chairs. Typically, this involves attaching the backrests and side panels to the seat base using the provided screws and Allen wrench. Do not fully tighten screws until all parts are loosely connected.
4. **Assemble Coffee Table:** Construct the coffee table frame according to the instructions. Once the frame is assembled, carefully place the tempered glass top onto the table, securing it with the provided suction cups to prevent movement.

5. **Connect Sectional Pieces:** Use the plastic clips provided to connect the individual chair sections together. These clips ensure the pieces remain securely in place when arranged as a sectional.
6. **Place Cushions:** Position the seat and back cushions on the assembled chairs. The cushions are designed with non-slip covers to help keep them in place.
7. **Final Tightening:** Once all components are assembled and positioned, go back and fully tighten all screws on the chairs and table.

If you encounter any difficulties during assembly, please refer to the detailed diagrams in your physical instruction manual or contact customer support.

4. Operating Instructions (Usage)

The Vongrasig 5-Piece Outdoor Sectional Furniture offers flexible configurations to adapt to your outdoor space and needs.

- **Modular Design:** Each chair piece can be used independently or connected together using the provided clips to form various sectional layouts (e.g., L-shape, straight sofa, individual seating).
- **Placement:** Position the furniture on a flat, stable surface. While designed for outdoor use, placing it under a covered area or using a furniture cover during harsh weather will extend its lifespan.
- **Cushion Comfort:** The 3-inch thick cushions provide comfort for extended use. Ensure cushions are properly seated to prevent shifting.



Image 4.1: Example of the sectional furniture arranged for use on a patio.

5. Maintenance & Care

Proper care will help maintain the appearance and longevity of your Vongrasig outdoor furniture.

- **Wicker Frame:** The hand-woven resin wicker is water-resistant. Clean the wicker frame with a soft cloth, mild soap, and water. Rinse thoroughly and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The zippered cushion covers are made of fade-resistant and water-spill repellent fabric. They are washable. For minor spills, wipe immediately with a clean, damp cloth. For deeper cleaning, remove covers and hand wash or machine wash on a gentle cycle with cold water and mild detergent. Air dry only; do not tumble dry.
- **Glass Table Top:** The tempered glass top can be easily wiped clean with a damp cloth and a glass cleaner.
- **Steel Frame:** The powder-coated steel frame is rustproof. Inspect periodically for any signs of wear or rust, and touch up with appropriate outdoor paint if necessary.
- **Weather Protection:** While designed for all-weather use, it is recommended to cover the furniture during prolonged periods of non-use or severe weather conditions (e.g., heavy rain, snow, strong winds) to extend its service life. Store cushions indoors during inclement weather.



Image 5.1: Details of the cushion and rattan construction, important for maintenance.

6. Troubleshooting

This section addresses common issues you might encounter with your Vongrasig outdoor sectional furniture.

- **Difficulty during assembly:** Ensure all parts are correctly oriented according to the diagrams. Do not fully tighten screws until all components are loosely connected. If a part does not fit, double-check the part number and orientation.
- **Cushions sliding:** The cushions are designed with non-slip covers. Ensure they are placed correctly. If cushions still slide in windy conditions, consider adding furniture ties (not included) to secure them to the frame.
- **Glass table top unstable:** Ensure the suction cups are properly attached to both the table frame and the glass top. Press down firmly on the glass over each suction cup to create a secure seal.
- **Sectional pieces separating:** Verify that the plastic connector clips are correctly installed between the desired sectional pieces. Ensure they are fully engaged to prevent movement.
- **Wicker damage:** While durable, avoid sharp objects or excessive force that could damage the rattan weaving.

For minor fraying, a small amount of clear outdoor adhesive can be used to secure loose strands.

7. Specifications

Feature	Detail
Brand	Vongrasig
Model Number	5YTBSF-DB
Color	Navy Blue
Number of Pieces	5 (2 Corner Chairs, 2 Armless Chairs, 1 Coffee Table)
Material	Rattan (PE Wicker), Powder-Coated Steel Frame, Tempered Glass, Foam Cushions
Item Dimensions (Overall L-Shape)	76.8 x 50.2 x 25 inches (L x W x H)
Item Weight	96 pounds
Cushion Thickness	3 inches



Image 7.1: Detailed dimensions of the furniture set components.

8. Warranty & Support

For any questions, concerns, or support needs regarding your Vongrasig 5-Piece Outdoor Sectional Furniture, please contact the seller directly through your purchase platform. Refer to your order details to find the 'Contact Seller' option. Please have your model number (5YTBSF-DB) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question