

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Heavy Duty Twin XL Loft Bed Frame Instruction Manual

Bellemave Loft Bed with Ladder

Bellemave Heavy Duty Twin XL Loft Bed Frame Instruction Manual

Model: Loft Bed with Ladder

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bellemave Heavy Duty Twin XL Loft Bed Frame. Please read all instructions carefully before assembly and use to ensure safe and proper operation of the product.



Image 1.1: Bellemave Heavy Duty Twin XL Loft Bed Frame.



Image 1.2: The loft bed provides significant under-bed clearance for additional furniture or storage.

2. SAFETY INFORMATION

Your safety is paramount. Adhere to the following guidelines:

- **Guardrails:** The loft bed frame is equipped with full-length guardrails on all four sides to prevent accidental falls. Ensure these are securely installed before use.
- **Ladders:** Two built-in ladders are provided for safe access to the bed. Always use the ladders for climbing up and down.
- **Anti-tip Device:** For enhanced stability and security, it is recommended to fix the loft bed to the wall using an anti-tip device. Follow the instructions provided in the assembly guide for proper installation.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 350 pounds.
- **Children's Product Certificate (CPC):** This product is certified by the Children's Product Certificate (CPC) for safety.

- **Mattress:** Use only a mattress that complies with the recommended dimensions for a Twin XL bed.




Image 2.1: Illustration of the anti-tip device installation for wall stability.



Image 2.2: Detail of the sturdy built-in ladder for safe access.

3. PACKAGE CONTENTS

The Bellemave Heavy Duty Twin XL Loft Bed Frame is shipped in two boxes. Please ensure all components are present before beginning assembly. Each order includes a clear and detailed assembly instruction guide and all necessary tools for assembly.

Included Components:

- Bed Frame Components (posts, rails)
- Guardrails
- Ladders (2 built-in)
- Steel Slats (20 pieces)
- Center Support Bar (1 piece)
- Hardware (screws, bolts, nuts)
- Noise-reducing rubber stoppers
- Anti-tip device
- Assembly Tools
- Assembly Instruction Guide

4. SETUP AND ASSEMBLY

Assembly of the Bellemave Twin XL Loft Bed Frame is designed to be straightforward. Refer to the included assembly instruction guide for step-by-step visual directions.

1. **Unpack:** Carefully unpack all components from both boxes and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the parts list in your assembly guide.
2. **Frame Assembly:** Begin by assembling the main frame structure according to the provided diagrams. Ensure all connections are finger-tightened initially.
3. **Guardrail and Ladder Attachment:** Attach the full-length guardrails and built-in ladders to the frame.
4. **Slat Installation:** Install the 20 steel slats and the center support bar onto the bed frame. Ensure the noise-reducing rubber stoppers are correctly placed to secure the slats and prevent movement.
5. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Ensure all connections are firm and secure for wobble-resistant sturdiness.
6. **Anti-tip Device Installation:** Install the anti-tip device by fixing the loft bed to a wall for added stability and security.

It is recommended to have two adults for assembly to ensure ease and safety during the process.

5. OPERATING INSTRUCTIONS

The Bellemave Heavy Duty Twin XL Loft Bed Frame is designed for comfortable and efficient use of space.

- **Mattress Use:** This loft bed does not require a box spring or foundation. Place your Twin XL mattress directly onto the steel slats. The 20 steel slats and 1 center support bar provide adequate support.
- **Access:** Use the two built-in ladders to safely access and exit the bed.
- **Under-Bed Space:** The design offers 51 inches of under-bed clearance, allowing you to utilize the space for a desk, seating area, storage, or other creative arrangements.
- **Weight Limit:** Adhere to the maximum weight capacity of 350 pounds for safe use.




Image 5.1: Key features including weight capacity, slat count, noise reduction, and guardrail height.

Your browser does not support the video tag.

Video 5.1: An overview of the Bellemave Twin XL Loft Bed Frame in a room setting, demonstrating its design and space-saving capabilities.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and safety of your loft bed frame.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the powder-coated finish.
- **Hardware Check:** Periodically check all screws, bolts, and connections to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent wobbling.

- **Noise Reduction:** The bed is designed with noise-reducing rubber stoppers. If any squeaking or noise occurs, inspect the rubber stoppers and slat connections to ensure they are properly seated.
- **Anti-rust Coating:** The heavy-duty steel frame features an anti-rust coating for durability. Avoid scratching the surface to preserve this coating.

7. TROUBLESHOOTING

If you encounter any issues with your Bellemave Loft Bed Frame, refer to the following common solutions:

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose hardware connections.	Check and tighten all screws and bolts securely. Ensure the anti-tip device is properly installed.
Squeaking or noise from the bed.	Slats moving or loose connections.	Verify that the noise-reducing rubber stoppers are correctly positioned on the slats. Ensure all slat connections are tight.
Missing parts during assembly.	Oversight during unpacking.	Carefully re-check all packaging materials. If parts are still missing, contact customer support.

8. SPECIFICATIONS

Detailed specifications for the Bellemave Heavy Duty Twin XL Loft Bed Frame:

- **Size:** Twin XL
- **Material:** Heavy-duty Metal (Steel)
- **Product Dimensions (L x W x H):** 82.7" x 41.7" x 64.6"
- **Under-Bed Clearance:** 51 inches
- **Style:** Modern
- **Color:** Black
- **Finish Type:** Powder Coated
- **Special Features:** No Box Spring Needed, Safety Guardrail, Space Saving, Noise Free Design
- **Included Components:** Guardrails, Ladders, Slats (20 pcs), Center Support Bar
- **Weight Capacity:** 350 lbs
- **Item Weight:** 30 pounds
- **Model Number:** Loft Bed with Ladder
- **UPC:** 800067076303
- **ASIN:** B0H2LPCTJ1

UNIT:INCH




Image 8.1: Dimensional drawing of the loft bed frame.

9. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your Bellemave Heavy Duty Twin XL Loft Bed Frame, please contact our customer support team.

- **Returns:** This product is eligible for 30-day free returns. Refer to your purchase platform for specific return policies.
- **Customer Support Email:** US-VC@bellemavehome.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question