

[Manuals.plus](#) /

› [TABWEE](#) /

› TABWEE T70 11-inch Android 16 Tablet User Manual

TABWEE T70

TABWEE T70 11-inch Android 16 Tablet User Manual

Model: T70

INTRODUCTION

Thank you for purchasing the TABWEE T70 11-inch Android 16 Tablet. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your tablet.

PACKAGE CONTENTS

The TABWEE T70 tablet comes with a comprehensive set of accessories to enhance your user experience. Please verify that all items are present in your package.

- TABWEE T70 11-inch Android 16 Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Touch Pen (Stylus)
- Headphones
- Protective Case with Stand Function
- USB Type-C Charging Cable
- Power Adapter
- User Manual (this document)

安心の充実セット！ 届いたその日から、 すぐに使える

- | | |
|-----------|-----------|
| 1. キーボード | 2. マウス |
| 3. 有線イヤホン | 4. 保護ケース |
| 5. タッチペン | 6. 保護フィルム |
| 7. 充電器 | 8. 取扱説明書 |



Image: TABWEE T70 tablet with its full accessory kit, including keyboard, mouse, stylus, headphones, charging cable, power adapter, and protective case.

SETUP

1. Initial Power On and Charging

Before first use, fully charge your TABWEE T70 tablet.

1. Connect the USB Type-C cable to the tablet's charging port.
2. Connect the other end of the cable to the power adapter, then plug the adapter into a wall outlet.
3. The battery indicator on the screen will show charging status. Once fully charged, disconnect the charger.
4. Press and hold the power button located on the side of the tablet until the TABWEE logo appears.




Image: The TABWEE T70 tablet connected to a charger via its USB-C port.

2. Connecting Bluetooth Accessories (Keyboard, Mouse)

The TABWEE T70 supports Bluetooth 5.0 for connecting external devices like the included keyboard and mouse.

1. **For Keyboard:** Turn on the power switch on the keyboard. Press the "Connect" button; the Bluetooth indicator light will flash, indicating pairing mode.
2. **For Mouse:** Turn on the power switch on the mouse. It should automatically enter pairing mode or have a dedicated pairing button.

3. On your tablet, go to **Settings > Connected devices > Bluetooth**. Turn on Bluetooth.
4. The tablet will search for available devices. Select "Bluetooth 3.0 Keyboard" (or similar name for the mouse) from the list to complete the connection.



Image: Step-by-step guide for pairing the Bluetooth keyboard with the TABWEE T70 tablet.

3. Wi-Fi Connection

Connect your tablet to a Wi-Fi network to access the internet.

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Turn on Wi-Fi. The tablet will scan for available networks.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted, then tap **Connect**.

4. Google Account Setup

A Google account is required to download apps from the Google Play Store and access Google services.

1. During initial setup, you will be prompted to sign in with your Google account. Follow the on-screen instructions.
2. If you skip this step, you can add an account later via **Settings > Accounts > Add account > Google**.

OPERATING YOUR TABLET

1. Basic Navigation and User Interface

The TABWEE T70 runs on Android 16, offering an intuitive user interface.

- **Touch Gestures:** Use taps, swipes, and pinches to navigate the interface, open apps, scroll, and zoom.
- **Home Screen:** Customize with widgets and app shortcuts.
- **Notification Panel:** Swipe down from the top of the screen to access notifications and quick settings.
- **Multitasking:** Android 16 allows for smooth switching between applications and split-screen functionality for enhanced productivity.

PCレベルの機能を備えた WPS Officeを内蔵！

Google Playストアから各種オフィスアプリを
ダウンロード可能。
仕事にもスムーズに対応！



MS Office搭載



Image: The Android 16 operating system interface on the TABWEE T70, demonstrating app management and multitasking capabilities.

2. Using Gemini AI

The TABWEE T70 integrates Gemini AI to assist with various tasks.

- **Information Retrieval:** Ask questions or search for information using voice commands or text input.
- **Content Creation:** Generate text, summarize documents, or assist with creative writing.
- **Organization:** Help manage notes, schedules, and other information.
- **Translation:** Translate text or speech in real-time.

Gemini AI搭載

学習、仕事、日常の情報収集まで、よりスムーズで効率的な体験を実現します。




音声・テキストアシスト
話しかけるだけで、検索・
質問・操作をサポート



情報整理・要約
長い文章や情報を分かりや
すくまとめて表示



ライティングサポート
文章作成やメモ整理をスム
ーズにサポート



翻訳
多言語を自然に変換し、コミ
ュニケーションをサポート
旅行・学習・ビジネスにも活
用可能



クリエイティブデザイン
アイデア出しからコンテン
ツ制作まで幅広くサポート



学習・調べもの支援
知りたい情報に素早くアク
セスし、学習効率を向上

Image: The Gemini AI interface on the TABWEE T70, showcasing its capabilities for chat, voice commands, photo editing, and video creation.

3. Display Settings and Media Consumption

The 11-inch IPS display offers a 90Hz refresh rate and 180Hz touch sampling for a smooth visual and interactive experience.

- **Refresh Rate:** Enjoy smoother scrolling and animations with the 90Hz refresh rate.
- **Eye Care Mode:** Activate this mode in settings to reduce blue light emission, making reading more comfortable, especially in low light.
- **Widevine L1 Support:** Stream high-definition content from services like Netflix, Prime Video, and Disney+ with Widevine L1 certification.
- **Wireless Projection:** Share your tablet screen wirelessly to a compatible TV or monitor for a larger viewing experience.

保護者による使用制限

保護者はリモートでタブレットの使用時間を管理でき、フォーカスモードにより学習中の子どもへの干渉を最小限に抑えられます。



利用時間上限設定



休憩時間設定



アプリの利用制限



コンテンツの制限



Image: The TABWEE T70 display showcasing vibrant visuals, emphasizing its Widevine L1 certification for high-quality streaming.

ワイヤレス投影対応！

臨場感と没入感を、そのまま大画面へコンテンツをより大きく、よりダイナミックに楽しめます。

NETFLIX

prime video

YouTube

hulu

HBO



Image: A family enjoying content projected wirelessly from the TABWEE T70 tablet to a television, demonstrating the wireless projection feature.

4. Storage Management

The tablet comes with 256GB of internal storage and supports microSD card expansion up to 2TB.

- **Internal Storage:** Manage your apps, photos, videos, and documents.
- **MicroSD Card:** Insert a microSD card into the designated slot to expand storage for media files and large documents.

普段使いにちょうどいい高性能CUP

SNS・ネット検索・動画視聴・オンライン学習など、日常操作もストレスなく快適に。



Image: The TABWEE T70 highlighting its 32GB RAM and 256GB storage, with support for up to 2TB microSD expansion.

5. Camera Usage

Capture moments with the 13MP rear camera and 8MP front camera.

- Open the Camera app from your home screen or app drawer.
- Switch between front and rear cameras as needed.
- Utilize AI image processing and Google Lens features for enhanced photography.



Image: The TABWEE T70 camera system, featuring a 13MP rear camera, 8MP front camera, Google Lens integration, and AI image optimization.

6. Parental Controls

Manage your child's tablet usage with built-in parental control features.

- Set usage time limits for the tablet.
- Restrict access to specific applications or content.
- Utilize Focus Mode to minimize distractions during study time.

選びたくなる2色、新登場。

洗練されたカラーが、日常をおしゃれに彩ります。



動画視聴



電子書籍



PDF閲覧



Image: The TABWEE T70 demonstrating parental control options, including setting usage time limits and restricting content access.

7. Face Recognition

Unlock your tablet quickly and securely using face recognition.

1. Go to **Settings > Security & privacy > Face unlock**.
2. Follow the on-screen instructions to register your face.
3. Once set up, simply look at the tablet's front camera to unlock it.

MAINTENANCE

1. Battery Management

The TABWEE T70 is equipped with an 8000mAh battery for extended use.

- To prolong battery life, avoid extreme temperatures.
- Use the provided charger for optimal charging.
- Enable power-saving mode in **Settings > Battery** to conserve power.

Bluetooth

キーボードの接続方法：

1. キーボード本体の電源スイッチをオンにします。
2. 「Connect」ボタンを押すと、Bluetoothランプが点滅し、ペアリングモードに入ります。
3. タブレット側でBluetooth設定を開き、デバイスを検索して接続します。
4. 表示された「Bluetooth 3.0 Keyboard」を選択して接続を完了します。



Image: The TABWEE T70's 8000mAh battery capacity, illustrating usage times for reading, video playback, light gaming, and document work.

2. Cleaning Your Tablet

Keep your tablet clean to maintain its appearance and functionality.

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals or abrasive materials.
- Ensure the tablet is powered off and unplugged before cleaning.

3. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features and security enhancements.

- Go to **Settings > System > System update**.
- Follow the on-screen instructions to download and install any available updates.

TROUBLESHOOTING

Common Issues and Solutions

Issue	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect to the charger and wait a few minutes before attempting to power on again.
Screen is unresponsive.	Restart the tablet by holding the power button for 10-15 seconds. If the issue persists, perform a factory reset (data will be lost).
Wi-Fi connection issues.	Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Ensure you are within range of the Wi-Fi signal.
Bluetooth accessory not connecting.	Ensure the accessory is in pairing mode and fully charged. Turn Bluetooth off and on again on the tablet. Remove and re-pair the device.
Apps are slow or crashing.	Close unnecessary background apps. Clear app cache (Settings > Apps > select app > Storage & cache > Clear cache). Restart the tablet.

For persistent issues, please refer to the Warranty and Support section for contact information.

SPECIFICATIONS

Feature	Detail
Brand	TABWEE
Model Name	T70
Operating System	Android 16
CPU	UNISOC T7250 Octa-core (2x Cortex-A75 + 6x Cortex-A55) @ 1.8 GHz
GPU	Mali-G57
RAM	32 GB (8GB Physical + 24GB Virtual)
Internal Storage	256 GB
Expandable Storage	MicroSD up to 2 TB
Display Size	11 inches

Feature	Detail
Display Type	IPS
Display Resolution	1280x800 pixels
Refresh Rate	90 Hz
Touch Sampling Rate	180 Hz
Battery Capacity	8000 mAh
Rear Camera	13 MP
Front Camera	8 MP
Connectivity	Wi-Fi (802.11a/b/g/n/ac), Bluetooth 5.0
Ports	USB Type-C, 3.5mm Headphone Jack
Dimensions (LxWxH)	25 x 17 x 0.9 cm
Weight	551 grams
Certifications	GMS, PSE
Additional Features	Gemini AI, USB OTG, Parental Controls, Split Screen, Face Recognition

WARRANTY AND SUPPORT

TABWEE provides comprehensive support for your T70 tablet.

- **Standard Warranty:** Your tablet comes with a 2-year manufacturer's warranty.
- **Extended Warranty:** You can extend the warranty period up to 4 years by contacting TABWEE official support.
- **Customer Support:** For any product malfunctions or inquiries, please contact customer support.

How to Contact Support:

You can typically reach support through your Amazon account:

1. Go to your Amazon Account.
2. Navigate to "Your Orders".
3. Find your TABWEE T70 order.
4. Select "Contact Seller" or "Get Product Support".

Support is available during business hours (e.g., Weekdays 10:00 - 19:00 JST, excluding weekends and holidays).



[安心のアフターサポート体制]

製品の不具合やご相談にも迅速に対応。
安心のカスタマーサポートで、
ご購入後も丁寧にサポートいたします。



730日 安心サポート!
購入後も万全の保証制度



ご使用開始後も
安心の保証制度



お問い合わせ方法

Amazonアカウント → 注文履歴 → 該当注文 → 出品者に連絡



受付時間

平日10時~19時(土日祝日および弊社指定休業日を除く)

Image: TABWEE customer support information, detailing warranty periods and contact methods.