Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GALAXHERO SYLTS037HR

GALAXHERO 6-Drawer Wooden TV Stand (Model SYLTS037HR) Instruction Manual

Introduction

Thank you for choosing the GALAXHERO 6-Drawer Wooden TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This versatile TV stand features six spacious drawers and a durable wooden construction, designed to accommodate TVs up to 65 inches. It serves as both a functional storage unit and a stylish media console, suitable for various living spaces.



Image: The GALAXHERO 6-Drawer Wooden TV Stand, showcasing its design and functionality in a home environment.

Safety Information

- **Anti-Tipping Kit:** It is crucial to install the included anti-tipping kit to prevent accidental tipping, especially in households with children or pets. Follow the instructions carefully for secure wall attachment.
- **Weight Capacity:** The top surface of the TV stand has a maximum weight capacity of 110 lbs (50 kg). Each drawer has a maximum weight capacity of 22 lbs (10 kg). Do not exceed these limits to ensure stability and prevent damage.
- **Placement:** Place the TV stand on a flat, level surface. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.
- **Assembly:** Assembly should be performed by at least two adults. Ensure all hardware is securely tightened before use.

Image: Visual guide demonstrating the proper installation of the anti-tipping kit for enhanced safety.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
Top Panel	Main top surface	1
Side Panels	Left and Right frame sides	2
Bottom Panel	Base of the unit	1
Drawer Fronts	Front panels for drawers	6
Drawer Sides/Backs	Components for drawer boxes	Various
Drawer Bottoms	Base panels for drawers	6
Back Panel	Rear support panel	1
Hardware Kit	Screws, dowels, cam locks, drawer slides, handles, anti-tipping kit	1 set

Setup and Assembly

Assembly typically requires two adults and basic tools such as a Phillips head screwdriver. Clear a spacious area for assembly and keep all hardware organized.

General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and hardware. Refer to the parts list to identify each piece.
2. **Assemble the Frame:** Begin by attaching the side panels to the bottom panel using the provided hardware (e.g., cam locks and dowels). Ensure all connections are snug.
3. **Install Drawer Slides:** Attach the drawer slides to the interior side panels of the main frame. Pay attention to the orientation (left/right) as indicated in the detailed diagrams.
4. **Construct Drawers:** Assemble each drawer by attaching the side and back panels to the drawer front. Slide the drawer bottom into the grooves, then secure the back panel. Attach the drawer handles.
5. **Insert Drawers:** Carefully align the assembled drawers with the installed drawer slides and push them into the frame until they click into place.
6. **Attach Back Panel:** Secure the back panel to the rear of the unit using small nails or screws.
7. **Install Anti-Tipping Kit:** Follow the specific instructions for the anti-tipping kit to secure the TV stand to a wall stud. This step is critical for safety.

Your browser does not support the video tag.

Video: An official assembly guide for the 6-Drawer Wood TV Stand, demonstrating key steps for construction and installation.



Image: The fully assembled GALAXHERO 6-Drawer Wooden TV Stand, ready for use.

Operating Instructions

Drawer Usage:

- **Opening/Closing:** Gently pull the bar handles to open the drawers. Push them back in until they are fully closed. The metal sliding rails ensure smooth operation.
- **Weight Distribution:** Distribute items evenly within the drawers to maintain balance and prevent strain on the drawer slides. Do not overload drawers beyond the 22 lbs capacity.

Top Surface Usage:

- **TV Placement:** Place your television centrally on the top surface. Ensure the TV base fits within the dimensions of the stand. The maximum weight for the top surface is 110 lbs.
- **Cable Management:** Utilize the space behind the stand for organizing cables to maintain a tidy appearance and prevent tripping hazards.



Image: An illustration of the spacious storage provided by the six drawers, suitable for various household items.




Image: Detailed view of the product's features, including elegant metal handles, smooth metal sliding rails, sturdy wood legs, and the anti-tip kit.

Maintenance

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes

that may damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or water damage to the wood.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Avoid Overloading:** Adhere to the specified weight limits for the top surface and drawers to prevent structural stress and damage.

Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose hardware.	Check that drawer slides are correctly installed and all screws are tightened. Ensure drawers are not overloaded.
Stand feels wobbly or unstable.	Loose connections or uneven placement.	Verify all assembly hardware is securely tightened. Ensure the stand is on a flat, level surface. Confirm the anti-tipping kit is properly installed.
Scratches or marks on the surface.	Sharp objects or abrasive cleaning.	Use coasters or protective pads under items. Clean with a soft cloth and avoid harsh chemicals.

Specifications

Feature	Detail
Brand	GALAXHERO
Model Number	SYLTS037HR
Color	Black
Number of Drawers	6
Item Dimensions (L x W x H)	53.98 x 15.75 x 32.09 inches
Item Weight	87.4 pounds
Material Type	Premium Wood
Style	Modern
Top Surface Weight Capacity	110 lbs (50 kg)
Drawer Weight Capacity (each)	22 lbs (10 kg)



Image: A visual representation of the product's dimensions, including overall size and individual drawer measurements.

Warranty and Support

For any questions regarding assembly, missing parts, or product issues, please contact GALAXHERO customer support. Refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H2MFDWG3

More documents and user manuals: **https://manuals.plus/**