

- Manuals.plus /
- > ULANZI /
- > ULANZI MT44M 2-in-1 Magnetic Phone & Camera Tripod User Manual

ULANZI MT44M

ULANZI MT44M 2-in-1 Magnetic Phone & Camera Tripod User Manual

Model: MT44M

INTRODUCTION

The ULANZI MT44M is a versatile 2-in-1 magnetic phone and camera tripod designed for content creators. It features a MagSafe-compatible magnetic mount, a 1/4" screw thread for cameras, a cold shoe port, a one-touch auto-deploy tripod mechanism, a 7-section telescopic pole, and a detachable Bluetooth remote. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.

SETUP

1. Auto-Deploying the Tripod

To deploy the tripod legs, simply tap the base of the unit on a flat surface. The four legs will automatically extend and lock into a stable quadpod configuration. This allows for quick setup in under 3 seconds.

Instant-Deploy Tripod

The tripod deploys on contact, so you're ready to shoot in seconds



Stable 4-Leg Support



Anti-Slip Silicone Pads



Image: The ULANZI MT44M tripod in its auto-deploying state, showing the four legs extending from the base with a red 'PUSH' button. This illustrates the quick setup feature.

2. Attaching Your Device

The MT44M offers multiple attachment options:

- **Magnetic Mount:** For MagSafe-compatible iPhones, simply snap your phone directly onto the magnetic head.
- **1/4" Screw Thread:** For mirrorless cameras, action cameras, or other devices, use the universal 1/4" screw thread.
- **Cold Shoe Port:** A built-in cold shoe port allows for quick attachment of accessories like fill lights or microphones.

Dual-Device Setup

Flexible mounting for your phone, camera, light, or mic



Image: A diagram illustrating the magnetic phone mount, the 1/4" screw mount for cameras, and the cold shoe mount for additional accessories on the ULANZI MT44M.

3. Using the Magnetic Adapter Ring (for non-MagSafe devices)

If your phone is not MagSafe-compatible, you can use the included magnetic adapter ring:

1. Ensure the back of your phone or phone case is clean, smooth, and dry.
2. Carefully align the magnetic adapter ring to the center of your device.
3. Firmly press the magnetic adapter ring for 20-30 seconds to ensure a secure bond. Allow 24 hours for the adhesive to fully cure before use.

Magnetic Adapter Ring Instructions

Apply to a clean, smooth, and flat surface only.

01



Firmly press the magnetic adapter ring and allow 24 hours for a secure bond.

02



*Align your device with the center of the mounted adapter ring.

Image: A visual guide demonstrating how to apply the magnetic adapter ring to a smartphone for MagSafe compatibility.

4. Pairing the Detachable Bluetooth Remote

The MT44M includes a detachable Bluetooth remote for hands-free operation:

- Remove the remote from its storage slot in the handle.
- Turn on the remote to enter pairing mode.
- On your smartphone, go to Bluetooth settings and connect to "Ulanzi MT-44 M".

Flexible Angles

Adjust easily for the perfect shooting angle

Horizontal



Vertical




Image: The ULANZI MT44M tripod with its detachable wireless remote, illustrating its use for remote control of a mounted phone.

OPERATING INSTRUCTIONS

1. Extending the Telescopic Pole

The 7-section telescopic pole can be extended to various heights, from a compact desktop stand to a full-height tripod of 59 inches (1.49 meters). Simply pull the pole upwards to extend and push downwards to retract. Ensure all sections are securely locked at your desired height.

Extends Up to 58.66 in / 1.49 m

Adjust the height easily with the 7-section telescopic pole



Image: A person using the ULANZI MT44M tripod fully extended to 58.66 inches (1.49 meters) for photography.

2. Adjusting the Ball Head

The smooth ball head allows for flexible positioning of your device:

- **360° Rotation:** Loosen the ball head adjustment knob to rotate your device horizontally for panoramic shots or to change viewing angles.
- **90° Vertical Tilt:** The ball head also supports a 90° vertical tilt, enabling you to shoot in portrait mode, capture overhead shots, or achieve low-angle perspectives.

Detachable Wireless Remote

33ft



Image: A detailed view of the ULANZI MT44M's ball head, highlighting its 360° rotation and 90° vertical tilt functionality with directional arrows.

3. Using the Wireless Remote

Once paired, the detachable Bluetooth remote can be used to:

- Capture photos.
- Start and stop video recording.
- Take group shots from up to 33 feet (10 meters) away.

4. Multi-Scenario Use

The MT44M is suitable for various content creation scenarios:

- **Group Shots:** Extend the pole and use the remote for wide-angle group photos.
- **Selfie Vlogging:** Mount your phone and an action camera simultaneously for dynamic vlogging.
- **Live Streaming/Monitoring:** Use the tripod as a stable stand for live broadcasts or for monitoring your shots.

Ready for Multiple Scenarios



Image: A collage showing the ULANZI MT44M being used for group shots, selfie vlogging with a phone and action camera, and live streaming with a camera.

MAINTENANCE

To ensure the longevity and optimal performance of your ULANZI MT44M tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe the tripod with a soft, dry cloth after each use to remove dust and debris. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully retracted and the legs are folded for compact storage.
- **Magnetic Mount:** Keep the magnetic surface clean and free of metallic particles that could interfere with its hold.
- **Remote Battery:** If the remote control's response becomes sluggish, replace the CR1632 coin cell battery.

TROUBLESHOOTING

- **Tripod legs do not auto-deploy:** Ensure the base is tapped firmly on a flat surface. Check for any obstructions in the leg mechanism.
- **Magnetic mount not holding securely:** Ensure your phone or case is MagSafe-compatible. If using the adapter ring, verify it is properly adhered and cured for 24 hours. Clean both the magnetic surface of the tripod and your device.
- **Bluetooth remote not connecting:** Ensure the remote is turned on and in pairing mode. Check your phone's Bluetooth settings to ensure it's searching for devices and that "Ulanzi MT-44 M" is selected. If issues persist, replace the remote's CR1632 battery.
- **Telescopic pole is stiff or stuck:** Gently twist and pull the sections. Avoid forcing the pole. Ensure no dirt or debris is lodged between sections.
- **Device stability issues:** Ensure the tripod legs are fully deployed and locked. Verify that the ball head adjustment knob is tightened after positioning your device. Do not exceed the maximum load capacity of 2.64 lbs (1.2 kg).

SPECIFICATIONS

Feature	Detail
Brand	ULANZI
Model	MT44M
Materials	Plastic, Aluminum Alloy, Magnets
Folded Size	2.36 × 2.36 × 13.19 inches (6 × 6 × 33.5 cm)
Extended Height	59 inches (149 cm)
Net Weight	Approx. 14.82 oz (420 g)
Load Capacity	Max. 2.65 lbs (1.2 kg)
Compatible Systems (Remote)	iOS, Android, HarmonyOS
Wireless Control Range	33 ft (10 m)
Remote Battery Type	CR1632 Coin Cell Battery
Included Components	Magnetic Selfie Stick ×1, Magnetic Adapter Ring ×1, User Manual ×1

Specifications

Brand:	Ulanzi
Model:	MT-44 M
Materials:	Plastic, Aluminum Alloy, Magnets
Folded Size:	6 × 6 × 33.5 cm / 2.36 × 2.36 × 13.19 in
Extended Height:	149 cm / 58.66 in
Net Weight:	Approx. 420 g / 14.82 oz
Gross Weight:	Approx. 490 g / 17.28 oz
Load Capacity:	1.2 kg / 2.65 lb

Wireless Remote	
Device Name:	Ulanzi MT-44 M
Compatible Systems:	iOS, Android, HarmonyOS
Wireless Control Range:	10 m / 33 ft
Battery Type:	CR1632 Coin Cell Battery
Battery Life:	Over 12,000 presses



*The above specifications are based on Ulanzi laboratory testing, provided for reference only. Product specifications are subject to change without prior notice.

Image: A graphic displaying the detailed specifications of the ULANZI MT44M tripod, including physical dimensions and remote control features.

WARRANTY

The ULANZI MT44M tripod comes with a **1-year warranty** from the date of purchase. Please retain your proof of purchase for any warranty claims. This warranty covers manufacturing defects and does not cover damage caused by misuse, accidents, or unauthorized modifications.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact ULANZI customer service through their official website or the retailer where the product was purchased. Refer to the packaging or ULANZI's official channels for the most up-to-date contact information.

© 2026 ULANZI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0H2MP54QL>

More documents and user manuals: <https://manuals.plus/>