

SHA CERLIN XH-9954-2

SHA CERLIN LED Queen Bed Frame with 51.2" Tall Headboard - User Manual

Model: XH-9954-2

INTRODUCTION

Thank you for purchasing the SHA CERLIN LED Queen Bed Frame. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new bed frame. Please read this manual thoroughly before beginning assembly and retain it for future reference.

SAFETY INFORMATION

- Keep all small parts away from children during assembly.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 900 pounds.
- Use only the provided parts and tools for assembly. Do not substitute parts.
- Assemble the bed frame on a soft, clean surface to prevent damage to the product or your floor.
- Unplug the bed frame from the power outlet before cleaning or performing any maintenance on the LED lights or charging station.

PARTS LIST


Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Headboard (with integrated LED strip light, 2-tier storage shelf, and charging station)
- Side Rails (Left and Right)
- Footboard
- Center Support Beam
- Support Legs
- Wood Slats (12 pieces)
- Hardware Pack (bolts, washers, nuts, Allen wrench)
- LED Remote Control
- Power Adapter for LED and Charging Station

SETUP (ASSEMBLY INSTRUCTIONS)

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Compare them with the parts list to ensure everything is present.
2. **Attach Side Rails to Headboard:** Connect the left and right side rails to the headboard using the provided bolts and Allen wrench. Ensure the connections are firm.
3. **Attach Footboard:** Connect the footboard to the side rails. Tighten all bolts securely.
4. **Install Center Support Beam and Legs:** Attach the center support beam to the designated points on the headboard and footboard. Install the support legs along the center beam and under the side rails for added stability.
5. **Place Wood Slats:** Lay the 12 wood slats across the bed frame. The slats are designed with Velcro connections for easy and secure installation. Ensure each slat is properly aligned and secured to the frame. The EVA mute foam on the slats helps reduce noise.
6. **Connect Power:** Locate the power cable for the LED lights and charging station. Connect it to the power adapter and then plug the adapter into a standard wall outlet.



Easy Assembly

Designed with Velcro connections, the slats can be installed simply and securely.

Image: Easy assembly slats with Velcro connections.

EVA Mute Foam

Effectively reduce rubbing and creaking for a silent, stable rest environment



Image: Noise-free foam on slats for a silent rest environment.



Sturdy Structure

The framework provides stable, shake-free support for a safe and comfortable sleeping experience.

Image: Sturdy structure of the bed frame with metal and wood components.

OPERATING INSTRUCTIONS

RGB LED Lighting

The integrated RGB LED strip lights can be controlled via the included remote control or a smartphone application.

- **Remote Control:** Use the remote to power the lights on/off, change colors (60,000+ options), adjust brightness, select dynamic modes (fade, flash, strobe), and activate music sync.
- **Smartphone App:** Download the designated app (refer to packaging or included instructions for app name/QR code). Pair your device with the bed frame's LED system via Bluetooth. The app offers advanced control, including custom color creation, timer functions, and more precise music synchronization.



Customizable Lights for
Ambiance and Mood

Smart RGB LED Bed Frame



Smart Timer



Music Mode



DIY Color
Control Mode



Mic Mode



Creative
Scenery Mode



APP/Remote Control

Image: Smart RGB LED Bed Frame features including remote and app control.

Built-in Charging Station

The headboard features a convenient 4-in-1 charging station.

- **AC Outlets:** Two 125V/12A AC outlets are available for powering larger devices like laptops or lamps.
- **USB Port:** One 5V/3A USB port is provided for charging smartphones, tablets, and other USB-powered devices.
- **Type-C Port:** One 5V/3A Type-C port offers fast charging for compatible devices.

Simply plug your devices into the appropriate ports. Ensure the bed frame is connected to a power source for the charging station to function.

2-TIER STORAGE SHELF WITH CHARGING STATION



2 AC Outlets
125V/12A



1 USB port
5V/3A



1 Type-C Port
5V/3A

Image: 2-Tier Storage Shelf with integrated charging station.

MAINTENANCE

Regular maintenance helps prolong the life and appearance of your bed frame.

- **Cleaning the Velvet Headboard:** Gently vacuum the velvet fabric with a brush attachment to remove dust and debris. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner specifically designed for velvet, testing on an inconspicuous area first. Do not rub vigorously.
- **Cleaning Metal and Wood Parts:** Wipe down metal and wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Checking Connections:** Periodically (every 3-6 months) inspect all bolts and screws. Re-tighten any loose connections to maintain stability and prevent squeaking.

- **LED Lights and Charging Station:** Keep the LED strip and charging ports free of dust. Do not attempt to disassemble or repair the electrical components yourself.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed frame is wobbly or squeaks.	Loose bolts or connections.	Check and re-tighten all bolts and screws. Ensure all support legs are firmly on the ground.
LED lights are not turning on.	Power adapter unplugged; remote battery dead; loose connection to LED strip.	Ensure the power adapter is securely plugged into the wall and the bed frame. Replace remote control batteries. Check the connection of the LED strip to the control box.
Charging station is not working.	Bed frame not powered; device cable faulty; charging station malfunction.	Verify the bed frame's power adapter is plugged in. Try a different charging cable or device. If the issue persists, contact customer support.
LED remote control is unresponsive.	Battery depleted; remote not paired; obstruction.	Replace the battery in the remote control. Ensure there are no obstructions between the remote and the LED receiver. If applicable, re-pair the remote according to the LED instructions.

If these solutions do not resolve the issue, please contact SHA CERLIN customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	XH-9954-2
Size	Queen
Product Dimensions (L x W x H)	86.2" x 63.6" x 51.2"
Headboard Height	51.2"
Material	Velvet, Metal, Wood
Weight Capacity	900 lbs
Box Spring Required	No

Feature	Detail
LED Lighting	RGB, App/Remote Control, Music Sync
Charging Station	2 AC Outlets (125V/12A), 1 USB Port (5V/3A), 1 Type-C Port (5V/3A)
Storage	2-Tier Headboard Shelf, Side Pockets
UPC	099641743056

PRODUCT INFORMATION



Material

Velvet, Wood,
Metal

Dimensions

L x W x H
86.2" x 63.6" x 51.2"

Weight Capacity

900 lb

Image: Product dimensions and specifications overview.

WARRANTY AND SUPPORT

SHA CERLIN products are designed for quality and durability. For specific warranty information, please refer to the warranty card included with your purchase or visit the official SHA CERLIN website. If you require assistance with assembly, missing parts, or troubleshooting that is not covered in this manual, please contact SHA CERLIN customer support.

Customer Support Contact: Please refer to your purchase documentation or the SHA CERLIN brand website for the most current contact information.

© 2023 SHA CERLIN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question