

[Manuals.plus](#) /

› [AIPER](#) /

› AIPER Seagull Pro ZT6002 Cordless Robotic Pool Cleaner Instruction Manual

AIPER ZT6002

AIPER Seagull Pro ZT6002 Cordless Robotic Pool Cleaner Instruction Manual

Model: ZT6002

1. INTRODUCTION

Thank you for choosing the AIPER Seagull Pro ZT6002 Cordless Robotic Pool Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.




Image: The AIPER Seagull Pro ZT6002 robotic pool cleaner positioned at the edge of a swimming pool.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of injury or damage, observe the following safety precautions:

- Read the user manual carefully before operating the device.

- Do not run the device out of water.
- Do not turn on the device while charging.
- Charge the device indoors in a dry, well-ventilated area.
- Only use the provided power adapter for charging.
- Ensure the charging port is dry before connecting the charger.
- Keep children and pets away from the pool cleaner during operation.
- Do not operate the cleaner if the power cord or plug is damaged.
- For use in swimming pools only.

3. PRODUCT OVERVIEW

The AIPER Seagull Pro ZT6002 is a cordless robotic pool cleaner designed for efficient cleaning of inground pools up to 1,600 sq.ft. It features advanced navigation, powerful scrubbing, and multiple cleaning modes.

Key Features:

- **WavePath Navigation:** Intelligent four-motor system for thorough cleaning of pool floors, walls, and waterlines.
- **Wall-Climbing Capability:** Four-wheel-drive system enables effective scrubbing of walls and waterlines.
- **Quad-Motor Performance:** Four motors provide up to 196W of power, filtering up to 80 gallons of water per minute.
- **Extended Battery Life:** 7,800mAh battery offers up to 150 minutes of continuous cleaning.
- **Fast Charging:** Fully recharges in 3–4 hours.
- **Multiple Cleaning Modes:** Includes Floor, Wall, and Auto modes.



Image: Internal view of the AIPER Seagull Pro ZT6002, highlighting the quad-motor system and water filtration process.

4. SETUP

4.1 Initial Charging

1. Ensure the pool cleaner is dry before charging.
2. Connect the charging adapter to the cleaner's charging port.
3. Plug the adapter into a power outlet indoors.

4. Allow 3-4 hours for a full charge. The battery indicator will show charging status.




Image: The AIPER Seagull Pro ZT6002 connected to its charger indoors, illustrating the charging process and time.

5. OPERATING INSTRUCTIONS

5.1 Deployment

1. Once fully charged, ensure the cleaner is turned off.
2. Gently lower the cleaner into the pool. It will sink to the bottom.
3. Ensure there are no obstructions in the pool that could impede its movement.

5.2 Selecting Cleaning Mode

The Seagull Pro ZT6002 offers three cleaning modes:

- **Automatic Mode:** Cleans both the pool floor and walls/waterline.
- **Floor Only Mode:** Focuses cleaning on the pool floor.
- **Wall Only Mode:** Focuses cleaning on the pool walls and waterline.

Use the intuitive control dial on top of the unit to select your desired cleaning mode. The dial also features a 4-color battery indicator to monitor real-time battery status.




Image: The control dial of the AIPER Seagull Pro ZT6002, illustrating the three cleaning modes.




Image: The intuitive control dial with a 4-color battery indicator for real-time monitoring of battery status.

5.3 WavePath Navigation

The WavePath Navigation system ensures comprehensive cleaning. In Auto Mode, the cleaner performs an 'S' pattern for the pool floor when the battery is over 50%, and an 'N' pattern for walls and waterline when the battery is below 50%.



Image: Visual representation of the WavePath Navigation system, demonstrating cleaning patterns for the pool floor and walls.

The package arrived WET? REPACKAGED?

It's **NOT USED** item.

Alle machines undergo **100% water testing** and **re-sampling inspection** before shipping to ensure proper functionality, which inevitably leads to the above conditions.



Image: Explanation of the AUTO mode operation, detailing cleaning behavior based on battery level.

5.4 Retrieval

After the cleaning cycle is complete or the battery is low, the cleaner will typically park itself near a wall. Use the included retrieval hook to safely lift the cleaner out of the water. The quick-water release feature allows for easy portability.




Image: Demonstrating the easy retrieval of the AIPER Seagull Pro ZT6002 from the pool and its quick water release for handling.

6. MAINTENANCE

6.1 Cleaning the Filter Basket

Regular cleaning of the filter basket is crucial for optimal performance. The Seagull Pro ZT6002 features an easy-access top-load filter basket.

1. Remove the cleaner from the pool.
2. Open the top cover to access the filter basket.
3. Remove the basket and pour out any collected debris.
4. Rinse the filter basket thoroughly with water to remove fine particles.
5. Reinsert the clean filter basket and close the top cover securely.




Image: Steps for accessing and cleaning the debris filter basket of the AIPER Seagull Pro ZT6002.



Image: Features of the upgraded filter basket, performance in sloped pools, and drain cleaning capability.

6.2 Storage

When not in use for extended periods, store the cleaner in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before storage to prolong its lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cleaner does not turn on.	Low battery or not charged.	Charge the cleaner fully (3-4 hours).
Cleaner moves slowly or stops.	Filter basket is full or clogged.	Clean the filter basket.
Cleaner does not climb walls effectively.	Low battery or dirty brushes/wheels.	Ensure battery is sufficiently charged. Clean brushes and wheels.
Poor cleaning performance.	Filter basket is dirty or debris is too large.	Clean the filter basket. Remove large debris manually before operation.

Problem	Possible Cause	Solution
Cleaner gets stuck.	Obstruction in the pool or uneven surface.	Remove obstructions. The cleaner is designed to handle most pool surfaces.

8. SPECIFICATIONS

Feature	Detail
Brand	AIPER
Model Name	Seagull Pro 0529
Model Number	ZT6002-G
Product Dimensions	16"L x 10"W x 16"H
Power Source	Battery Powered
Battery Type	Lithium-Ion
Battery Capacity	7,800mAh (196.56 Watt Hours)
Runtime	Up to 150 minutes
Charging Time	3-4 Hours
Filtration Capacity	Up to 80 gallons per minute
Motor Power	Up to 196W (Quad-Motor)
Pool Size Compatibility	Up to 1,600 sq.ft (Inground Pools)
Special Features	Cordless, Rechargeable, WavePath Navigation, Wall-Climbing

9. WARRANTY AND SUPPORT

The AIPER Seagull Pro ZT6002 robotic pool cleaner comes with a two-year product protection. For warranty claims, technical support, or any inquiries, please contact AIPER customer service through their official website or the retailer where the product was purchased. Please have your model number (ZT6002) and proof of purchase ready when contacting support.