Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AUVEBY LT-147

AUVEBY LT-147 Portable Cordless Car Vacuum User Manual

Model: LT-147

Introduction

Thank you for choosing the AUVEBY LT-147 Portable Cordless Car Vacuum. This versatile 4-in-1 device is designed for efficient cleaning, blowing, inflating, and pumping, offering high power and convenience for your car, home, and office. With its 20,000Pa strong suction, 45-minute runtime, and easy-empty dust cup, maintaining a clean environment has never been easier. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: The AUVEBY LT-147 vacuum in use, demonstrating its long runtime and large dust cup capacity for comprehensive cleaning.

What's Included

Your AUVEBY LT-147 Portable Cordless Car Vacuum package includes the following components:

- Vacuum Cleaner Unit
- Floor Brush

- Inflation Nozzle
- Blowing Nozzle
- Suction Nozzle (Crevice Nozzle)
- Brush Nozzle
- Small Brush
- Air Suction Nozzle
- USB-C Charging Cable
- Extension Hose
- 2 Washable HEPA Filters (one pre-installed, one spare)
- Steel Filter (pre-installed)
- Storage Bag



Image: A visual representation of all components included in the AUVEBY LT-147 package.

Setup

Charging the Vacuum

1. Connect the provided USB-C charging cable to the charging port on the vacuum cleaner.
2. Plug the other end of the USB-C cable into a compatible USB-A power adapter (not included) or a USB-A port.
3. The battery indicator on the vacuum will show charging status. A full charge takes approximately 3.5 hours.
4. Ensure the vacuum is fully charged before first use to maximize battery life and performance.

Assembling Attachments

To attach any nozzle or hose, align it with the vacuum's suction or blowing port and push firmly until it clicks into place. To remove, pull the attachment away from the port.

Operation

Power On/Off and Suction Modes

- Press the power button once to turn on the vacuum at the lowest suction mode (Eco Mode).
- Press the power button again to cycle through the three available suction modes (Low, Medium, High).

- Press the power button a fourth time to turn off the vacuum.
- The digital display will indicate the current suction mode and battery level.

Vacuuming Function

Attach the desired nozzle (crevice, brush, or floor brush) to the suction port. Use the crevice nozzle for tight spaces, the brush nozzle for upholstery and stubborn debris, and the floor brush for larger flat surfaces like car mats. The 336ml dust cup allows for extended cleaning sessions without frequent emptying.



Image: Demonstrating the vacuum's effectiveness in cleaning different parts of a car interior.

Blowing Function

Attach the blowing nozzle to the exhaust port of the vacuum. This function is ideal for dusting dashboards, keyboards, or blowing light debris from hard-to-reach areas.

Inflating Function

Use the inflation nozzle with the exhaust port to inflate small items like swim rings or air cushions. Ensure the nozzle fits securely to prevent air leakage.

Pumping Function (Vacuum-Sealing)

The vacuum can also be used to remove air from vacuum-sealable storage bags. Attach the appropriate nozzle to the suction port and apply it to the bag's valve.




Image: Illustrating the multi-functional capabilities of the AUVEBY vacuum for various cleaning and air-moving tasks.

Care and Maintenance

Emptying the Dust Cup

1. Ensure the vacuum is turned off.
2. Press the one-touch release button to detach the dust cup from the main unit.
3. Empty the contents of the dust cup into a waste bin.
4. Reattach the dust cup to the vacuum until it clicks securely into place.

Cleaning the Filters

Regular cleaning of the filters is crucial for maintaining optimal suction power and extending the life of your vacuum.

1. After emptying the dust cup, twist and detach the filter assembly (HEPA filter and steel filter).
2. Rinse both the HEPA filter and the steel filter under running water until clean. Do not use harsh detergents.
3. Allow both filters to air-dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters.
4. Once dry, reassemble the filters and attach them back into the dust cup, then reattach the dust cup to the vacuum unit.



Image: Step-by-step instructions for cleaning the vacuum's dust cup and filters.

Troubleshooting

If you encounter any issues with your AUVEBY LT-147 vacuum, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Low Suction Power	Dust cup is full; Filters are clogged; Nozzle/hose is blocked; Battery is low.	Empty the dust cup. Clean or replace filters. Check and clear any blockages in the nozzle or hose. Recharge the battery.

Problem	Possible Cause	Solution
Vacuum Not Turning On	Battery is depleted; Power button not pressed correctly; Unit malfunction.	Charge the vacuum fully. Ensure the power button is pressed firmly. If the issue persists after charging, contact customer support.
Battery Not Charging	Charging cable is not connected properly; USB power adapter is faulty; Charging port is damaged.	Ensure the USB-C cable is securely connected to both the vacuum and the power adapter. Try a different USB power adapter or charging cable. If the problem continues, contact customer support.

Product Specifications

Feature	Specification
Brand	AUVEBY
Model Name	Vacuum cleaner (LT-147)
Special Feature	Easy Clean, Large Capacity, 4-in-1 (Vacuum, Blow, Inflate, Pump)
Filter Type	HEPA Filter (Washable)
Power Source	Battery Powered
Capacity	336 cubic centimeters (0.09 Gallons)
Suction Power	Up to 20,000Pa
Motor Speed	147,000 RPM (Brushless)
Output Power	100W
Number of Speeds/Power Levels	3
Voltage	10.8 volts DC
Runtime	Up to 45 minutes (Eco Mode)
Charging Time	Approx. 3.5 hours (USB-C)
Form Factor	Handheld
Item Weight	1.08 lbs (490g)
Item Dimensions (L x W x H)	8.15"L x 2.76"W x 7.95"H
Recommended Uses	Car, Home, Office, Outdoor (Inflating)

Warranty and Customer Support

AUVEBY products are manufactured with quality and performance in mind. For specific warranty details regarding your

LT-147 Portable Cordless Car Vacuum, please refer to the warranty information provided at the time of purchase or contact the retailer.

Should you have any questions, require technical assistance, or need to report an issue that cannot be resolved using the troubleshooting guide, please contact AUVEBY customer support through the retailer's platform or the official AUVEBY website. Please have your product model number (LT-147) and purchase information ready when contacting support.

© 2026 AUVEBY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H3NH72NC

More documents and user manuals: **https://manuals.plus/**