

SEEGER SLFRZ5BK

Seeger MultiCream Ice Cream Maker User Manual

Model: SLFRZ5BK

1. INTRODUCTION

The Seeger MultiCream Ice Cream Maker allows you to create a wide variety of homemade frozen desserts. From creamy vanilla ice cream to refreshing sorbets, protein ice cream, frozen yogurt, milkshakes, slushies, and smoothie bowls, this intelligent 10-in-1 machine brings your favorite frozen treats directly to your kitchen.

You choose your own ingredients, fill the EasyCup, freeze it for 24 hours, and let the MultiCream do the rest. Thanks to its powerful SmartSpin Technology, the machine transforms frozen ingredients into a creamy, smooth, and well-blended frozen preparation, tailored to your taste, diet, and occasion.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Seeger MultiCream Ice Cream Maker. Keep this manual for future reference.

- Always ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the main unit in water or any other liquid.
- Keep hands and utensils out of the EasyCup during operation to prevent injury and damage to the machine.
- Do not operate the appliance with a damaged cord or plug.
- Ensure the EasyCup is properly seated and the lid is securely closed before starting the machine.
- This appliance is for household use only.

3. WHAT'S IN THE BOX

Your Seeger MultiCream Ice Cream Maker package includes the following components:

- Seeger MultiCream Ice Cream Maker (Main Unit)
- 3 x EasyCup Containers (500 ml each)
- 3 x Lids for EasyCups
- Lid with Blade Unit / Mixing Accessory
- User Manual



Image: Three 500ml BPA-free EasyCups with lids, filled with different frozen desserts, displayed on a wooden table.

4. SETUP AND FIRST USE

Preparing your frozen treats with the MultiCream is straightforward. Follow these simple steps:

1. **Prepare Your Mixture:** Mix your desired ingredients for your frozen dessert. Ensure the mixture is liquid or semi-liquid.
2. **Fill the EasyCup:** Pour your mixture into an EasyCup. Do not exceed the 'MAX FILL' line.
3. **Freeze:** Place the filled EasyCup in your freezer for at least 24 hours at -18°C (0°F) or colder. The mixture must be

completely frozen solid.

4. **Assemble:** Once frozen, remove the EasyCup from the freezer. Place the frozen cup into the MultiCream machine base. Attach the lid with the blade unit, ensuring it clicks securely into place.
5. **Select Program:** Plug in the machine. Use the digital touchscreen to select your desired program.
6. **Process and Enjoy:** Press the START/STOP button. The MultiCream will process your frozen base into a creamy treat. Serve and enjoy!



Image: Seeger MultiCream 4-step process: Prepare ingredients, freeze for 24 hours, Smart Spin processing, and enjoy the finished frozen treat.

5. OPERATING INSTRUCTIONS

5.1. 10 Automatic Programs

The Seeger MultiCream offers 10 automatic programs to cater to all your frozen dessert preferences:

- **Ice Cream:** For classic ice cream flavors like vanilla, chocolate, strawberry, or cookie ice cream.
- **Light Ice Cream:** For lighter recipes, e.g., with less sugar or dairy-free options.
- **Gelato:** For soft, rich gelato with a creamy texture.
- **Sorbet:** For fruity and refreshing sorbets like strawberry, mango, peach, or pineapple.
- **Frappe:** For iced coffee drinks and creamy coffee creations.
- **Slush:** For refreshing slush drinks with soda, iced tea, sports drinks, or fruit juice.
- **Milkshake:** For thick or thinner milkshakes with milk, ice cream, or plant-based alternatives.
- **Frozen Yogurt:** For fresh yogurt desserts with fruits, honey, chocolate, or other toppings.
- **Smoothie Bowl:** For thick frozen bowls, ideal for breakfast, snacks, or lunch.
- **Frozen Drink:** For fresh drinks, fruity beverages, and frozen cocktails.



Image: Visual representation of the 10-in-1 programs offered by the Seeger MultiCream.

5.2. SmartSpin Technology

The SmartSpin Technology powerfully and uniformly processes frozen ingredients. The machine's blade moves through the frozen base, transforming it into a creamy ice cream texture.

A practical advantage is the ability to choose which part of the EasyCup you want to process. With **TOP**, **BOTTOM**, and **FULL** selections, you decide whether to process the upper half, lower half, or the entire cup. This allows for portion control and flexibility.



Image: Illustration of the SmartSpin Technology, highlighting the blade mechanism inside the EasyCup during the mixing process.

5.3. Mix-in Function

To add toppings like chocolate chips, nuts, cookies, fruits, or candies to your frozen dessert, use the **Mix-in** function. This ensures that the toppings are evenly distributed throughout the ice cream, enhancing texture and flavor in every bite.

Fonction Mix-in

AJOUTEZ DES GARNITURES SUPPLÉMENTAIRES



Image: Close-up of the Mix-in function in action, showing crushed cookies being added to ice cream in an EasyCup.

5.4. Re-spin Function

If your frozen dessert is too firm or crumbly after initial processing, use the **Re-spin** function. Add a small amount of liquid (milk, water, juice, or another liquid from your recipe), then allow the machine to re-process the dessert for a softer, creamier texture.

5.5. Easy-to-Use Touchscreen

The digital touchscreen makes operation clear and enjoyable. Simply select your program, start the machine, and monitor progress via the live progress bar on the screen. The display clearly indicates when your dessert is ready. The controls are logical and easy to understand, allowing quick navigation between different programs, even for first-time users.



Image: Detailed view of the Seeger MultiCream's easy-to-use digital touchscreen control panel.

6. MAINTENANCE AND CLEANING

After enjoying your frozen treat, cleaning the MultiCream is simple and quick:

- **Clean Function:** The Seeger MultiCream is equipped with a convenient **Clean** function. This allows for easy cleaning of the cup, blade, and other parts with water.
- **Dishwasher Safe:** The EasyCups and their lids are dishwasher safe, making daily cleaning practical, especially when preparing multiple flavors consecutively.
- **Wipe Down Main Unit:** Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

7. TROUBLESHOOTING

If you encounter any issues with your Seeger MultiCream, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue; machine not assembled correctly.	Ensure power cord is securely plugged into a working outlet. Check if the EasyCup and lid are correctly installed and locked.
Frozen dessert is too crumbly/icy.	Base not frozen solid enough; recipe too low in fat/sugar; insufficient liquid.	Ensure EasyCup is frozen for a full 24 hours at -18°C (0°F). Use the Re-spin function with a small amount of liquid (milk, water, juice). Adjust recipe for more fat/sugar if desired.
Machine stops during operation.	Overload; EasyCup not properly seated.	Unplug, check for obstructions, and ensure EasyCup and lid are correctly installed. Allow machine to cool if it overheated.
Toppings not mixing evenly.	Mix-in function not used or toppings added too late.	Ensure to use the Mix-in function after the initial processing cycle. Add toppings at the appropriate stage as per recipe or instructions.

If the problem persists, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	SEEGER
Model Number	SLFRZ5BK
Color	Black
Capacity	1.5 liters (total for 3 EasyCups)
Special Feature	Touchpad Control
Product Dimensions (L x W x H)	30.3L x 16.7W x 39.5H centimeters
Item Weight	5.3 Kilograms
Operation Mode	Automatic
Included Components	3 x 500 ml EasyCup containers, 3 x EasyCup lids, Lid with blade unit / mixing accessory, User Manual

9. WARRANTY AND SUPPORT

The Seeger MultiCream Ice Cream Maker comes with a standard manufacturer's warranty. Please refer to the warranty

card included in your packaging for specific terms and conditions, including warranty duration and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact Seeger customer service. Contact information can typically be found on the product packaging, the official Seeger website, or the warranty card.

When contacting support, please have your product model number (SLFRZ5BK) and proof of purchase readily available.

© 2023 SEEGER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question