

[Manuals.plus](#) /

› [JBL](#) /

› JBL EasySing Mic Mini Duo Wireless Microphone Instruction Manual


JBL JBLESMICMINIDUO

JBL EasySing Mic Mini Duo Wireless Microphone User Manual

Model: JBLESMICMINIDUO

INTRODUCTION

The JBL EasySing Mic Mini Duo is a compact, versatile wireless microphone set designed for various audio applications, including karaoke, gaming, streaming, and video conferencing. It features AI vocal removal, seamless connectivity options, and intuitive controls, making it an ideal companion for enhancing your audio experience.



JBL

米国カリフォルニア発祥の
世界最大級のオーディオブランド

全世界にて
ヘッドホン・イヤホンの累計出荷台数が

2億台を突破

(2022年末時点)

Image: A user enjoying the JBL EasySing Mic Mini Duo, demonstrating its ease of use.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- 2 x Small Wireless Microphones
- 1 x USB-C Dongle
- 1 x Charging Case
- 2 x Magnetic Clips
- 2 x Magnetic Handles





Image: All included accessories for the JBL EasySing Mic Mini Duo.

SETUP

1. Initial Charging

Before first use, fully charge the microphones and the charging case. Place the microphones into the charging case. Connect the charging case to a power source using a USB-C cable (not included).



Image: The charging case for the JBL EasySing Mic Mini Duo.

2. Connecting to a Device

The JBL EasySing Mic Mini Duo offers multiple connection methods:

- **Bluetooth:** For compatible JBL Bluetooth speakers (e.g., BOOMBOX 4, XTREME5, CHARGE 6, FLIP 7, GRIP, GO5, PartyBox series). Ensure your speaker is in pairing mode, then power on the microphone. The microphone will automatically attempt to connect.

- **USB-C Dongle:** Insert the USB-C dongle into a compatible device (smartphone, tablet, laptop, or speaker with a USB-C port). Power on the microphone, and it will connect to the dongle.
- **AUX Connection:** For devices with an AUX input, connect the USB-C dongle to the device using an appropriate AUX cable (not included).



JBL

JBLスピーカーとシームレス接続

対応するJBL BluetoothスピーカーやPartyBoxシリーズとUSB-CまたはAUXで接続。スピーカーをポータブルPAのように使えます。



USB-C/AUXで幅広く使える

JBL製品だけでなくスマートフォンやPCにもUSB-Cで接続可能。AUX接続にも対応し、配信や通話用マイクとしても活用できます。

対応製品

JBL Go 5、Grip、Flip 7、Charge 6、Xtreme 5、BoomBox 4、ならびにUSB Type-CまたはAUXを搭載したすべてのPartyBoxモデルに対応（最新の対応製品はウェブサイトJBL.comでご確認下さい）

Image: The USB-C dongle connected to a JBL speaker.

For detailed connection diagrams and compatibility, refer to the JBL One app or the official JBL website.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the power button on each microphone to turn it on or off. An indicator light will confirm the status.

2. AI Vocal Removal

The microphone features an AI vocal removal function. Press the dedicated button on the microphone to toggle vocal separation on or off. This allows you to easily convert any song into a karaoke track.



リアルタイムボーカルOFF

マイクのボタン操作で楽曲のボーカルをリアルタイムに分離・抑制。手持ちの音楽を、すぐにカラオケ体験へ変えられます。



クリアな音声

2.4GHzデジタルワイヤレス方式で、有効距離は最大25m。小型ながら、歌声やトークをしっかり届けるマイクセットです。

3. Microphone Volume Control

Adjust the microphone volume using the knob located on the microphone body.

4. Usage Modes: Pin Mic and Handheld

The JBL EasySing Mic Mini Duo can be used in two ways:

- **Pin Microphone:** Attach the strong magnetic clip to your clothing, then secure the microphone to the clip.
- **Handheld Microphone:** Attach the microphone to the provided ring handle for comfortable handheld use.



便利なアクセサリ付属

ピンマイクのように使えるマグネットクリップ、手持ち用リングハンドル、充電ケース、持ち運び用ポーチを同梱しています。



直感UI&アプリ調整

マイク本体のノブでボーカル分離や音量を調整。JBL OneアプリからEQやエコーも調整でき、場面に合わせて歌いやすく整えられます。

用途	対応機種	接続	アクセサリ
カラオケ	PartyBox 第3&第4世代		
	現行最新ポータブルスピーカー		 
	旧世代のAux-in付PartyBox		  
歌の練習	有線ヘッドホン		
録音やポッドキャスト	スマートフォン 録音やポッドキャスト用アプリ		 
ライブ配信	PC/スマートフォン ライブ配信アプリ		

Image: Microphone attached to the handheld handle.

5. JBL One App Integration

Download the JBL One app for advanced control and customization. The app allows you to adjust EQ settings, echo levels, and pitch changes to optimize your sound for different scenarios.



Image: The JBL EasySing Mic Mini Duo with JBL One app compatibility.

MAINTENANCE

1. Cleaning

Wipe the microphones and charging case with a soft, dry cloth. Do not use abrasive cleaners or immerse the devices in water.

2. Battery Care

The microphones provide up to 6 hours of battery life. For optimal battery longevity, avoid fully discharging the battery frequently and store the device in a cool, dry place when not in use for extended periods.



Image: The USB-C dongle can be used for charging compatible devices.

TROUBLESHOOTING

No Sound or Low Volume

- Ensure the microphones are powered on and fully charged.
- Check that the microphone volume knob is turned up.
- Verify that the microphone is correctly connected to your playback device via Bluetooth, USB-C dongle, or AUX.
- Adjust the volume settings on your connected speaker or device.

Connection Issues

- For Bluetooth connections, ensure both the microphone and the receiving device are in pairing mode and within range (up to 25m).
- If using the USB-C dongle, ensure it is securely inserted into the device.
- Try restarting both the microphone and the connected device.

Sound Quality Concerns (e.g., Robotic Sound, Volume Fluctuations)

- Ensure the microphone is positioned correctly and not too close or too far from the sound source.
- Check for environmental interference that might affect wireless signal quality.
- Use the JBL One app to adjust EQ settings or disable/reduce echo effects, which can sometimes affect perceived sound clarity.
- Ensure the vocal removal feature is set to your desired level, as aggressive vocal removal can sometimes impact overall sound.

SPECIFICATIONS

Brand	JBL
Model Name	JBL EasySing Mic Mini Duo
Manufacturer Model Number	JBLESMICMINIDUO
Connectivity Technology	AUX, Bluetooth, USB-C
Connector Type	3.5mm Jack, USB Type-C
Features	Echo Control, Clip, Pitch Change, Vocal Removal, Mic EQ Customization
Compatible Devices	PA System, Speaker, Smartphone, Laptop, Headphones
Color	Black
Product Weight	37 grams
Microphone Form Factor	Pin Microphone, Handheld Microphone
Power Type	Battery Powered
S/N Ratio	59 dB
Number of Channels	2
Frequency Response	15 KHz
Product Dimensions	24 x 34 x 61 mm
Product Exterior Material	Recycled Plastic
Recommended Uses	Karaoke, Gaming, Streaming, Video Conferencing, Singing

WARRANTY AND SUPPORT

Warranty Information

This product is warranted for one year from the date of delivery for new items purchased from authorized domestic retailers. Proof of purchase (delivery note) is required. The warranty is limited to use within the country of purchase. For second-hand or resold items, repairs will be handled at the actual cost.

Customer Support

For further assistance, technical support, or warranty claims, please visit the official JBL website or contact your local JBL customer service center. You can find contact information and FAQs on the JBL support page.

JBL Official Website: www.jbl.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question