

[Manuals.plus](#) /

› [Greesum](#) /

› Greesum GS-LCRF0320-N1 3-Piece Patio Furniture Set Instruction Manual

Greesum GS-LCRF0320-N1

Greesum GS-LCRF0320-N1 3-Piece Patio Furniture Set Instruction Manual

Model: GS-LCRF0320-N1 | Brand: Greesum

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage.

- Keep all children and pets away from the assembly area.
- Ensure all parts are securely fastened before use.
- Do not exceed the weight capacity of the furniture.
- Place the furniture on a flat, stable surface.
- Avoid using harsh chemicals for cleaning; refer to maintenance instructions.
- Periodically check all connections to ensure they remain tight.

2. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact Greesum customer support.

- Sectional Sofa (L-shaped, detachable into two loveseats)
- Adjustable Seat Mechanism
- Soft Cushions (seat and backrest)
- Coffee Table with Glass Top
- Assembly Hardware (bolts, nuts, washers, tools)
- Instruction Manual



Image: Overview of the Greesum 3-Piece Patio Furniture Set, showing the sectional sofa and coffee table.

3. ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. All necessary parts and instructions are packaged in two boxes. Follow the provided diagrams and text descriptions carefully.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all hardware and match them with the assembly diagrams.
3. Assemble the sofa frame sections according to the step-by-step diagrams. Ensure all bolts are finger-tightened initially.
4. Attach the adjustable seat mechanism to the designated sofa section.
5. Assemble the coffee table frame and place the glass top securely.
6. Once all sections are assembled, fully tighten all bolts using the provided tool. Do not overtighten.
7. Place the soft cushions on the sofa seats and backrests.

PRODUCT SIZE DETAILS

This L-shaped rattan sofa is detachable as two loveseats

 300LBS



Image: Diagram illustrating the dimensions of the L-shaped rattan sofa and coffee table, highlighting its detachability into two loveseats.

4. OPERATING INSTRUCTIONS AND FEATURES

4.1 Adjustable Seat Function

The sectional sofa features a card-slot design that allows for an adjustable seat. This mechanism provides stable support and allows you to lift the sofa base to form 5 different angles of elevation. This feature is designed for enhanced comfort, particularly for lounging or side sleeping.



Image: Close-up view of the adjustable seat mechanism, showing the 5-position angle adjustment for reclining.

4.2 Comfortable Cushions

The furniture set includes thick padded cushions for both seats and backrests. These cushions are stuffed with soft cotton to provide a comfortable and relaxed seating experience.

4.3 Utility Coffee Table

The included coffee table provides a convenient surface for beverages, snacks, or decorative items. Its design complements the sectional sofa.

UTILITY COFFEE TABLE

Break the Product Details content into separate separate



Image: Top-down view of the coffee table, showcasing its glass surface and utility for holding items.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your patio furniture set.

- **Frame Care:** Wipe the rattan and steel frame with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Cushion Care:** The cushion covers possess high water-resistance. For general cleaning, wipe with a damp cloth. For deeper cleaning, remove covers if possible and follow care instructions on the label. Allow cushions to dry completely before storing or replacing.
- **Glass Top Care:** Clean the glass top with a standard glass cleaner and a soft cloth.
- **Storage:** During prolonged periods of non-use or inclement weather, it is recommended to cover the furniture or store it indoors to protect it from the elements.
- **Inspection:** Periodically inspect all bolts and connections to ensure they are tight. Tighten as necessary.

6. TROUBLESHOOTING

- **Wobbly Furniture:** Ensure all bolts are securely tightened. Check that the furniture is placed on a level surface.
- **Difficulty Adjusting Seat:** Verify that the card-slot mechanism is clear of obstructions. Apply gentle, even pressure when adjusting.
- **Cushions Flattening:** Periodically fluff cushions to maintain their shape and loft.
- **Rattan Damage:** While the PE rattan is UV-resistant, prolonged exposure to extreme conditions can cause wear. Consider covering the furniture when not in use.

7. SPECIFICATIONS

Feature	Detail
Brand	Greesum
Model Number	GS-LCRF0320-N1
Color	Beige
Material Type	Polyethylene (PE Rattan), Powder-coated Steel Frame
Item Dimensions (L x W x H)	76 x 49.1 x 24 inches
Item Weight	87.8 pounds
Style	Contemporary
Shape	L-Shape (Sectional)
UPC	760606111929
Included Components	Patio Furniture Set (Sectional Sofa, Coffee Table, Cushions)

CLASSIC AND PRACTICAL PRODUCT DETAIL DESIGN



**Reinforcement
Frame**



**Soft & Thick
Cushion**



**Weatherproof
Rattan**




Image: Detailed view of the product's construction, highlighting the reinforcement frame, soft thick cushions, and weatherproof rattan material.

8. WARRANTY AND SUPPORT

For warranty information or customer support regarding your Greesum patio furniture set, please refer to the documentation included in your product packaging or contact Greesum directly through their official website or the retailer where the product was purchased.

For additional protection, optional 2-Year and 3-Year Protection Plans may be available for purchase separately. Please check with your retailer for details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0H3V3N18G>

More documents and user manuals: <https://manuals.plus/>