

Virubi N729P335558E

Virubi N729P335558E 70.8-inch Tall Storage Cabinet Instruction Manual

Model: N729P335558E

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Virubi N729P335558E 70.8-inch Tall Storage Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- **Anti-Tip Hardware:** This cabinet includes anti-tip hardware for enhanced safety. It is crucial to install this hardware to prevent the cabinet from tipping over, especially in households with children or pets. Follow the specific instructions provided for anti-tip hardware installation.
- Do not overload shelves or drawers beyond their specified weight capacities.
- Keep small parts and packaging materials away from children.
- Assembly is recommended for two people.

Metal Anti-Tip Hardware For Added Stability



Figure 1: Illustration of the metal anti-tip hardware for securing the cabinet to a wall, enhancing stability and safety.

PACKAGE CONTENTS

Before assembly, verify that all components are present. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (various sizes)
- Hardware Pack (screws, dowels, cam locks, hinges, drawer slides, handles, anti-tip kit)
- Assembly Instructions Manual

TOOLS REQUIRED

- Phillips Head Screwdriver
- Hammer (optional, for dowels)
- Drill (for anti-tip hardware wall attachment, if needed)
- Pencil
- Measuring Tape

SETUP AND ASSEMBLY INSTRUCTIONS

Follow the step-by-step diagrams and instructions provided in the separate assembly manual included in your package. Below are general guidelines and important considerations.

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Compare them with the parts list in your assembly manual to ensure everything is present.
2. **Assemble the Frame:** Begin by connecting the main side panels and base using the provided hardware. Ensure all connections are snug but do not overtighten.
3. **Install Drawer Slides:** Attach the drawer slides to the cabinet frame and the drawer box according to the instructions. The drawer uses bottom-mounted slide rails for smooth operation.
4. **Assemble Drawer and Doors:** Construct the drawer box and attach the front panel. Install hinges onto the cabinet doors and then attach the doors to the cabinet frame. Adjust hinges as needed for proper alignment.
5. **Insert Shelves:** Place the fixed shelf and adjustable shelves into their desired positions. The adjustable shelves can be moved to accommodate items of various heights.
6. **Attach Anti-Tip Hardware:** Securely attach the anti-tip hardware to the top rear of the cabinet and then to a wall stud using appropriate wall anchors (not always included, depending on wall type). This step is critical for stability.

Size inch




Figure 2: Detailed dimensions of the cabinet, useful for planning placement and internal organization.

OPERATING INSTRUCTIONS

Using the Doors and Drawer

The cabinet features soft-closing doors and a soft-closing drawer. This mechanism allows the doors and drawer to close gently and quietly, reducing wear and tear. Simply push the door or drawer lightly to engage the soft-close function.

Adjusting Shelves

Your cabinet includes two adjustable shelves. To adjust a shelf, carefully remove any items, lift the shelf, and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted before placing the shelf back.



Figure 3: The cabinet with doors open, demonstrating internal storage capacity and organization possibilities.

Flexible Storage



Two Adjustable Shelves, Store Items Your Way



Fixed Shelf, Secure Support For Heavier Items



Figure 4: Illustration of adjustable shelves and their respective weight capacities.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as they may damage the painted finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage, especially on the engineered wood surfaces.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Doors/Drawer do not close properly or rub.	- Hinges or drawer slides are misaligned. - Hardware is loose. - Cabinet is not level.	- Adjust hinges (usually screws on the hinge allow for vertical, horizontal, and depth adjustment). - Check and tighten all screws on hinges and drawer slides. - Ensure the cabinet is on a flat, level surface. Use shims if necessary.
Cabinet feels wobbly or unstable.	- Hardware is loose. - Anti-tip hardware not installed or improperly installed.	- Check and tighten all assembly screws. - Ensure the anti-tip hardware is correctly installed and securely anchored to a wall stud.
Missing parts or damaged components.	Manufacturing defect or shipping damage.	Contact customer support with your purchase details and a description of the issue.

SPECIFICATIONS

Model Number	N729P335558E
Product Dimensions (W x D x H)	23.7" x 15.7" x 70.8"
Item Weight	91.1 lbs
Material	Engineered Wood (Particle Board, MDF)
Finish Type	Painted Finish
Color	Charcoal Grey
Number of Drawers	1
Number of Doors	4
Adjustable Shelves	2
Soft-Close Feature	Doors and Drawer
Adjustable Shelf Weight Capacity	44.09 lbs (20 kg)
Drawer Weight Capacity	22 lbs (10 kg)
Anti-Tip Hardware	Included

WARRANTY INFORMATION

Specific warranty details for the Virubi N729P335558E Tall Storage Cabinet may vary by retailer and region. Please refer to your purchase receipt or contact the retailer where you purchased the product for detailed warranty terms and conditions. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the seller or manufacturer directly. For purchases made through Amazon, you can typically find seller contact information via your order history.

Seller: Com Furniture

Please have your model number (N729P335558E) and ASIN (B0H41FBVCL) ready when contacting support.