

[Manuals.plus](#) /

› [Aquaguard](#) /

› Aquaguard Aspire Glow RO+UV+Copper+Alkaline Water Purifier User Manual

Aquaguard GWPDHRUCA0002X

Aquaguard Aspire Glow RO+UV+Copper+Alkaline Water Purifier User Manual

Model: GWPDHRUCA0002X

1. INTRODUCTION

Thank you for choosing the Aquaguard Aspire Glow RO+UV+Copper+Alkaline Water Purifier. This manual provides essential information for the safe and efficient operation, installation, maintenance, and troubleshooting of your water purifier. Please read it thoroughly before using the appliance and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Ensure the purifier is installed by a qualified service technician.
- Do not expose the purifier to direct sunlight or extreme temperatures.
- Use only the power adapter supplied with the unit.
- Keep the purifier away from heat sources and flammable materials.
- Do not attempt to open or repair the unit yourself. Contact authorized service personnel.
- Ensure the water inlet pressure is within the specified operating range.
- Regularly check for leaks and address them immediately.

3. PRODUCT OVERVIEW

The Aquaguard Aspire Glow is an advanced water purifier designed to provide safe and healthy drinking water. It features a 12-stage purification process, intelligent indicators, and a sleek design.

Key Features:

- **Intelligent Halo Lights:** Communicate purifier status (Red for alert/service, Blue for purification, Ambient Glow for standby).
- **Real-Time Water Quality Display:** Shows live TDS levels of input and purified water.
- **Advanced Nanopore Long-Life Filters:** Designed to last up to 2 years, removing contaminants like Lead, Mercury, Arsenic, Cadmium, Microplastics, and Pesticides.

- **Active Copper & Alkaline Boost:** Enriches water with Copper, Zinc, Calcium, Magnesium, and enhances pH levels.
- **5th Gen UV LED Purification:** Mercury-free, instant purification, designed for a 10-year life.
- **High-Speed Flow Rate:** Fills a glass in approximately 10 seconds.
- **Compatibility:** Works with municipal, bore-well, and tanker water with TDS up to 2000 mg/L.



Image: The Aquaguard Aspire Glow water purifier showcasing its intelligent halo lights in red (alert), blue (purification), and ambient (standby) modes.

4. SETUP & INSTALLATION

Your Aquaguard Aspire Glow water purifier is designed for countertop installation. For optimal performance and to ensure proper functioning, professional installation is highly recommended.

Installation Steps:

1. **Unpacking:** Carefully remove the purifier and all components from the packaging. Verify that the installation kit is present.
2. **Site Selection:** Choose a clean, dry, and well-ventilated location near a water source and an electrical outlet. Ensure it is a stable countertop surface.
3. **Water Connection:** Connect the purifier to the raw water supply using the provided tubing and connectors. Ensure all connections are secure to prevent leaks.
4. **Drain Connection:** Connect the waste water tube to a suitable drain point.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.
6. **Initial Flush:** Before first use, allow the purifier to run for a few minutes to flush out any manufacturing residues. Refer to the operating instructions for details on initial flushing.

For assistance with installation, please contact Aquaguard customer service. The product includes free installation as part of its 2-year unconditional warranty.

Not just a Purifier. A Design Upgrade.

Designed for homes that
care about details.



Halo Lights Control
Set the mood of
your kitchen



Feather Touch
For Instant Dispense



Image: A diagram illustrating the dimensions of the Aquaguard Aspire Glow water purifier and its external sediment filter, showing its sleek and compact design suitable for modern kitchens.

5. OPERATING INSTRUCTIONS

Powering On:

Once installed and connected to power, the purifier will initiate its startup sequence. The Intelligent Halo Lights will indicate its status.

Understanding Halo Lights:

- **Blue Light:** Indicates that the purification process is active, and water is being purified.
- **Ambient Glow:** The purifier is in standby mode, ready for use.
- **Red Light:** Signals an alert or indicates that service is required. Refer to the troubleshooting section or contact customer support.



Image: The Aquaguard Aspire Glow water purifier demonstrating its halo lights control and feather touch dispense feature for instant water access.

Water Dispensing:

To dispense purified water, gently touch the dispense button. The purifier features a high-speed flow rate, filling a glass in approximately 10 seconds.



Image: The Aquaguard Aspire Glow water purifier dispensing purified water into a glass, highlighting its instant water delivery feature.

Real-Time TDS Display:

The built-in smart display shows the live TDS (Total Dissolved Solids) levels of both the input and purified water, allowing you to monitor water quality.

Advanced Purification with

NANOPORE

LONG LIFE FILTERS

Complete Protection against:




Lead, Mercury,
Arsenic & Cadmium^



Microplastics#



Pesticides



2-Year Unconditional
Warranty on Filters

*Microplastics reduction was validated using 0.5-micron microspherical test particles. Actual reduction may vary with microplastics size, type, and water conditions.

^Removes a significant amount of lead, mercury, arsenic, and cadmium based on internal testing under standard

Image: A close-up of the Aquaguard Aspire Glow water purifier's smart display showing the real-time TDS level of the purified water.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your Aquaguard Aspire Glow water purifier.

Filter Replacement:

The Nanopore Long-Life Filters are designed to last up to 2 years. The purifier's intelligent system will alert you when filter replacement is due (indicated by a red halo light). It is crucial to replace filters as recommended to maintain purification effectiveness.

Superior Purification. Superior Service.

Aquaguard Glow 2X Advantage



Benefits	Aquaguard Glow 2X Purifier	Other 2X Purifiers
Advanced 5th Gen UV LED Protection	✓	✗
Intelligent Halo Lights to display purifier status	✓	✗
Nanopore Purification at every TDS Level	✓	✗
Complete 2-year warranty on filters, spares & service	✓	✗
Wide service network covering 19,500+ pin codes	✓	✗

Image: An illustration of the Nanopore Long-Life Filters and the water purification process, highlighting the Auto Flush Technology and Anti-Scale Filter.

Auto Flush Technology:

The purifier is equipped with Auto Flush Technology, which periodically cleans the filters automatically, extending their life and maintaining performance.

Anti-Scale Filter:

An integrated Anti-Scale Filter helps minimize scale build-up, particularly important in areas with hard water, ensuring consistent performance.

Cleaning the Exterior:

Wipe the exterior of the purifier with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

7. 12-STAGE RO+UV PURIFICATION PROCESS

The Aquaguard Aspire Glow employs a comprehensive 12-stage purification system to deliver pure and safe drinking water:




Image: A visual representation of the 12 stages of advanced RO+UV purification, detailing each filter and its function.

1. **Mega Sediment Filter:** Removes fine dust, dirt, and mud, preventing filter choking.
2. **Sedi Shield 2X:** Removes physical impurities up to 5 microns.
3. **Particulate Filter:** Removes pathogenic particles and suspended matter.
4. **Anti-Scale Filter:** Prevents filter clogging by capturing salt impurities.
5. **Chemi Block 2X:** Protects against chemicals, odor, and bad taste.
6. **RO Maxx 2X:** Removes microplastics, pesticides, and industrial waste like lead and mercury.
7. **5th Gen UV LED:** Provides instant purified water with zero wait time, mercury-free, and has a 10-year life, eliminating 99.99% bacteria and viruses.
8. **4-in-1 Active Copper Technology (Stages 8-11):** Infuses water with Copper, Zinc, Calcium, and Magnesium.
9. **Alkaline Boost (Stage 12):** Increases pH and makes water alkaline as per BIS standards.

8. TROUBLESHOOTING

If you encounter any issues with your Aquaguard Aspire Glow, refer to the table below. For problems not listed or if the issue persists, contact Aquaguard customer support.

Problem	Possible Cause	Solution
No water dispensed	No power supply; Water inlet closed; Tank empty; Touch sensor issue.	Check power connection; Open water inlet valve; Wait for tank to fill; In case of power cut, the touch button will not work, so water cannot be dispensed. Contact service if issue persists.
Red Halo Light On	Filter replacement due; Service required; System error.	Contact Aquaguard customer service for filter replacement or service.
Slow water flow	Clogged filters; Low inlet water pressure.	Check inlet water pressure; Contact service for filter inspection/replacement.

Problem	Possible Cause	Solution
Water leakage	Loose connections; Damaged component.	Immediately turn off water supply and power. Contact Aquaguard customer service.
Unusual taste/odor	Filters need replacement; Initial use residue.	Flush the system thoroughly; If taste persists, contact service for filter inspection.

9. SPECIFICATIONS

Feature	Detail
Brand	Aquaguard
Model Name	AQUAGUARD ASPIRE GLOW ROUV CUALK 2X
Model Number	GWPDHRUCA0002X
Product Dimensions (L x W x H)	32.3L x 31.8W x 51H Centimeters
Item Weight	10 Kilograms
Material	Acrylonitrile Butadiene Styrene
Capacity	5 Liters
Installation Type	Countertop
Purification Method	Reverse Osmosis, Ultraviolet
Power Source Type	Corded Electric
Lower Temperature Range	5 Degrees Celsius
Upper Temperature Rating	45 Degrees Celsius
Maximum Flow Rate	24 Liters Per Hour
Operating Pressure Range	Up to 3 Kilograms Per Square Centimeter
Supported Water TDS Level Maximum	2000 PPM
Water Saving Percentage	40.0%
Filter Life Cycle	2 Years
What's in the box?	Installation Kit


10. WARRANTY & SUPPORT

2-Year Unconditional Warranty:

The Aquaguard Aspire Glow comes with a 2-year unconditional warranty. This includes:

- Zero filter cost for 2 years.
- Zero spare parts cost for 2 years.
- Zero service cost for 2 years.

- Free installation.
- Unlimited repair visits.
- No Annual Maintenance Contract (AMC) required for the warranty period.

A promotional banner for the Aquaguard Aspire Glow water purifier. The background is dark. On the left, the text '2-Year Unconditional Warranty' is written in large, bold, orange letters. Below it, a rounded rectangle contains the text 'Zero Hidden Costs' in orange. Further down, three icons are displayed: a water filter, a rupee symbol, and a gear with a hand, each followed by the text 'Zero Filter Cost', 'Zero Spares Cost', and 'Zero Service Cost' respectively. On the right, a black water purifier with a glowing blue circular light around its top is shown. The brand name 'Aquaguard' is visible on the purifier. At the bottom right, the text 'Valid for 2 years.' is written in small white font.

2-Year Unconditional Warranty

Zero Hidden Costs

Zero Filter Cost Zero Spares Cost Zero Service Cost

Valid for 2 years.

Image: The Aquaguard Aspire Glow water purifier highlighting its 2-year unconditional warranty, which covers zero filter, spares, and service costs.

Customer Support:

Aquaguard is backed by India's widest service network, accessible across 19,500+ pin-codes. For any service requests, queries, or support, please contact:

- **Manufacturer:** Eureka Forbes Limited
- **Registered Office Address:** B1/B2, 701, 7th Floor, Marathon Innova, Off. Ganpatrao Kadam Marg, Lower Parel (West), Mumbai, Maharashtra – 400013
- **Customer Service:** Refer to the contact information provided in your product packaging or visit the official Aquaguard website.