

COBIZI 143-SPC000266

COBIZI 16x16 Hexagonal Pop-up Gazebo Instruction Manual

Model: 143-SPC000266

1. INTRODUCTION AND PRODUCT OVERVIEW

Thank you for choosing the COBIZI 16x16 Hexagonal Pop-up Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your gazebo. Please read these instructions carefully before use and retain them for future reference.

This gazebo offers an ultra-large 256 sq.ft coverage, designed to comfortably accommodate 14-18 guests. Its innovative 6-sided hexagonal design provides more usable space compared to traditional square canopies. Key features include a heavy-duty steel frame, 360° bug-proof mosquito netting, adjustable height settings, and a double-vented roof for improved air circulation and stability.



Image 1.1: The COBIZI 16x16 Hexagonal Pop-up Gazebo set up in a backyard.

2. SAFETY INFORMATION

- **Weather Conditions:** Do not use the gazebo in severe weather conditions such as heavy rain, strong winds (exceeding 25 mph), hail, or snow. Disassemble and store the gazebo to prevent damage and ensure safety.
- **Anchoring:** Always secure the gazebo firmly to the ground using the provided stakes and ropes. For additional stability, use sandbags or other weights on the legs.
- **Assembly:** Ensure at least two adults are present for assembly and disassembly to prevent injury. Follow all steps carefully.
- **Clearance:** Set up the gazebo on level ground, away from overhead power lines, trees, and other obstructions.
- **Fire Safety:** Keep all heat sources and open flames away from the gazebo fabric. The material is not fireproof.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow them to play unsupervised around the gazebo.
- **Inspection:** Regularly inspect all components for wear, damage, or loose connections. Do not use if any parts are damaged.

3. PACKING LIST

Before assembly, verify that all components listed below are present in your package.



Image 3.1: Contents of the COBIZI Gazebo package.

- 1 x Waterproof Carry Bag
- 1 x Adjustable Height Frame
- 2 x Mosquito Netting (for hexagonal structure)
- 1 x Canopy Top
- 6 x Ropes
- 6 x Sandbags
- 12 x Stakes
- 1 x Instruction Manual

4. SETUP INSTRUCTIONS

Assembly typically requires two people. Follow these steps for quick and easy setup.

Easy to assemble 2person

Step 1

Take out the frame, cover the top and open the canopy.



Step 2

Push the central lock tech.

Step 3

Adjust the height
(3 Height adjustment)



Image 4.1: Visual guide for gazebo assembly steps.

1. Step 1: Unfold the Frame and Attach Canopy Top

With a partner, gently pull the frame legs outwards to begin unfolding the structure. Place the canopy top over the partially opened frame, ensuring it is correctly oriented. Secure the canopy to the frame corners.

2. Step 2: Engage the Central Lock Mechanism

From underneath the canopy, push the central lock mechanism upwards until it clicks into place. This will fully extend the canopy frame.

3. Step 3: Adjust Height and Secure

Press the pinch-free buttons on each leg to adjust the gazebo to your desired height. There are 3 adjustable height settings. Once the height is set, secure the gazebo to the ground using the provided stakes and ropes. Attach sandbags to the legs for additional stability, especially in breezy conditions.

4. Step 4: Attach Mosquito Netting

Attach the mosquito netting panels to the gazebo frame using the integrated zippers and fasteners. Ensure all panels are securely connected to provide 360° insect protection.



Image 4.2: Details of the gazebo's construction, including frame, zipper, height adjustment, and foot plate.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The gazebo features an innovative pinch-free button system allowing for effortless height adjustment. Each leg has a button that, when pressed, releases the locking mechanism. Adjust the center pole height up to 9 feet in 3 distinct positions to suit your needs on various terrains or for different events. Ensure all legs are adjusted to the same height for stability.

5.2 Mosquito Netting Usage

The premium 210D PU-coated Oxford mosquito netting provides comprehensive insect protection while maintaining airflow and clear visibility. Use the smooth zippers to open and close the netting panels as needed. When not in use, the netting can be tied back to the legs or removed for storage.

210D Oxford Cloth with Dual-layer Durability

Blocks Rain, Wind, and UV Rays



Image 5.1: Detail of the durable Oxford cloth and mosquito netting.

5.3 Vented Top Functionality

The gazebo is equipped with a double-tier vented roof. This design is crucial for improving air circulation, allowing hot air to escape, and reducing wind stress on the canopy. This helps keep the interior cooler on warm days and enhances the gazebo's overall stability and wind resistance.



Image 5.2: Illustration of the vented top for air circulation.

5.4 Disassembly and Storage

To disassemble, reverse the assembly steps. Lower the height, disengage the central lock, and carefully fold the frame. Ensure the canopy and netting are clean and dry before folding and placing them into the included carry bag. Store in a cool, dry place to prolong product life.



Image 5.3: Gazebo dimensions and compact folding size for transport. Note: Dimensions shown are for a 13x13FT model, refer to Section 8 for 16x16FT model dimensions.

6. MAINTENANCE

- **Cleaning:** Clean the canopy and netting with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Wipe down the steel frame with a damp cloth to remove dirt and debris. Inspect for any signs of rust or damage. Apply a rust-inhibiting spray if necessary.
- **Storage:** When not in use for extended periods, or during adverse weather, disassemble the gazebo and store all components in the carry bag in a dry, protected area.
- **Regular Inspection:** Periodically check all connections, ropes, and stakes for security and wear. Replace any worn or damaged parts immediately.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Gazebo is unstable or wobbly.	Not properly anchored; uneven ground; legs not fully extended/locked.	Ensure all stakes and ropes are securely fastened. Use sandbags for extra weight. Verify all legs are locked at the same height. Relocate to level ground if possible.
Difficulty extending/retracting frame.	Frame joints are stiff; central lock mechanism is stuck.	Apply a silicone-based lubricant to moving parts. Ensure no fabric is caught in the frame. Gently wiggle the frame while pushing/pulling.
Mosquito netting zippers are sticking.	Dirt or debris in zipper teeth; zipper alignment issue.	Clean zipper teeth with a small brush. Apply zipper lubricant or wax. Ensure netting is not pulled too tight.
Water pooling on canopy.	Canopy not taut enough; frame not fully extended.	Ensure the frame is fully extended and locked. Adjust canopy tension if possible. Do not use in heavy rain.

8. SPECIFICATIONS

Brand: COBIZI

Model Number: 143-SPC000266

UPC: 840561214535

Product Dimensions (L x W x H): 192"L x 192"W x 106"H (16 ft x 16 ft x 8.8 ft)

Floor Area: 256 Square Feet

Occupancy: 14-18 People

Shape: Hexagonal

Frame Material: Metal (Powder-coated Steel)

Canopy Material: 210D PU-coated Oxford fabric

Water Resistance Level: Waterproof

Ultraviolet Light Protection: 100% (UPF 50+)

Assembly Required: No (Pop-up design, minimal assembly)

Color: Dark Gray

9. WARRANTY INFORMATION

COBIZI products are manufactured to high-quality standards. For specific warranty details regarding your COBIZI 16x16 Hexagonal Pop-up Gazebo, please refer to the warranty card included with your purchase or contact COBIZI customer support directly. Please retain your proof of purchase for any warranty claims.

A 30-day return policy is typically offered for this product. Please check with your retailer for their specific return guidelines.

10. CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact COBIZI customer support.

Manufacturer: COBIZI

Seller: COBIZI Direct

Online Store: [Visit the COBIZI Store on Amazon](#)

For further assistance, please refer to the contact information provided in your product packaging.