Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KM-qBp9FZ

Generic Console Table User Manual

Model: KM-qBp9FZ (120x30x80cm, Black/White)

1. Introduction

Thank you for choosing the Generic Console Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before assembly and keep it for future reference.



Figure 1: Generic Console Table (Black/White variant). This image shows the overall design of the console table with its sleek rock slab top and sturdy metal frame, suitable for various home settings.

2. Safety Information

- Read all instructions carefully before assembly.
- Keep small parts and packaging materials away from children.
- Assemble the table on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the table. Refer to specifications for weight capacity.
- Do not stand or sit on the table.
- Place the table on a level surface to prevent tipping.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Rock Slab Tabletop (1x)
- Metal Frame Components (various pieces)
- Assembly Hardware (screws, bolts, Allen key, etc.)
- Instruction Manual (this document)

4. Setup and Assembly

Assembly is designed to be straightforward and typically takes less than 20 minutes. Two people are recommended for easier handling of the tabletop.

Required Tools (Not Included):

- Phillips head screwdriver (if not provided)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, non-abrasive surface to prevent damage.
2. **Assemble Frame Base:** Identify the base components of the metal frame. Connect them using the provided screws and the Allen key. Do not fully tighten screws yet.
3. **Attach Vertical Supports:** Connect the vertical metal supports to the assembled base. Ensure they are oriented correctly according to the diagrams. Secure with screws, but do not fully tighten.
4. **Position Tabletop:** With assistance, carefully place the rock slab tabletop onto the top of the assembled frame. Align the pre-drilled holes on the tabletop with the mounting points on the frame.
5. **Secure Tabletop:** Attach the tabletop to the frame using the remaining screws. Once all screws are in place, gradually tighten all screws on the entire frame and tabletop until secure. Do not overtighten.
6. **Final Check:** Gently shake the table to ensure stability. If any wobbling occurs, re-check all connections and tighten screws as needed.



Figure 2: Frame Design Detail. This image highlights the creative modeling design of the structural metal frame, emphasizing its contribution to strong stability.



Figure 3: Assembly Reference. This image provides a visual reference of the console table, potentially showing it before and after final assembly or in different stages, illustrating the overall structure.

5. Operating and Usage

Your console table is designed for versatile use in various settings:

- **Entryway/Hallway:** Ideal for displaying decorative items, holding keys, mail, or other essentials near your front door.
- **Living Room:** Can serve as a stylish accent table behind a sofa, or against a wall to display art, lamps, or books.
- **Bedroom/Office:** Adds a refined touch for holding small personal items, plants, or as a decorative surface.

Its slim profile is designed to maximize space, fitting well against walls without obstructing pathways.

6. Maintenance and Care

Proper care will ensure the longevity and appearance of your console table.

- **Rock Slab Top:** The 12mm thick rock slab surface is smooth and easy to clean. Wipe spills immediately with a soft, damp cloth. For general cleaning, use a mild soap solution and dry thoroughly. Avoid abrasive cleaners or harsh chemicals that could damage the surface.
- **Metal Frame:** Clean the metal frame with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid using abrasive cleaners or steel wool.
- **Protection:** Use coasters under drinks and placemats under decorative items to prevent scratches and stains.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or material degradation over time.



Figure 4: Countertop Thickness. This image illustrates the 12mm thickness of the rock slab countertop, highlighting its durable and sleek design.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Table wobbles	Uneven floor; loose screws	Move table to a level surface; check and tighten all assembly screws.
Scratches on tabletop	Sharp objects; abrasive cleaning	Use coasters and placemats. For minor scratches, consult a professional for rock slab repair. Avoid abrasive cleaners.
Stains on tabletop	Spills not cleaned promptly	Clean spills immediately. For dried stains, use a mild cleaner specifically designed for stone surfaces.

8. Specifications

Brand:	Generic
Model Number:	KM-qBp9FZ
Dimensions (L x W x H):	120 cm x 30 cm x 80 cm (47.2 x 11.8 x 31.5 inches)
Color:	Black/White
Materials:	12mm Thick Rock Slab Top, Metal Frame
Assembly Required:	Yes

9. Warranty and Support

Specific warranty information for this product is not provided in the product details. Please refer to your retailer's return policy or contact the seller directly for details regarding warranty coverage and customer support.

For assistance with missing parts, damaged components, or assembly questions, please contact the seller through your purchase platform.

© 2026 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H4FS4VNV

More documents and user manuals: **https://manuals.plus/**