

Oprisen Oprisen Chaise Lounge Indoor 01

Oprisen Tufted Upholstered Chaise Lounge Indoor Chair User Manual

Model: Oprisen Chaise Lounge Indoor 01

1. PRODUCT OVERVIEW

The Oprisen Tufted Upholstered Chaise Lounge is designed for comfort and style in various indoor settings. It features soft velvet upholstery, nailhead trim, and classic wooden legs, making it suitable for reading, relaxing, or as an elegant accent piece.

Key features include:

- **Elegant Design:** Velvet upholstery with nailhead trim and classic wooden legs.
- **Comfortable Seating:** High-quality, breathable velvet fabric and high-density foam filling.
- **Durable Construction:** Solid wood frame and base supporting up to 600 lbs.
- **Versatile Use:** Ideal for bedrooms, living rooms, reading rooms, or apartments.
- **Included:** One decorative pillow.



Image 1.1: The Oprisen Tufted Upholstered Chaise Lounge in Velvet Blue, showcasing its overall design and elegant appearance.


Comfy Chaise Lounge Chair Indoor



Luxurious chenille Fabric



High-Resilience Foam



Classic Button-tufted Upholstery



Side Pockets



7.8" Sturdy Turned Wood Leg

Image 1.2: Detailed view of the chaise lounge highlighting luxurious velvet fabric, high-resilience foam, classic button-tufted upholstery, and convenient side pockets.



Image 1.3: Illustration of the chaise lounge's sturdy turned wood legs, high load capacity (695 lbs), and clearance for robot vacuums.

2. SETUP AND ASSEMBLY

The Oprisen Chaise Lounge requires minimal assembly. Follow the included instructions carefully to ensure proper setup. Typically, assembly can be completed by one person in under 20 minutes.

2.1 Unpacking

1. Carefully open the packaging and remove all components.
2. Verify that all parts listed in the assembly guide are present.
3. Place all components on a soft, clean surface to prevent scratches during assembly.

2.2 Assembly Steps

Refer to the detailed assembly instructions provided in the box for specific steps. General steps include attaching the legs to the base and securing any backrest or armrest components.

Chromatic Aberration



Due to the light, may lead to a slight color difference between the picture and the actual product, the final color is subject to the actual product.

Image 2.1: Visual representation of the product delivery and the ease of assembly, indicating that one person can assemble it quickly.

3. OPERATING AND USAGE

The Oprisen Chaise Lounge is designed for versatile use, providing ergonomic support for various activities.

3.1 Ergonomic Seating

The chaise lounge features a design that supports your body in key areas, including the back, lumbar, hips, and legs. The included round backrest pillow enhances comfort and support.



Image 3.1: A person demonstrating the ergonomic seating experience, with labels indicating back, lumbar, hip, and leg support.

Match your decor and style



Reading Books



Watching TV



Sitting & Lounging



Taking a nap



Image 3.2: Another view of the ergonomic seating experience, emphasizing comfortable back support provided by the round back pillow.

3.2 Versatile Activities

This chaise lounge is suitable for various activities:

- Reading books
- Watching TV
- Sitting and lounging
- Taking a nap



Image 3.3: Examples of how the chaise lounge can be used for reading, watching TV, sitting, and napping, adapting to various decor styles.

3.3 Additional Features

The chaise lounge includes practical features such as side pockets for storage and a removable back pillow for adjustable comfort.

Match your decor and style



Reading Books



Watching TV



Sitting & Lounging



Taking a nap



Image 3.4: Detailed view of high-resilience cushions, side pockets for magazines or remotes, the removable back pillow, and the 16.3-inch seat height.

4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your chaise lounge.

4.1 Cleaning the Upholstery

- **Regular Cleaning:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild upholstery cleaner following the product instructions. Test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use harsh detergents, solvents, or abrasive cleaners, as these can damage the velvet fabric.

4.2 Wood Frame and Legs

- Wipe wooden parts with a soft, damp cloth. Dry immediately.
- Avoid prolonged exposure to direct sunlight or extreme temperatures, which can cause wood to warp or fade.

4.3 General Care

- Keep the chaise lounge away from heat sources and direct sunlight to prevent fading and material degradation.
- Periodically check and tighten all screws and bolts to ensure stability.

5. TROUBLESHOOTING

This section addresses common issues you might encounter.

5.1 Stability Issues

- **Problem:** The chaise lounge feels wobbly.
Solution: Ensure all legs are securely tightened. Check that the chaise lounge is placed on a flat, even surface.

5.2 Fabric Care

- **Problem:** Fabric appears flattened or matted.

Solution: Gently brush the velvet fabric with a soft-bristle brush in the direction of the pile to restore its texture.

- **Problem:** Minor stains.

Solution: Refer to the spot cleaning instructions in Section 4.1.

5.3 Missing Parts

- **Problem:** Missing hardware or components during assembly.

Solution: Contact Oprisen customer support with your product model number and a description of the missing parts.

6. SPECIFICATIONS

Feature	Detail
Brand	Oprisen
Model Name	Oprisen Chaise Lounge Indoor VVBURF
Model Number	Oprisen Chaise Lounge Indoor 01 VVBURF
Color	Velvet Blue
Material	Velvet (Fabric), Wood (Frame)
Product Dimensions (D x W x H)	56.3" x 21" x 29.5"
Seat Height	16.3 inches
Seat Depth	50 inches
Item Weight	100 pounds
Maximum Weight Recommendation	600 pounds
Included Components	Pillow
Room Type	Apartment, Bedroom, Living Room, Study Room

Product Dimension



Image 6.1: Diagram illustrating the precise dimensions of the Oprisen Chaise Lounge, including length, width, height, and seat height.

7. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or contact Oprisen customer support directly. If you have any questions or require assistance with assembly, parts, or general product inquiries, please reach out to the manufacturer's customer service.

Contact information for Oprisen can typically be found on their official website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question