

COBIZI 10x20 pop up gazebo-251

COBIZI 12x20 Pop Up Canopy Tent Gazebo Instruction Manual

This manual provides detailed instructions for the safe and efficient assembly, operation, and maintenance of your COBIZI 12x20 Pop Up Canopy Tent Gazebo. Please read thoroughly before use.

1. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines to prevent injury or damage to the product:

- Always ensure the gazebo is securely anchored using all provided ropes, stakes, and sandbags.
- **Important:** To ensure your safety and the long-term use of the gazebo, please take it down in stormy or hurricane weather. Do not use in high winds exceeding 20 mph.
- Keep all flame and heat sources away from the canopy fabric.
- Adult supervision is required for assembly and disassembly.
- Do not hang heavy objects from the frame.
- Regularly inspect all components for wear or damage. Do not use if any parts are compromised.

2. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present in your package. If any parts are missing, please contact COBIZI support for replacements.



This image shows all components included in the package: 1x Steel Frame, 1x Cover Bag, 6x Ropes, 4x Sandbags, 12x Stakes, 1x Repair Patch, 1x Canopy Top, 6x Mosquito Netting, and 4x Eave Poles (2 long; 2 short).

- 1x Steel Frame
- 1x Cover Bag
- 1x Canopy Top (210D Oxford fabric)
- 6x Mosquito Netting Panels
- 6x Ropes
- 4x Sandbags
- 12x Stakes
- 1x Repair Patch
- 4x Eave Poles (2 long, 2 short)

3. PRODUCT FEATURES

The COBIZI 12x20 Pop Up Canopy Tent Gazebo is designed for versatility and durability, offering a comfortable outdoor


experience.

- **Ample Space:** Provides a usable area of 10x20 ft (excluding overhangs), accommodating 15-20 people.
- **High-Quality Fabric:** Features 210D Oxford fabric with an internal silver coating, offering SPF50+ protection, 1500mm waterproofing, and blocking up to 99% of UV rays.
- **Robust Steel Frame:** Constructed with a powder-coated steel frame (3mm thickness, supporting up to 150 lbs) that undergoes pickling and phosphating processes to prevent corrosion and rust. Includes pre-drilled bases and stakes for stability.
- **Overhanging Eaves:** Additional 18-inch overhanging eaves provide extended shade and enhanced protection against wind and rain.
- **Multi-Lock System:** Ensures secure locking of poles during extension.
- **Adjustable Height:** Offers 3 height settings: 110in/280cm, 114in/290cm, 120in/300cm (from roof to bottom).
- **Insect Protection:** Equipped with 6 removable zippered mesh panels to keep insects out while maintaining airflow.



**Ample Space,
Infinite Comfort**
Store all your outdoor gear

The COBIZI 12x20 Pop Up Canopy Tent Gazebo provides ample space for outdoor activities, featuring a sturdy frame and mesh walls.



Gathering With Friends

18 inches eaves provide an expanded shade footprint

The gazebo features 18-inch overhanging eaves, designed to provide additional shade and protection from the elements.




INSECT-PROOF

Insect-proof nets block flying insects effectively, offering a comfy space.



The gazebo includes insect-proof nets to effectively block flying insects, ensuring a comfortable and protected outdoor space.

PACKING LIST



1x Steel Frame




1x Cover Bag



6 x Ropes



4 x Sandbags



12 x Stakes



1 x Repair Patch



1 x Canopy Top



6 x Mosquito Netting



4 x Eave Poles (2 long; 2 short)

The canopy fabric is high-density and silver-coated, providing excellent waterproofing and UV protection (SPF50+, 99% UV block).

4. SETUP INSTRUCTIONS

Assembly typically takes two people approximately 15 minutes and requires no additional tools.

Step-by-Step Assembly:

1. **Open the Frame:** Carefully unfold the steel frame. Ensure all legs are extended. Install the eave poles into their designated slots.
2. **Install Roof Fabric:** Drape the canopy top fabric over the frame. Tuck the overhanging eaves securely underneath the frame structure.
3. **Lift and Lock:** With assistance, lift the six corners of the frame upwards until the multi-lock latches click into place, securing the frame in its fully extended position.
4. **Adjust Height and Attach Mesh Panels:** Adjust the gazebo to your desired height setting (110in, 114in, or 120in)

by pressing the comfort grip locks on the poles. Attach the six removable mesh panels using the zippers and Velcro fasteners.



A visual guide detailing the four main steps for quick assembly: 1. Open the frame and install eave poles. 2. Install the roof fabric. 3. Lift corners until latches click. 4. Adjust height and install mesh panels.

Securing the Gazebo:

- Use the provided ropes and stakes to anchor the gazebo firmly to the ground.
- Fill the sandbags with sand and attach them to the gazebo legs for additional stability, especially in moderate wind conditions.

5. OPERATING INSTRUCTIONS

Adjusting Height:

The gazebo offers three height settings. To adjust, locate the comfort grip locks on each leg. Press the button to release the lock, then carefully raise or lower the leg to the desired height. Ensure all four legs are locked at the same height for stability.

Using Mosquito Netting:

The gazebo comes with 6 removable zippered mesh panels. These can be used in various configurations:

- **Fully Enclosed:** Zip all panels together to create an insect-free environment.
- **Semi-Enclosed:** Zip some panels and tie back others for partial enclosure and ventilation.
- **Open Pavilion:** Remove all mesh panels or tie them back completely for an open-air setup.


Each mesh panel is designed to stick close to the canopy bottom edge with a hook attached to the crossbar, ensuring a tight seal against insects.

Comes with 6 Removable Zippered Mesh


All 6 panels can be zipping or unzipping smoothly, you get free entry and exit.




No Mosquito Net



Enclosed gazebo



Semi-enclosed gazebo



4 Mosquito Net



Ventilated Gazebo



Cool Pavilion

The gazebo offers versatile configurations with its 6 removable zippered mesh panels, allowing for various setups including fully enclosed, semi-enclosed, or open pavilion styles.

6. MAINTENANCE

Cleaning:

- **Canopy Fabric:** Clean with mild soap and water. Do not use harsh detergents or abrasive cleaners. Allow to air dry completely before storage.
- **Steel Frame:** Wipe down with a damp cloth. For stubborn dirt, use mild soap and water. Ensure the frame is dry to prevent rust.
- **Mesh Panels:** Hand wash with mild soap and water. Air dry.

Storage:

When not in use, especially during adverse weather conditions or for extended periods, disassemble the gazebo and store it in the provided cover bag. Store in a cool, dry place away from direct sunlight to prolong the product's lifespan.

Inspection:

Periodically inspect all parts, including the frame, fabric, zippers, ropes, and stakes, for any signs of wear, damage, or corrosion. Replace any damaged components immediately to ensure safe operation.

7. TROUBLESHOOTING

- **Gazebo is unstable:** Ensure all legs are fully extended and locked at the same height. Verify that all ropes, stakes, and sandbags are properly installed and secured. Do not use in winds exceeding 20 mph.
- **Water pooling on canopy:** Ensure the canopy fabric is taut and properly installed over the frame. Adjust the height if necessary to create proper tension.
- **Difficulty with assembly/disassembly:** Ensure two people are assisting. Refer to the installation guide and ensure all buttons are pressed to release locks before adjusting.
- **Missing accessories:** If any parts are missing upon delivery, please contact COBIZI support for replacement.

8. SPECIFICATIONS

Feature	Specification
Brand	COBIZI
Model Number	10x20 pop up gazebo-251
Dimensions (L x W x H)	252"L x 144"W x 130"H (21 ft L x 12 ft W x 10.8 ft H)
Floor Area	200 square feet (usable area 10x20 ft)
Item Weight	75.8 pounds
Occupancy	15-20 people
Frame Material	Powder-coated Steel (3mm thickness)
Canopy Fabric	210D Oxford with Silver Coating
UV Protection	SPF50+, blocks up to 99% UV rays
Water Resistance Level	Waterproof (1500mm)
Wind Resistance	Up to 20 mph
Height Settings	3 (110in/280cm, 114in/290cm, 120in/300cm)
UPC	840561214948

9. WARRANTY AND SUPPORT

COBIZI is committed to providing quality products and customer satisfaction.

- **Quality Protection:** The product comes with 1 year quality protection. Damaged parts will be replaced free of charge within this period.
- **Customer Support:** COBIZI provides 24-hour support for any issues or inquiries you may have.
- For assistance, missing accessories, or warranty claims, please contact COBIZI customer service directly. Refer to your purchase documentation for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question