VASAGLE ULTV535K101

VASAGLE Farmhouse TV Stand

Model: ULTV535K101

Brand: VASAGLE

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your new VASAGLE Farmhouse TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The VASAGLE Farmhouse TV Stand, Honey Brown, in a modern living room with a TV mounted above it.

Safety Information

- Always follow the assembly instructions provided in the package.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of the tabletop (170 lb / 77.5 kg) or middle shelf (38 lb / 17.5 kg).
- Place the TV stand on a flat, stable surface to prevent tipping.
- Keep small parts away from children during assembly to avoid choking hazards.
- Use caution when moving the assembled unit to prevent injury or damage.

Package Contents

Your VASAGLE Farmhouse TV Stand package includes:

- 1 x TV Stand (main components)
- 1 x Assembly Kit (containing all necessary hardware and tools)
- 1 x Detailed Assembly Instructions Manual (PDF link availablehere)

Please verify all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

Assembly Instructions

Assembly of the VASAGLE Farmhouse TV Stand is designed to be straightforward. Please refer to the included detailed assembly instructions manual for step-by-step guidance. The process typically involves:

1. Unpacking all components and verifying against the parts list.
2. Attaching the side panels to the base and top panels.
3. Installing the adjustable shelves into the desired positions.
4. Assembling and attaching the sliding barn doors to the track.
5. Securing all connections with the provided hardware.

For visual assistance, consult the PDF manual linked above. The assembly kit includes all necessary tools, such as an Allen wrench.

Operation

Sliding Barn Doors

The TV stand features two sliding barn doors that allow for flexible storage. You can slide the doors to cover the central compartments or either of the side compartments, depending on your preference for displaying or concealing items.



Image: Close-up of the TV stand illustrating the functionality of the sliding barn doors to customize storage visibility.

Adjustable Shelves

The internal shelves are adjustable, offering three height options to accommodate items of varying sizes, such as DVDs, game consoles, or decorative objects. To adjust, simply remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf.



Image: Diagram showing the adjustable shelves with three height options, each 1.2 inches (3 cm) apart.

Cable Management

The TV stand is equipped with six cable holes on the back panel to help organize and conceal wires from your electronic devices, reducing clutter and maintaining a tidy appearance.



Image: View of the TV stand's back panel highlighting the six cable holes for organized wire routing.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.

- **Spills:** Clean spills immediately to prevent staining or damage to the particleboard and MDF panels.
- **Inspection:** Periodically check all hardware connections to ensure they remain tight. Re-tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood-look finish.

Troubleshooting

Wobbly Stand

If the TV stand feels wobbly after assembly, ensure all screws and fasteners are fully tightened. Check that the stand is placed on a level surface. Adjust the feet if applicable (this model does not specify adjustable feet, so assume level surface is key).

Sliding Doors Not Moving Smoothly

If the barn doors do not slide smoothly, check the track for any obstructions or debris. Ensure the door rollers are properly seated in the track. A small amount of silicone lubricant can be applied to the track if needed, but avoid oil-based lubricants.

Missing or Damaged Parts

If you discover any missing or damaged parts upon opening the package, please contact VASAGLE customer support immediately for assistance. Do not attempt to assemble the unit with incomplete or damaged components.

Specifications

Feature	Detail
Brand	VASAGLE
Model Number	ULTV535K101
Color	Honey Brown
Material	Particleboard, MDF (Medium Density Fiberboard), Steel
Item Dimensions (L x W x H)	58 x 16 x 24 inches (147 x 40 x 60.5 cm)
Item Weight	70 pounds (31.75 kg)
Max. Static Load Capacity (Tabletop)	170 lb (77.5 kg)
Max. Static Load Capacity (Middle Shelf)	38 lb (17.5 kg)
TV Size Compatibility	Up to 65 inches (e.g., 40", 43", 50", 55", 60", 65")
Number of Compartments	4
Cable Management	6 cable holes




Image: Detailed diagram illustrating the dimensions and maximum load capacities of the TV stand.

Warranty and Support

This product is covered by standard return policies. For specific warranty details, please refer to the purchase documentation or contact the retailer directly. For customer support regarding assembly, missing parts, or product issues, please reach out to VASAGLE customer service through your point of purchase.
Amazon offers a 30-day easy return policy and customer support for purchases made through their platform.

© 2026 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question