

[Manuals.plus](#) /

> [invens](#) /

> invens S2000 Senior Flip Phone User Manual

invens S2000

invens S2000 Senior Flip Phone User Manual

Model: S2000

1. INTRODUCTION

The invens S2000 is a user-friendly flip phone designed for seniors, featuring large buttons, a clear display, and essential functions for daily communication. Its robust design and practical features ensure ease of use and peace of mind.



Image 1.1: Overview of the invens S2000 Senior Flip Phone highlighting its main features like 1700mAh battery, 2.4-inch screen, large keys, SOS button, and Quad SIM capability.

2. PACKAGE CONTENTS

Please check the box for the following items:

- invens S2000 Phone x 1
- Protective Case (2 pieces) x 1
- Type-C USB Cable x 1
- User Manual x 1
- Lanyard x 1



Image 2.1: Contents of the invens S2000 package, including the phone, protective case, USB cable, user manual, and lanyard.

3. PRODUCT FEATURES

- **Flip Design:** Protects the screen and keys, easy to carry.
- **Large Physical Buttons:** Facilitates dialing and menu navigation.
- **2.4-inch Color Screen:** Clear display for contacts, messages, and information.
- **SOS Button:** Quick access to emergency contacts for enhanced safety.
- **Quad SIM Support:** Allows use of up to four SIM cards.
- **Integrated Flashlight:** Practical for various daily situations.
- **Loud Speaker:** Ensures clear audio for calls.
- **FM Radio:** For entertainment and news.
- **1700mAh Battery:** Long-lasting power for extended use.
- **USB-C Charging:** Modern and convenient charging port.

4. SETUP

4.1. Installing SIM Cards and Battery

1. **Open the back cover:** Gently slide the metallic back cover to open it.
2. **Insert SIM Cards:** The invens S2000 supports up to four SIM cards. Carefully slide each SIM card into its designated slot. Ensure the gold contacts face downwards.
3. **Insert Battery:** Place the battery into the compartment, aligning the contacts.
4. **Close the back cover:** Replace the back cover and slide it until it clicks into place.

1700mAh Batterie longue durée

Des recharges moins fréquentes, plus de tranquillité d'esprit pour les seniors

1700mAh

Utilisation quotidienne prolongée

1000mAh

Charges plus fréquentes

Moins
de soucis de charge

Fiable
pour les appels quotidiens

Conçu
pour les seniors

Image 4.1: Step-by-step guide for installing up to four SIM cards into the invens S2000 phone.

4.2. Charging the Phone

Connect the provided Type-C USB cable to the charging port on the phone and the other end to a compatible USB power adapter. The battery indicator on the screen will show charging status. Ensure the phone is fully charged before first use.



Image 4.2: The invens S2000 phone connected to a charger via its USB-C port, with earphones also connected to the 3.5mm jack.

4.3. Powering On/Off

- **To Power On:** Press and hold the red 'End Call' button (usually marked with a power icon) until the screen lights up.
- **To Power Off:** Press and hold the red 'End Call' button until the power off options appear on the screen, then confirm.

5. OPERATING INSTRUCTIONS

5.1. Making and Receiving Calls

- **To Dial:** Enter the phone number using the large numeric keypad. Press the green 'Call' button to initiate the call.
- **To Answer:** When the phone rings, open the flip to answer the call automatically (if enabled), or press the green 'Call' button.
- **To End Call:** Close the flip to end the call automatically (if enabled), or press the red 'End Call' button.




Image 5.1: The invens S2000 demonstrating the convenience of answering calls by opening the flip and ending them by closing it.

5.2. SOS Emergency Function

The SOS button provides quick access to pre-set emergency contacts.

1. **Setup:** Before using, ensure emergency contacts are configured in the phone's settings. Refer to the phone's menu for 'SOS Settings'.
2. **Activation:** In an emergency, press and hold the dedicated SOS button (usually located on the back or side of the phone) for 3 seconds.
3. **Action:** The phone will automatically call your pre-registered emergency contacts in sequence until one answers. It may also send an emergency SMS message.

INVENS S2000

Simple. Fiable. Conçu pour vous.

Or Noir

1700mAh

Longue autonomie.
Recharges moins fréquentes.

Écran 2,4 pouces Clair et facile à lire	Mémoire 32 Mo + 32 Mo Jusqu'à 32 Go	Haut-parleur puissant Un son clair à chaque appel
Réseau 2G Appels et SMS fiables	Facile à utiliser Grandes touches. Écran clair.	SOS en un clic Une aide rapide en cas de besoin

Performances fiables
Utilisation fluide et stable au quotidien

Longue autonomie
Plus d'énergie, moins de souci

La sécurité avant tout
La sérénité pour vous et votre famille

Lampe torche intégrée

Prise casque 3,5 mm

Recharge USB-C

Image 5.2: Explanation of the SOS emergency call feature on the invens S2000, showing the button, connection process, and getting help.

5.3. Using the Flashlight

The phone includes a convenient flashlight function.

- **Activation:** Locate the flashlight switch on the side of the phone. Slide the switch to turn the flashlight on.
- **Deactivation:** Slide the switch back to turn the flashlight off.
- *Note: The flashlight can be used even when the phone is powered off, provided the battery has charge.*

Conçu pour le format à clapet.

Pensé pour la simplicité au quotidien.

Un design à clapet familial conçu pour un usage quotidien confortable.

Charnière fluide
Ouverture et fermeture sans effort

Clapet protecteur
Aide à protéger l'écran et les touches

Design à clapet compact
Moins d'appuis involontaires • Facile à transporter

Image 5.3: Illustration of the invens S2000's flashlight, showing its location and the side switch for activation.

5.4. FM Radio

The invens S2000 features a built-in FM radio. To use it, navigate to the 'FM Radio' option in the phone's main menu. You may need to connect headphones (not included) to act as an antenna for better reception.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid overcharging and fully discharging the battery frequently.
- **Protection:** Use the provided protective case to guard against scratches and minor impacts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not power on	Low battery; Battery not inserted correctly; Faulty battery/charger.	Charge the phone for at least 30 minutes. Ensure the battery is correctly inserted. Try a different charger.
Cannot make/receive calls	No SIM card; SIM card not inserted correctly; No network signal; SIM card not activated.	Ensure SIM card(s) are correctly inserted. Check for network signal. Contact your service provider to activate the SIM.
Poor call quality	Weak network signal; Obstructions; Speaker/microphone issues.	Move to an area with better signal. Ensure nothing is blocking the speaker or microphone.
SOS function not working	Emergency contacts not set up; Incorrect numbers; No network signal.	Verify emergency contacts in settings. Ensure numbers are correct and active. Check network signal.
Flashlight not working	Low battery; Switch not fully engaged.	Charge the phone. Ensure the flashlight switch is fully slid to the ON position.

8. SPECIFICATIONS

Feature	Detail
Brand	invens
Model Name	S2000
Operating System	Nucleus OS
Memory Storage Capacity	32 MB
Screen Size	2.4 Inches
Display Type	LCD
Max Display Resolution	300x240 Pixels
Wireless Carrier	All carriers
Cellular Technology	2G
Connectivity Technology	Bluetooth
Color	Gold

Feature	Detail
Number of SIM Card Slots	Quad SIM
Analog RGB Input	3.5 mm Jack
Form Factor	Flip
Product Features	FM Radio, Basic Phone
Model Year	2026
Country of Origin	China
Battery Description	Lithium-polymer
Battery Power	1700 mAh
GPS Geopositioning Feature	False



Image 8.1: Detailed dimensions of the invens S2000 phone in both closed and open states.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your package or contact invens customer service through their official website or the retailer where the product was purchased.

Online Support: Visit the [invens Brand Store](#) for more information and support resources.

© 2026 invens. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why will the SD card not activate on my invens S2000 phone?

If your SD card is not activating or being recognized by your invens S2000 phone, please try the following troubleshooting steps: Check the Card Format: Ensure your micro SD card is formatted to a...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0H5R9QD6F>

More documents and user manuals: <https://manuals.plus/>