

IRONCK HK-BZDSG-09

IRONCK Mid Century Modern TV Stand

MODEL: HK-BZDSG-09

1. Introduction

Thank you for purchasing the IRONCK Mid Century Modern TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The IRONCK Mid Century Modern TV Stand, featuring a black finish, arched grooved doors, and gold-trimmed legs, positioned in a living room with a television mounted above it.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Do not overtighten screws, as this may damage the material.
- Keep small parts away from children during assembly.
- This TV stand is designed to support televisions up to 70 inches. Do not exceed the recommended weight capacity.
- For stability, place the TV stand on a level surface.
- If wall anchoring hardware is provided, it is highly recommended to secure the unit to a wall to prevent tipping.

3. Package Contents

Verify that all components and hardware are included in your package. If any parts are missing or damaged, please contact customer support.

- TV Stand Panels (Top, Bottom, Sides, Back, Shelves, Drawer components, Doors)
- Metal-Trimmed Legs
- Handles and Knobs
- Built-in Power Strip (pre-installed or separate)
- LED Lighting Kit (LED strip, controller, remote)
- Hardware Package (screws, dowels, cam locks, hinges, drawer slides, cable management clips)
- Assembly Instructions (this manual)

4. Setup and Assembly

Assembly typically requires two adults. Tools required (not included): Phillips head screwdriver, hammer.

4.1. Preparation

1. Clear a spacious area for assembly.
2. Lay out all parts and hardware, comparing them against the parts list.
3. Identify each component by its label (if provided).

4.2. Assembly Steps

Follow the step-by-step diagrams provided in the separate assembly guide included with your hardware package. General steps include:

1. Attach cam locks and dowels to the main panels.
2. Assemble the base and side panels.
3. Install shelves and drawer slides.
4. Assemble the drawer and attach handles.
5. Attach hinges to the doors and then to the main unit.
6. Install the Metal-Trimmed Legs to the bottom of the unit. Ensure they are securely fastened.
7. Carefully place the top panel onto the assembled unit.
8. Connect the Built-in Charging Hub and LED Lighting components as per their specific instructions.
9. Utilize the rear cable management holes to organize wires.

Product Dimensions



Image 4.1: Detailed diagram showing the dimensions of the IRONCK TV Stand, including overall measurements (62.9" W x 15.7" D x 21.9" H), internal cabinet spaces, and drawer dimensions.

Metal-Trimmed Legs



Image 4.2: A close-up view of the black tapered legs with gold metal trim, illustrating the design detail and how they connect to the base of the TV stand.

5. Operating Instructions

5.1. Built-In Charging Hub

The TV stand is equipped with a power strip for convenient device charging and power access.

- **Power Connection:** Plug the power cord from the built-in charging hub into a standard wall outlet.
- **AC Outlets:** Use the 4 AC 120V/12A outlets for powering your TV, media players, or other electronics.
- **USB Ports:** The hub includes 1 USB 5V/2A port and 1 Type-C 5V/2A port for charging compatible devices like smartphones and tablets.
- **Cable Management:** Utilize the cable management holes at the rear of the stand to route and organize power cords and media cables, keeping them tidy and out of sight.



Image 5.1: A detailed view of the built-in charging station, showing 4 AC outlets, 1 USB port, and 1 Type-C port, integrated into the TV stand's design for convenient power access.

5.2. Smart LED Lighting

The integrated LED lighting system enhances the ambiance of your living space.

- **Power On/Off:** Use the provided remote control or a compatible phone app to turn the LED lights on or off.
- **Color Selection:** Choose from 7 available colors to match your mood or decor.
- **Brightness Adjustment:** Adjust the brightness level to your preference using the remote or app.
- **App Control:** Download the specified phone application (refer to the LED lighting kit's separate instructions for app details) to access additional customization options and control features.



Image 5.2: The TV stand illuminated with multi-color RGB LED lighting, demonstrating various color options and the effect it creates in a room. The image also shows the remote control and a phone app interface for controlling the lighting.

5.3. Storage Utilization

The TV stand offers various storage options:

- **Cabinets:** Three cabinets provide enclosed storage for media devices, books, or other items.
- **Drawer:** One pull-out drawer is ideal for smaller accessories like remotes, cables, or game controllers.

6. Maintenance

Proper care will ensure the longevity and appearance of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

7. Troubleshooting

If you encounter any issues, refer to the following common solutions:

- **Wobbly Stand:** Ensure all screws are tightened. Check that the stand is on a level surface. Adjust leg levelers if present.
- **Drawer/Door Not Closing Properly:** Check for obstructions. Ensure drawer slides or hinges are correctly installed and aligned. Adjust hinges if necessary.
- **Charging Hub Not Working:** Verify the power cord is securely plugged into both the hub and the wall outlet. Check the wall outlet with another device.
- **LED Lights Not Functioning:** Ensure the LED power adapter is connected and plugged in. Check the remote control battery. Refer to the LED lighting kit's specific troubleshooting guide.
- **Missing Parts:** If parts were missing upon delivery, contact customer support immediately with your purchase details.

8. Specifications

Feature	Detail
Model Number	HK-BZDSG-09
Brand	IRONCK
Color	Black
Material Type	Engineered Wood
Style	Mid-Century
Overall Dimensions (L x W x H)	62.9 x 15.7 x 21.9 inches
Item Weight	82.9 pounds
TV Size Compatibility	Up to 70 inches
Number of Drawers	1
Charging Hub	4 AC Outlets (120V/12A), 1 USB Port (5V/2A), 1 Type-C Port (5V/2A)
LED Lighting	Smart RGB, 7 Colors, Adjustable Brightness (App/Remote Control)
Included Components	Hardware package

Feature	Detail
UPC/GTIN	722385452914

9. Warranty and Support

IRONCK products are designed for quality and durability. For warranty information, missing parts, or technical support, please contact IRONCK customer service through the retailer where the product was purchased or visit the official IRONCK website. Please have your model number (HK-BZDSG-09) and purchase date ready when contacting support.

© 2024 IRONCK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question