

## TARKARI Deck Box

# TARKARI 330 Gallon Outdoor Storage Box Instruction Manual

## INTRODUCTION

Thank you for choosing the TARKARI 330 Gallon Outdoor Storage Box. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage solution. Designed for durability and convenience, this resin deck box offers a spacious, waterproof, and UV-resistant solution for organizing your outdoor essentials.

## SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep children and pets away from the assembly area. Small parts may pose a choking hazard.
- Do not allow children to play inside the storage box to prevent suffocation.
- Ensure the storage box is placed on a flat, stable surface to prevent tipping.
- Do not overload the storage box. Refer to the specifications for maximum weight capacity.
- Exercise caution when opening and closing the lid, especially with hydraulic rods, to avoid pinching fingers.
- This product is designed for outdoor storage. Do not store hazardous materials or flammable liquids inside.

## PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

- Side Panels (Left, Right, Front, Back)
- Bottom Panel
- Lid
- Hydraulic Rods
- Assembly Hardware (screws, connectors, etc.)

## SETUP AND ASSEMBLY

Assembly of the TARKARI 330 Gallon Outdoor Storage Box is designed to be straightforward with intuitive snap-fit parts. For optimal results, a two-person assembly is recommended.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components are present according to the package contents list.
2. **Assemble Side Panels:** Connect the side panels to the front and back panels using the designated snap-fit mechanisms. Ensure all connections are secure.
3. **Attach Bottom Panel:** Secure the bottom panel to the assembled side structure.
4. **Install Hydraulic Rods:** Attach the hydraulic rods to the designated points on the main body and the lid. These rods assist in smooth lid operation. Refer to the detailed diagram for correct orientation.
5. **Attach Lid:** Carefully align and attach the lid to the main body, ensuring the hydraulic rods are properly engaged.



Image: Close-up of hydraulic rod, easy carry handles, and secure storage latch.




Image: Detailed view of the hydraulic rod for labor-saving lid operation.

Video: A short demonstration of opening and closing the TARKARI storage box, showcasing its functionality.

Video: A close-up view of the storage box's interior, demonstrating its capacity and quality.

## OPERATING INSTRUCTIONS

- **Opening the Lid:** Gently lift the lid. The hydraulic rods will assist in opening and holding the lid in an open position.
- **Closing the Lid:** Apply gentle downward pressure on the lid to close it. Ensure both sides close evenly to prevent strain on the hinges. If the lid feels flimsy or requires excessive force, check for obstructions or ensure the box is on a level surface.
- **Locking Mechanism:** The storage box features a lockable design. A padlock (not included) can be inserted through the designated latch for added security.
- **Using as a Bench/Table:** The sturdy lid can support up to 1000 lbs, allowing it to function as an extra seat or

patio side table. Ensure the lid is fully closed and secure before using it for seating.



Image: Storage box with lid open, demonstrating ample storage space for cushions.



Image: Storage box used as a durable and stable extra seat or table.

## MAINTENANCE

To ensure the longevity and appearance of your TARKARI Outdoor Storage Box, follow these maintenance guidelines:

- **Cleaning:** Wipe down the exterior with a soft cloth and mild soap and water. Avoid abrasive cleaners or harsh chemicals, which can damage the resin material. Rinse thoroughly with clean water.
- **UV Protection:** The resin material is UV-resistant, designed to prevent fading and cracking. However, prolonged exposure to extreme sunlight can still affect its appearance over many years. Occasional cleaning helps maintain its protective properties.
- **Waterproofing:** The box is designed to be waterproof. Regularly check the seals and ensure the lid closes properly to maintain its water-resistant properties.
- **Winter Storage:** While durable in various weather conditions, consider storing delicate items indoors during harsh winter months.



Image: Visual representation of the UV-resistant and waterproof capabilities.

## TROUBLESHOOTING

- **Lid does not close smoothly:** Check for any obstructions inside the box or along the lid's edges. Ensure the hydraulic rods are correctly installed and not bent. Verify the box is on a level surface.
- **Lid opens unexpectedly in wind:** While hydraulic rods assist opening, strong winds can sometimes force the lid open. For added security in windy conditions, consider using an external clip or tie to keep the lid firmly shut.
- **Water inside the box:** Ensure the lid is fully closed and properly aligned. Check for any cracks or damage to the resin panels. Verify that the box is not placed in an area where water can pool around its base.
- **Difficulty during assembly:** If you encounter difficulties, refer to the assembly diagrams in the manual. Ensure all parts are correctly oriented before snapping them into place. A second person can often assist in aligning larger panels.

## SPECIFICATIONS

| Feature                     | Detail                                                               |
|-----------------------------|----------------------------------------------------------------------|
| Brand                       | TARKARI                                                              |
| Model Number                | Deck Box                                                             |
| Color                       | Black                                                                |
| Material                    | Resin                                                                |
| Item Dimensions (L x W x H) | 67.72" x 32.20" x 33.66"                                             |
| Storage Volume              | 330 Gallons                                                          |
| Weight Capacity (Lid)       | Max 1000 lbs                                                         |
| Special Features            | Waterproof, UV-Resistant, Lockable (lock not included), Weathertight |
| Closure Type                | Flip Top                                                             |

## WARRANTY INFORMATION

TARKARI products are manufactured to high-quality standards. This product is covered by the manufacturer's standard warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the documentation included with your purchase or contact TARKARI customer support.

## SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact TARKARI customer support. Have your product model number and purchase information ready when you call or email.

For the most up-to-date contact information, please visit the official TARKARI website or refer to your purchase documentation.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**