

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Full Loft Bed with Stairs, Desk, Charging Station, and Wardrobe - Instruction Manual

Bellemave Loft Bed with Stairs

Bellemave Full Loft Bed with Stairs, Desk, Charging Station, and Wardrobe

Instruction Manual

INTRODUCTION

Thank you for choosing the Bellemave Full Loft Bed. This versatile furniture piece is designed to maximize space and functionality in your room, offering a comfortable sleeping area, an integrated desk, a convenient charging station, and ample storage with stairs and a wardrobe. Please read this manual carefully before assembly and use to ensure safe and proper operation.



Image: The Bellemave Full Loft Bed in a room setting, showcasing its integrated desk, stairs, and overall design.

SAFETY INFORMATION

Maximum weight capacity: 550 lbs. Do not exceed this limit.

- Ensure proper assembly and secure all parts to prevent instability or collapse.
- Use anti-tip fittings as recommended during installation to enhance stability.
- Be cautious of moving slats and potential pinch points during assembly and regular use.
- Regularly inspect all connections and hardware to ensure they remain tight and secure.

PRODUCT FEATURES

Integrated Desk, Bedside Shelf, and Pegboard

The loft bed includes a spacious desk area underneath, a convenient bedside shelf, and a pegboard for organizing study materials or personal items. This design creates an efficient workspace or creative zone.



Image: A close-up view of the integrated desk area, showing the pegboard, charging station, and space for a computer setup.

Charging Station and Multicolor LED Lights

Equipped with a built-in charging station featuring 2 AC outlets and 2 USB ports, this bed allows for convenient device charging. A multicolor LED light strip enhances the ambiance and can be adjusted via remote control.



Image: A detailed view of the charging station with AC outlets and USB ports, alongside the LED light strip.

Stairs with Storage and Built-in Wardrobe

The multi-functional staircase provides easy access to the loft bed and doubles as open storage shelves. A built-in wardrobe offers hidden hanging space for clothes, maximizing bedroom efficiency. Note: The location of the stairs cannot be changed.



Image: A view of the integrated stairs with open storage compartments and the adjacent built-in wardrobe.

Noise-Free Design with Buckle Slats

The bed frame is designed with a high-quality silent strip to prevent noise from moving slats. The buckle design slats offer effortless assembly and provide robust support, ensuring a stable and quiet sleeping experience.



Image: A close-up of the buckle design slats, highlighting the secure and noise-free construction of the bed frame.

SPECIFICATIONS

Feature	Detail
Size	Full
Material	Metal
Product Dimensions (L x W x H)	95.28" x 64.69" x 73.62"
Maximum Weight Capacity	550 lbs
Number of Slats	17 pcs + one center support bar
Color	Black
Special Features	Charging Station, Desk, Lights, Stairs, Wardrobe



Image: Detailed diagram showing the dimensions of the Bellemave Full Loft Bed in inches.

SETUP (ASSEMBLY)

Assembly of the Bellemave Full Loft Bed requires careful attention to detail. We recommend two adults for the assembly process to ensure safety and efficiency.

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list provided in your separate assembly guide. Ensure all pieces are present and undamaged.
2. **Prepare Workspace:** Clear a spacious area for assembly, preferably near the final placement of the bed.
3. **Follow Instructions:** Refer to the detailed step-by-step assembly instructions included in your product packaging. Pay close attention to diagrams and warnings.
4. **Secure Connections:** Tighten all screws and bolts firmly, but do not overtighten until instructed. Ensure all connections are secure before proceeding to the next step.
5. **Install Anti-Tip Fittings:** For enhanced stability and safety, install the provided anti-tip fittings as directed in the assembly guide.
6. **Slat Installation:** The bed features a snap-in slat design for easy installation. Ensure each slat is securely snapped into place to provide proper mattress support and prevent noise.

Always keep children and pets away from the assembly area.

OPERATING INSTRUCTIONS

Using the Charging Station

The integrated charging station provides convenient power access. Simply plug the bed's power cord into a standard wall outlet. You can then use the 2 AC outlets for larger electronics and the 2 USB ports for charging mobile devices.

Controlling the LED Light Strip

The multicolor LED light strip can be controlled using the provided remote control. Point the remote at the receiver (usually located near the light strip or charging station) to:

- Turn the lights On/Off.
- Change light colors.
- Adjust brightness levels.
- Select various lighting modes (if available).

Ensure the remote control has working batteries and an unobstructed line of sight to the receiver.

MAINTENANCE

- **Cleaning:** Wipe down metal and wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they are tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Ensure weight is evenly distributed on the bed and shelves to prevent stress on the frame.
- **Electrical Components:** Keep the charging station and LED light strip free from dust. Do not attempt to repair electrical components yourself; contact qualified personnel if issues arise.

TROUBLESHOOTING

- **Bed is Wobbly:**
 - Check all bolts and screws to ensure they are fully tightened.
 - Verify that the anti-tip fittings are correctly installed and secured to the wall.
 - Ensure the bed is on a level surface.
- **Squeaking Noises:**
 - Retighten all hardware.
 - Ensure all buckle design slats are properly seated and secured. The silent strip should minimize noise, but loose connections can still cause squeaks.
- **Charging Station Not Working:**
 - Check if the bed's main power cord is securely plugged into a functional wall outlet.
 - Test the wall outlet with another device to confirm it has power.
 - Ensure devices are properly plugged into the AC outlets or USB ports.
- **LED Lights Not Responding:**
 - Check the remote control batteries and replace if necessary.
 - Ensure there is a clear line of sight between the remote and the light strip's receiver.
 - Verify the bed's main power cord is plugged in.

WARRANTY

Specific warranty details for your Bellemave Full Loft Bed are typically provided with your purchase documentation or on the product listing page. Please refer to these resources for information regarding coverage, duration, and claims procedures. Keep your proof of purchase for any warranty claims.

SUPPORT

Should you encounter any issues or have questions regarding your Bellemave Full Loft Bed, please do not hesitate to contact our customer support team.

Email: US-VC@bellemavehome.com

When contacting support, please provide your product model number (Loft Bed with Stairs) and a detailed description of your issue to help us assist you more efficiently.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question