

Ytaoeo 8-10P

Ytaoeo Inflatable Tent 8-10 Person Instruction Manual

Model: 8-10P

1. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before setting up and using your Ytaoeo Inflatable Tent. Failure to follow these instructions may result in injury or damage to the product.

- **Fire Safety:** Keep all flame and heat sources away from tent fabric. The tent is made of flame-resistant fabric, but it is not fireproof.
- **Ventilation:** Ensure adequate ventilation, especially when using heating devices or cooking inside the tent. Carbon monoxide can be deadly.
- **Stove Jack Use:** If using a wood stove with the stove jack, ensure the stove pipe is properly installed and secured. Use only approved stoves and follow their safety guidelines. Never leave a burning stove unattended.
- **Weather Conditions:** Do not set up the tent under trees with dead branches. Avoid pitching the tent in areas prone to flash floods or strong winds without proper anchoring.
- **Anchoring:** Always use all provided stakes and guy ropes to secure the tent firmly to the ground, especially in windy conditions.
- **Children:** Keep children away from the tent during setup and takedown. Do not allow children to play with the air pump or tent components unsupervised.

2. PACKAGE CONTENTS

Verify that all components are present before beginning setup:

- 1 x Inflatable Tent (8-10 Person)
- 1 x Divided Curtain
- 4 x Guy Ropes
- 1 x Air Pump (Hand Pump)
- Stakes
- 1 x Tent Storage Bag

3. SETUP INSTRUCTIONS

Follow these steps for quick and easy tent setup:

1. **Step 1: Prepare the Area.** Choose a flat, clear area for your tent. Remove any sharp objects or debris that could damage the tent fabric.
2. **Step 2: Lay Out the Tent.** Unpack the tent from its storage bag and lay it flat on the ground. Ensure the tent is spread out completely.



Image: The inflatable tent laid out flat on a grassy area, ready for inflation.

3. **Step 3: Secure Corners.** Secure the four corners of the tent to the ground using the provided stakes. This prevents the tent from shifting during inflation.
4. **Step 4: Inflate the Air Beams.** Locate the air valve on the tent. Connect the hose from the included hand pump to the valve. Begin pumping air into the tent until the air beams are firm and the tent stands upright. The recommended inflation pressure is 7 PSI. The tent features a 2-in-1 upgraded air valve for easy inflation from the top and deflation from the bottom. Do not unscrew the automatic pressure release valve.

Divided Curtain for Privacy



Image: A person using a hand pump to inflate the tent's air beams, causing the tent structure to rise.

5. **Step 5: Secure with Guy Ropes.** Once inflated, secure the tent further using the guy ropes and additional stakes. This provides stability against wind.

Your browser does not support the video tag.

Video: A demonstration of securing the tent with stakes and guy ropes, followed by the installation of a stove pipe through the stove jack. This video illustrates key setup and feature utilization steps.

4. OPERATING THE TENT

Your Ytaoeo Inflatable Tent is designed for comfort and versatility.

4.1 Ventilation

The tent features a dual-door design and four large mesh windows to ensure excellent airflow and protection from insects. For optimal ventilation, open multiple windows and doors as needed. Note that the solid window coverings are on the exterior, requiring you to go outside to adjust them.

Mesh Doors & Windows

Excellent Ventilation



UV Proof



Water Proof



Ventilation


Image: The tent exterior showing mesh windows open, with blue arrows indicating airflow for ventilation.

4.2 Stove Jack and AC Port

The tent includes a dedicated stove jack for safe use of a wood stove and an AC port for portable air conditioning units. Always ensure proper installation and ventilation when using these features.



Stove Jack



AC Port

Image: Interior of the tent highlighting the stove jack opening with a stove pipe installed and an AC port for climate control.

4.3 Spacious Interior and Divided Curtain

With a 13ft x 9ft footprint and 6.5ft center height, the tent offers ample space. A divided curtain is included to create two separate rooms for privacy.

117 sq ft Spacious Space 2 Rooms Design



Image: Interior view of the tent demonstrating the spacious 117 sq ft area and the option for a divided curtain to create two rooms.

4.4 Skylight for Stargazing

The tent features a large PVC skylight, allowing for natural light during the day and stargazing at night.

Large PVC Skylight for Stargazing



Image: Interior view of the tent highlighting the large PVC skylight for stargazing.

5. MAINTENANCE

Proper maintenance will extend the life of your tent.

- **Cleaning:** Clean the tent with a soft brush or sponge and mild soap. Do not use harsh detergents or bleach. Rinse thoroughly with water.
- **Drying:** Always ensure the tent is completely dry before packing it away to prevent mildew and odors. Air dry in a shaded area.
- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Air Beam Care:** Avoid over-inflating the air beams. Inspect the air valves periodically for any damage or leaks.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Tent Not Inflating Properly:**
 - Check that the air valve is securely closed and not leaking.
 - Ensure there are no twists or kinks in the internal air beams.
 - Verify the pump hose is properly connected to the valve.
- **Water Leaks:**
 - Ensure all zippers are fully closed.
 - Check for any small punctures or tears in the fabric. Repair with a tent repair kit if necessary.
 - Confirm that guy ropes are taut and the tent is pitched correctly to allow water runoff.
- **Excessive Condensation:**
 - Increase ventilation by opening windows and doors.
 - Avoid cooking or using unvented heaters inside the tent.
- **Tent Instability in Wind:**
 - Ensure all stakes are fully driven into the ground.
 - Tighten all guy ropes.
 - Consider using heavier-duty stakes in very soft or sandy soil.

7. SPECIFICATIONS

Feature	Detail
Brand	Ytaoeo
Model	8-10P
Product Dimensions (L x W x H)	156"L x 106"W x 79"H
Floor Area	117 square feet
Occupancy	8-10 Person
Seasons	4 Season
Material Type	Oxford Fabric
Water Resistance Technology	PU3000mm
Special Features	Easy Setup, Inflatable, UV Protection, Ventilation, Waterproof, Stove Jack, AC Port
Included Components	Tent, Divided Curtain, Guy Ropes, Air Pump, Stakes, Storage Bag

8. WARRANTY AND SUPPORT

For warranty information or product support, please contact Ytaoeo customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question