Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee PHK_34UR

Garvee 7 Drawer Dresser (Model PHK_34UR) Instruction Manual

Model: PHK_34UR | Brand: Garvee

1. Introduction

Thank you for choosing the Garvee 7 Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new dresser. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The Garvee 7 Drawer Dresser in Oak finish, showcasing its modern design and handle-free drawers.

2. Safety Information

WARNING: Furniture tipping hazard. Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always install the anti-tipping device provided with the dresser.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Place heaviest items in the lowest drawers.
- Do not open more than one drawer at a time.

Regularly check all connections and fasteners to ensure they remain tight and secure.



Image 2.1: Illustration of the anti-tipping device installation and a visual warning against furniture tip-over, emphasizing child safety.



Image 2.2: Close-up view of the metal bracket for the anti-tipping device, designed to secure the dresser to a wall.

3. Package Contents

Before assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact

customer support.

- Dresser panels (top, bottom, sides, back, drawer fronts, drawer sides, drawer backs, drawer bottoms)
- Drawer slides (metal)
- Hardware kit (screws, dowels, cam locks, anti-tipping device)
- Assembly instructions manual

4. Setup and Assembly

Assembly is designed to be straightforward. It is recommended to have two people for assembly. A Phillips head screwdriver and a hammer may be required (not included).

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in the included assembly guide to identify each piece.
2. **Assemble the Main Frame:** Follow the step-by-step diagrams in the separate assembly guide to construct the dresser's main frame. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the dresser frame and the drawer sides as indicated in the instructions. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawers:** Construct each of the 7 drawers. Insert the drawer bottoms into the grooves and secure the drawer fronts and backs.
5. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame.
6. **Install Anti-Tipping Device:** This is a critical safety step. Securely attach the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. Refer to Image 2.1 and 2.2 for guidance.



Image 4.1: Detail of the metal drawer slides, illustrating their mechanism for smooth drawer operation.

5. Operating Instructions

The Garvee 7 Drawer Dresser is designed for convenient storage. Its handle-free design provides a sleek, modern aesthetic.

- **Opening Drawers:** Gently pull the top edge of the drawer front to open.
- **Closing Drawers:** Push the drawer firmly until it is fully closed and flush with the dresser frame.
- **Weight Distribution:** Distribute weight evenly across drawers. Place heavier items in lower drawers to maintain stability.



Image 5.1: The dresser with several drawers open, demonstrating the ample storage space available for various items.



Image 5.2: An overhead view of the dresser with drawers organized, highlighting its capacity for storing blouses, hats, socks, pants, toys, and tissues.

6. Maintenance

Proper care will ensure the longevity and appearance of your Garvee dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage, especially on the waterproof tabletop.
- **Drawer Slides:** If drawers become stiff, apply a small amount of silicone lubricant to the metal slides.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood finish.
- **Stability Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary.



Image 6.1: Features of the dresser including large capacity drawers, a waterproof tabletop, smooth gliding drawers, and a stable overall structure.

7. Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or debris in tracks.	Check alignment of slides; clean tracks. Apply silicone lubricant if needed.
Dresser feels wobbly.	Loose fasteners or uneven floor.	Tighten all assembly screws. Ensure dresser is on a level surface; use shims if necessary. Verify anti-tipping device is securely installed.
Drawer does not close flush.	Obstruction or misaligned drawer front.	Check for items blocking the drawer. Re-check drawer assembly and slide alignment.

8. Specifications

Brand	Garvee
Model Number	PHK_34UR
Material	Engineered Wood
Finish Type	Painted
Product Dimensions (D x W x H)	15.6"D x 53.1"W x 32.1"H
Number of Drawers	7
Item Weight	126.3 pounds
Color	Oak
GTIN	881206111512



Image 8.1: Detailed dimensions of the Garvee 7 Drawer Dresser, including overall size and individual drawer measurements.

9. Warranty and Support

For warranty information, please refer to the specific terms provided at the time of purchase or contact the retailer. Garvee is committed to customer satisfaction.

If you encounter any issues or have questions regarding your Garvee 7 Drawer Dresser, please contact Garvee customer support through the official Garvee store on Amazon: Garvee Store.

© 2026 Garvee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H7C2BRNN

More documents and user manuals: **https://manuals.plus/**