Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FURYCUBE ZY800032

FURYCUBE IP108 Lipstick Keyboard User Manual

Model: ZY800032

1. Introduction

This manual provides instructions for the FURYCUBE IP108 Lipstick Keyboard. This 108-key wired RGB backlit keyboard features a full-size layout with a dedicated number pad, function row, and navigation cluster. It is designed for use with Windows and macOS computers, offering plug-and-play operation via a USB-C connection. The keyboard incorporates dual-layer ABS and clear PC keycaps that diffuse 14 preset RGB lighting modes and are designed for durability and comfortable typing.

The unique dual-layer molded keycaps combine a colored ABS inner keycap with a frosted transparent PC outer layer. This design diffuses RGB light around each key, protects the colored surface, and creates a distinct aesthetic. Cushioned membrane keys contribute to reduced typing noise.



Image 1.1: Overview of the FURYCUBE IP108 Lipstick Keyboard highlighting its design and features.

2. Package Contents

Please check the package contents to ensure all items are present:

- FURYCUBE IP108 Lipstick Keyboard
- 1.5 m USB-C Cable
- User Manual (this document)

3. Setup

3.1 Connecting the Keyboard

1. Locate the USB-C port on the FURYCUBE IP108 Keyboard.
2. Connect one end of the included 1.5 m USB-C cable to the keyboard's USB-C port.

3. Connect the other end of the USB-C cable to an available USB port on your Windows or macOS computer.
4. The keyboard is plug-and-play and should be recognized automatically by your operating system. No additional drivers are typically required.

3.2 Adjusting Typing Angle

The keyboard features two-stage adjustable feet on its underside. Gently flip out these feet to raise the rear of the keyboard, allowing for a more ergonomic typing angle. You can choose between two different angles or keep the keyboard flat.



Image 3.1: Adjustable feet for customizing the keyboard's typing angle.

4. Operating Instructions

4.1 RGB Lighting Effects

The FURYCUBE IP108 Keyboard features 14 preset RGB lighting effects. These effects illuminate the transparent PC

keycap layer.

- To cycle through the different lighting effects, press the **Fn** key simultaneously with the **Ins** (Insert) key.
- The lighting effects are preset and cannot be customized or programmed.



Image 4.1: RGB lighting effects on the keyboard.

4.2 Anti-Ghosting

The keyboard supports 25-key anti-ghosting. This feature ensures that multiple key presses are registered accurately, which is beneficial for fast typing, office work, and casual gaming where specific multi-key combinations are used.

4.3 Keycap Design

The keycaps are designed with a dual-layer construction: a colored ABS inner layer and a frosted transparent PC outer layer. This design provides a unique aesthetic and helps protect the keycap legends from wear. The rounded key surfaces are shaped to conform to fingertips for a comfortable typing experience.



Image 4.2: Frosted jelly double-layer keycaps.

5. Maintenance

5.1 Cleaning the Keyboard

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution to wipe the keycaps and keyboard surface.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the keyboard's finish and keycap legends.
- For dust and debris between keys, use compressed air or a small brush.
- Ensure the keyboard is completely dry before reconnecting it to your computer.

6. Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	• Loose USB-C cable connection. • Faulty USB port on computer. • Operating system issue.	• Ensure the USB-C cable is securely connected to both the keyboard and the computer. • Try connecting the keyboard to a different USB port on your computer. • Restart your computer. • Test the keyboard on another computer if possible.
RGB lighting not working	• Lighting effect turned off or set to a dim mode. • Keyboard not receiving sufficient power (unlikely for wired).	• Press **Fn + Ins** repeatedly to cycle through all lighting effects. • Ensure the keyboard is properly connected to a functioning USB port.
Keys are sticky or unresponsive	• Debris under keycaps. • Liquid spill.	• Clean the keyboard as described in the Maintenance section. • If a liquid spill occurred, disconnect immediately and allow to dry completely before attempting to use again. Professional repair may be necessary.

7. Specifications

Feature	Detail
Brand	FURYCUBE
Model Number	ZY800032
Connectivity Technology	USB-C (Wired)
Keyboard Description	Membrane
Number of Keys	108
Keyboard Layout	QWERTY
Keycap Material	ABS (inner), Polycarbonate (outer)
Special Features	Anti-Ghosting (25-key), RGB Backlit (14 preset effects), Silent (cushioned membrane keys)
Compatible Operating Systems	Windows, macOS
Cable Length	1.5 m
Dimensions (L x W x H)	17.58 x 5.64 x 1.55 inches

8. Warranty and Support

8.1 Warranty Information

The FURYCUBE IP108 Lipstick Keyboard comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your FURYCUBE IP108 Lipstick Keyboard, please contact FURYCUBE customer support. Refer to the product packaging or the official FURYCUBE website for the most

current contact information.

© 2026 FURYCUBE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H8GY1PVJ

More documents and user manuals: **https://manuals.plus/**