

[Manuals.plus](#) /

› [HAOYUYAN](#) /

› HAOYUYAN BX17 Wireless Earbuds User Manual

HAOYUYAN BX17

HAOYUYAN BX17 Wireless Earbuds User Manual

Model: BX17

INTRODUCTION

The HAOYUYAN BX17 Wireless Earbuds are engineered for an active lifestyle, offering a secure fit, IPX7 waterproofing, and immersive audio. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX

- HAOYUYAN BX17 Wireless Earbuds (L/R)
- Charging Case
- USB-C Charging Cable
- Silicone Ear Tips (Small, Medium, Large)

PRODUCT OVERVIEW

80 Hours Long Battery Life

Enjoy longer music time with charging case



1.5hrs
Fast Charging



15hrs
Single Charge



60hrs
Charging case



Type-c

The charging case provides up to 80 hours of total playtime. Each earbud offers 15 hours on a single charge, with the case providing an additional 60 hours. The case recharges quickly via its Type-C port.

Hi-Fi stereo Sound


Equipped with a 14.2mm Graphene Diaphragm



Equipped with powerful 14.3mm dynamic drivers and an advanced acoustic design, the BX17 headsets deliver rich bass and clear treble for an immersive stereo sound experience.




Features Bluetooth 5.3 technology for a stable, fast, and one-step pairing process with your compatible devices.



Designed with elastic soft ear hooks and three sizes of ear tips (S/M/L) for a secure and comfortable fit during sports and workouts. IPX7 waterproof rating protects against sweat and rain.

Easy Control, Physical Buttons

Light Click of Your Fingertips to Play Music or Answer Calls



Intuitive physical buttons allow seamless management of audio playback, volume adjustment, and call handling with simple taps or long presses.

LED Power Digital Display

Easily Check The Remaining Battery and Charging Status at Any Time



The charging case features a dual digital power display, allowing you to easily check the remaining battery life of both the case and individual earbuds in real-time.

SETUP

1. Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up to confirm charging.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included).
3. The LED digital display on the case will show the charging status. A full charge is indicated when the display shows 100% for the case and the earbud indicators turn off.

2. Initial Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode. The LED indicator on one earbud will flash, indicating it is ready to pair.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "BX17" in the list of available Bluetooth devices and select it to connect.
4. Once connected, a voice prompt will confirm successful pairing, and the earbud LED indicators will turn off.

3. Re-pairing / Single Earbud Use

- The earbuds will automatically reconnect to the last paired device when taken out of the case.
- Either earbud can be used independently. Simply take one earbud out of the case, and it will automatically connect to your device if previously paired.

OPERATING INSTRUCTIONS

Button Controls

Function	Action (Left/Right Earbud)
Power On	Open charging case (Automatic)
Power Off	Place earbuds in charging case and close lid (Automatic)
Play/Pause	One tap (R/L)
Next Track	Long press (R)
Previous Track	Long press (L)
Volume Up	One tap + (R)
Volume Down	One tap - (L)
Answer/End Call	One tap (R/L)
Reject Call	Long press (R/L)
Activate Voice Assistant	Long press (R/L)

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds, ear tips, and charging contacts with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. However, the charging case is not waterproof. Ensure earbuds are completely dry before placing them back in the charging case to prevent damage.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device	◦ Ensure earbuds are charged and out of the case. ◦ Turn off and on Bluetooth on your device. ◦ Forget "BX17" from your device's Bluetooth list and re-pair. ◦ Try pairing with another device to rule out device-specific issues.
Only one earbud working	◦ Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out together. ◦ Ensure both earbuds are charged. ◦ Reset the earbuds (refer to manufacturer's specific reset instructions if available, otherwise try forgetting device and re-pairing).
Earbuds not charging	◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different USB-C cable and power adapter.
Low volume or poor sound quality	◦ Adjust the volume on both your device and the earbuds. ◦ Ensure ear tips are properly sealed in your ear canal. Try different sized ear tips. ◦ Clean any earwax or debris from the earbud speaker mesh. ◦ Ensure there are no obstructions between your device and the earbuds.

SPECIFICATIONS

- **Brand:** HAOYUYAN
- **Model:** BX17
- **Ear Placement:** In Ear
- **Form Factor:** Over Ear (with ear hooks)
- **Noise Control:** Environmental Noise Cancellation (Passive)
- **Connectivity:** Wireless (Bluetooth 5.3)
- **Water Resistance:** IPX7 (Earbuds only)
- **Earbud Playtime:** Up to 15 hours per charge
- **Total Playtime (with case):** Up to 80 hours
- **Driver Size:** 14.3mm Dynamic Driver
- **Charging Port:** USB Type-C

OFFICIAL PRODUCT VIDEO

This official product video demonstrates the key features and usage of the HAOYUYAN BX17 Wireless Earbuds, including their design, fit, and controls.

WARRANTY AND SUPPORT

Warranty Information

The HAOYUYAN BX17 Wireless Earbuds come with a **90-day warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact HAOYUYAN-US customer support. Refer to your purchase platform or product packaging for specific contact details.

© 2026 HAOYUYAN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question