

[Manuals.plus](#) /

› [SILLAID](#) /

› SILLAID GW20 Golf GPS Watch Instruction Manual

SILLAID GW20

SILLAID GW20 Golf GPS Watch Instruction Manual

Model: GW20

INTRODUCTION

This instruction manual provides comprehensive guidance for the SILLAID GW20 Golf GPS Watch. It covers essential information regarding product setup, operational procedures, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using your device.



Image: The SILLAID GW20 Golf GPS Watch displayed on a golf course, highlighting its primary use.

WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- SILLAID Golf GPS Watch (Main Unit)
- Charging Cable
- Instruction Manual
- APP User Manual
- Quick-Start Card



Image: All items included in the SILLAID GW20 Golf GPS Watch package.

PRODUCT OVERVIEW

Display and Design

The SILLAID GW20 features a 1.43-inch AMOLED touchscreen display with a 466x466 resolution and 60Hz refresh rate. This display provides clear and vibrant visuals, ensuring readability even in bright sunlight. The watch is designed to be lightweight, weighing approximately 49g, for comfortable wear during extended periods.



Image: The watch display showing distances to the green and a course map.

Key Features

- **Preloaded Courses:** Over 40,000 global golf courses are preloaded, requiring no subscription fees.
- **Multi-Satellite Positioning:** Supports GPS, Beidou, Galileo, and GLONASS for stable and accurate positioning.
- **Precise Distance Measuring:** Provides distances to the front, middle, and back of the green, along with up to 6 hazard distances.
- **Slope Mode:** Offers the ability to toggle between true distance and plays-like distance with slope compensation.
- **Shot Tracking:** Manual shot distance tracking to record performance.
- **App Synchronization:** Syncs with the free SILL AID GOLF app for score and data analysis.
- **Health Monitoring:** Built-in heart rate, blood oxygen (SpO2), and fitness tracking (steps, calories).
- **Long Battery Life:** Up to 8+ hours in GPS mode and 12+ days in standby mode.



Image: Overview of the SILLAID GW20's comprehensive golf features.

SETUP

1. Charging the Device

Before initial use, fully charge your SILLAID GW20 Golf GPS Watch. Connect the provided charging cable to the watch and a USB power source. A full charge typically takes approximately 1 hour. The watch can operate for up to 8 hours in GPS mode and 12 days in standby mode on a single charge.



Image: The watch indicating its battery status and long endurance.

2. Power On/Off

- **To Power On:** Press and hold the power button (usually located on the side of the watch) until the SILL AID logo appears.
- **To Power Off:** Press and hold the power button, then select 'Power Off' from the options on the screen.

3. App Synchronization

Download the free SILL AID GOLF app from your smartphone's app store. Follow the in-app instructions to pair your watch via Bluetooth. The app allows you to store scores, track stats, and analyze game data for continuous skill improvement.

		
	GW20	
Display	1.43-inch AMOLED	1.4-inch MIP
Touch Control	✓	✓
Slope Mode	✓	✓
FCB Function	✓	✓
Green View	✓	✓
Green View Switching	✓	✗
3 Score Type Tracking	✓	✗
3-Point Distance Measurement	✓	✗
Smartphone Connectivity	✓	✓

Image: The SILLAID GOLF app on a smartphone, showing golf statistics.

4. Course Recognition

The SILLAID GW20 automatically recognizes nearby golf courses using its multi-satellite positioning system (GPS, Beidou, Galileo, GLONASS). No manual setup or course searching is typically required. Ensure you are in an open area for optimal satellite signal acquisition.

What's in the Box

Main Unit	*1
Instruction Manual	*1
APP User Manual	*1
Charging Cable	*1



Image: Representation of global course coverage and satellite positioning.

OPERATING INSTRUCTIONS

1. Basic Navigation

The GW20 features a touchscreen display for intuitive navigation. Swipe left, right, up, or down to access different menus and functions. Tap to select options and use the physical buttons for quick access to specific features or to return to the previous screen.

2. GPS Golf Mode

Once a course is recognized, the watch will display key distances. The screen shows distances to the front, center, and back of the green. You can also view up to 6 key hazards, such as bunkers and water hazards, to assist with shot planning.



Image: The watch showing precise distances to the green.

3. Slope Mode

The GW20 includes a slope mode feature. This allows you to toggle between the true distance and a 'plays-like' distance, which accounts for elevation changes on the course. This feature can be enabled or disabled based on tournament rules or personal preference.



Image: The watch demonstrating slope compensation for accurate shot planning.

4. Shot Tracking

To track your shot distances, use the manual shot distance tracking function. After hitting a shot, mark your position on the watch, walk to your ball, and the watch will record the distance. This data can be used to optimize club selection and improve your game over time.



Image: The watch showing the interface for manual shot distance tracking.

5. Health Monitoring

The GW20 includes sensors for health monitoring. You can track your heart rate, blood oxygen (SpO2) levels, steps taken, and calories burned. Access these features through the watch's health monitoring menu. These functions are for informational purposes and not intended for medical use.



Image: The watch displaying various health monitoring metrics.

MAINTENANCE

1. Cleaning

Regularly clean your watch to maintain its appearance and functionality. Use a soft, damp cloth to wipe the screen and watch body. Avoid using harsh chemicals or abrasive materials that could damage the device. Ensure the charging contacts are clean and dry before charging.

2. Battery Care

To prolong battery life, avoid exposing the watch to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods. If storing the watch for a long time, charge it to approximately 50% before storage.

TROUBLESHOOTING

1. Watch Not Powering On

- Ensure the watch is fully charged. Connect it to the charging cable and a power source for at least 30 minutes.
- Try performing a soft reset by pressing and holding the power button for 10-15 seconds.

2. GPS Signal Issues / Course Not Found

- Ensure you are in an open outdoor area with a clear view of the sky.
- Wait a few minutes for the watch to acquire satellite signals.
- Verify that the watch's software is up to date via the SILLAID GOLF app.

3. App Synchronization Problems

- Ensure Bluetooth is enabled on your smartphone and the watch.
- Restart both the watch and the smartphone.
- Try unpairing and re-pairing the watch through the SILLAID GOLF app's settings.
- Check for updates for the SILLAID GOLF app.

4. Inaccurate Distances

- Ensure the watch has a strong GPS signal.
- Confirm that the correct course and hole are selected on the watch.
- Calibrate the GPS if an option is available in the watch settings (refer to the APP User Manual for advanced settings).

SPECIFICATIONS

Below are the technical specifications for the SILLAID GW20 Golf GPS Watch:

Feature	Detail
Brand	SILLAID
Model Number	GW20
Screen Size	1.43 inches
Display Type	AMOLED Touchscreen

Feature	Detail
Connectivity Technology	Bluetooth
Supported Satellite Systems	BeiDou, GLONASS, GPS, Galileo
Preloaded Courses	40,000+ Worldwide
Battery Life (GPS Mode)	Up to 8+ hours
Battery Life (Standby)	Up to 12+ days
Charging Time	Approx. 1 hour
Product Dimensions	3.8"L x 3.7"W x 2.6"H
Weight	Approx. 49g
Human Interface Input	Touchscreen
Health Monitoring	Heart Rate, Blood Oxygen (SpO2), Fitness Tracking



Image: Feature comparison of the GW20 model.

WARRANTY INFORMATION

The SILLAID GW20 Golf GPS Watch comes with a 2-year warranty. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your product packaging or contact SILLAID customer support.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact SILLAID customer support. Contact information can typically be found on the SILLAID website or in the APP User Manual provided with your device.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question