Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka Forbes GVCDFSCFS00000

Eureka Forbes SmartClean Fully Automatic Cleaning Blitz Robotic Vacuum User Manual

Model: GVCDFSCFS00000

1. Introduction

Thank you for choosing the Eureka Forbes SmartClean Fully Automatic Cleaning Blitz Robotic Vacuum. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new robotic vacuum cleaner. Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This appliance is for indoor household use only.

- Do not allow children to play with the appliance.
- Ensure the power cord is not damaged. If damaged, contact customer support.
- Do not use the appliance in wet environments or near flammable materials.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Only use attachments recommended by the manufacturer.
- Do not pick up hard or sharp objects, liquids, or burning/smoking materials.
- Always turn off the appliance before cleaning or maintenance.

3. Package Contents

Verify that all items are present in the package:

- Robotic Vacuum Cleaner
- Fully Automatic Cleaning Station
- Battery (pre-installed)
- Charging Adapter
- Dirt Disposal Bag (pre-installed in station)
- Filter (pre-installed)
- Side Brush (set)
- User Manual

4. Product Overview

The Eureka Forbes SmartClean Blitz is an advanced robotic vacuum with a fully automatic cleaning station designed for comprehensive floor care.



The robotic vacuum and its fully automatic cleaning station, highlighting the dirty water tank, clean water tank, auto mop washing, and auto dust emptying features.



The automatic dust emptying system, providing up to 75 days of hands-free cleaning.

Key Features:

- **Fully Automatic Cleaning Station:** Features auto dust disposal, automatic mop washing with clean water, dirty water collection, and 45°C hot air drying for mops.
- **LiDAR Navigation:** Utilizes DToF and Line Laser technology for 360° real-time mapping and precise navigation, detecting objects as small as 40mm.
- **18,000Pa HyperSuction:** Powerful suction in Max Mode for effective removal of dust, debris, and pet hair. Includes Auto Suction Boost for carpets.
- **Advanced Deep Mopping:** Dual spinning mop heads with steady downward pressure replicate hand-mopping. Smart Mop Lifting (10mm on carpets) and Mop Extend Technology for edge cleaning.

- **Long Battery Life:** 5200mAh battery provides up to 4 hours of cleaning in Quiet Mode.
- **Anti-Tangle Hair Design:** Specially designed main roller brush to reduce hair tangling.
- **Forbes GermGuard Compatibility:** Use with Forbes GermGuard Cleaning Liquid for germ elimination and a refreshing fragrance.
- **Smart App & Voice Control:** Control via Smart Life App, Amazon Alexa, and Google Assistant.
- **HEPA Filtration:** Captures fine dust, allergens, and particles for cleaner indoor air.

5. Setup

Follow these steps to set up your robotic vacuum cleaner for the first time.

5.1 Unpacking and Placement

1. Carefully remove all components from the packaging.
2. Choose a suitable location for the Fully Automatic Cleaning Station. Ensure it is against a wall, with at least 0.5 meters of clear space on either side and 1.5 meters in front for the robot to dock properly.
3. Plug the charging adapter into the cleaning station and then into a power outlet. Ensure the station is powered on.

5.2 Initial Charging

Place the robotic vacuum onto the charging station. The robot will automatically align and begin charging. For first-time use, allow the robot to charge completely (approximately 4-6 hours) before operation.

5.3 App Connection (Smart Life App)

1. Download the **Smart Life App** from your smartphone's app store.
2. Register or log in to your account.
3. Follow the in-app instructions to add your Eureka Forbes SmartClean Blitz. This typically involves putting the robot into pairing mode (refer to the robot's indicator lights for status) and connecting it to your home Wi-Fi network.
4. Once connected, the app will guide you through initial mapping of your home. The LiDAR system can map your home in approximately 5 minutes.

Virtual Demo: A complimentary virtual demo is available after purchase to guide you through setup, cleaning modes, app controls, and maintenance. Contact customer support to schedule your demo.

6. Operating Instructions

Learn how to operate your robotic vacuum cleaner for optimal cleaning performance.

6.1 Before Cleaning

- Clear the floor of any small objects, cables, or obstacles that could entangle the robot.
- Ensure the clean water tank in the cleaning station is filled and the dirty water tank is empty.
- For mopping, ensure the mop pads are attached and moistened.

6.2 Starting a Cleaning Cycle

You can start a cleaning cycle using the robot's physical buttons, the Smart Life App, or voice commands.

- **Robot Buttons:** Press the power button on the robot to start or pause cleaning. Press the home button to send the robot back to the charging station.
- **Smart Life App:** Use the app to start/stop cleaning, select specific rooms, set no-go zones, adjust suction power (Quiet, Standard, Strong, Max), and customize mop settings.
- **Voice Control:** Integrate with Amazon Alexa or Google Assistant for hands-free control. (e.g., "Alexa, start cleaning with SmartClean Blitz").



The robotic vacuum's powerful 18,000 Pa HyperSuction for deep cleaning.



Edge cleaning capability with Mop Extension Technology.



GermFree wet mopping action with dual spinning pads.

Next-Gen LiDAR Navigation powered by DToF and Line Laser for precise mapping.

6.3 Mopping Function

The robot performs advanced deep mopping. For best results and germ elimination, use only Forbes GermGuard Cleaning Liquid in the clean water tank. The robot will automatically lift mops by 10mm when detecting carpets.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your robotic vacuum.

7.1 Cleaning Station Maintenance


- **Empty Dirty Water Tank:** Periodically empty the dirty water tank.
- **Refill Clean Water Tank:** Ensure the clean water tank is filled before each mopping cycle.
- **Replace Dust Bag:** The auto dust disposal system uses a dust bag that lasts up to 75 days. Replace it when full.
- **Clean Mop Washing Tray:** Regularly clean the mop washing tray to prevent residue buildup.

7.2 Robotic Vacuum Maintenance

- **Clean Main Roller Brush:** The anti-tangle design reduces hair tangling, but regular inspection and cleaning are recommended. Remove any wrapped hair or debris.
- **Clean Side Brushes:** Check side brushes for wear and tear, and remove any tangled hair or debris. Replace if damaged.
- **Clean Mop Pads:** Remove and wash mop pads after each mopping cycle. Replace worn-out pads.
- **Clean HEPA Filter:** Tap out dust from the HEPA filter regularly. Replace the filter every 3-6 months, depending on usage.
- **Clean Sensors:** Wipe all sensors (LiDAR, anti-drop, anti-collision) with a dry cloth to ensure proper navigation.



The anti-tangling design of the main roller brush.



Automatic mop washing feature of the cleaning station.

8. Troubleshooting

If you encounter issues with your robotic vacuum, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Robot does not start or respond.	Low battery; Power switch off; Robot stuck.	Charge the robot; Ensure power switch is ON; Clear obstacles.
Robot cannot return to charging station.	Charging station blocked; Robot too far; Station not powered.	Clear area around station; Manually place robot on station; Check station power.

Problem	Possible Cause	Solution
Poor cleaning performance.	Dustbin full; Brushes tangled; Filter clogged; Mop pads dirty.	Empty dustbin; Clean brushes; Clean/replace filter; Wash mop pads.
App connection issues.	Incorrect Wi-Fi password; Router too far; Robot not in pairing mode.	Verify Wi-Fi details; Move robot closer to router; Re-enter pairing mode.
Robot gets stuck frequently.	Obstacles on floor; Sensors dirty.	Clear floor; Clean all sensors.

If the problem persists, please contact Eureka Forbes customer support.

9. Specifications

Feature	Detail
Brand	Eureka Forbes
Model Name	FORBES SMARTCLEAN with FULLY AUTOMATIC CLEANING STATION BLITZ
Model Number	GVCDFSCFS00000
Surface Recommendation	Tile, Marble, Carpet & Wooden
Special Features	Anti-Collision, Anti-Fall, Anti-Hair Wrap, App Or Voice Control, Auto Mop Washing
Color	Black
Controller Type	App Control, Voice Control
Filter Type	Multi-Stage Filtration System (HEPA)
Battery Life	Up to 4 Hours
Battery Type	Lithium Ion (5200mAh)
Power Source	Battery Powered
Item Dimensions (L x W x H)	47L x 60W x 46H Centimeters
Item Weight	6 Kilograms
Country of Origin	China

10. Warranty and Support

Your Eureka Forbes SmartClean Fully Automatic Cleaning Blitz Robotic Vacuum comes with a**1-year comprehensive warranty** from the date of purchase.

Warranty Exclusions: The warranty excludes consumable parts such as filters, mop cloths, dust bags, side brushes, and the main roller brush. Physical damage is also not covered under warranty.

For warranty claims, technical support, or to schedule your complimentary virtual demo, please contact Eureka Forbes customer service. Refer to the product packaging or the official Eureka Forbes website for the most current contact information.

Manufacturer Contact Information: Eureka Forbes Ltd.

Importer Contact Information: Eureka Forbes Ltd.

© 2026 Eureka Forbes Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HDYTK43J

More documents and user manuals: **https://manuals.plus/**