

[Manuals.plus](#) /

› [VECELO](#) /

› VECELO 55" TV Stand with Universal Swivel Mount Instruction Manual

VECELO TV Stand with Mount

VECELO 55" TV Stand with Universal Swivel Mount Instruction Manual

Model: TV Stand with Mount

1. PRODUCT OVERVIEW

The VECELO 55" TV Stand with Universal Swivel Mount is designed to provide a stable and versatile platform for televisions ranging from 32 to 75 inches. This entertainment center features a swivel mount for optimal viewing angles, ample storage shelves for media devices and accessories, and an integrated cable management system to maintain a tidy appearance. Constructed from engineered wood and a robust metal frame, it offers both durability and a modern aesthetic.



Image 1.1: The VECELO 55-inch TV Stand with Universal Swivel Mount, showcasing its design and functionality in a living room setting with a television mounted.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Assembly should ideally be performed by two adults to ensure safety and proper alignment.
- Do not exceed the maximum weight capacity for the TV mount or shelves. Refer to the specifications section for details.
- Ensure all screws and fasteners are securely tightened before placing a television or other items on the stand.
- Place the TV stand on a flat, stable, and level surface to prevent tipping.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact VECELO customer support.

- 1 x TV Stand with Mount
- 1 x Tool Kit (includes basic assembly tools)
- 1 x Instructions Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your VECELO TV Stand with Mount. It is recommended to have a second person assist with assembly, especially when handling larger components and mounting the television.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in the included manual to identify each piece.
2. **Assemble the Base Frame:** Begin by assembling the metal frame components for the base of the TV stand. Ensure all connections are secure but do not fully tighten screws until the entire frame is assembled.
3. **Attach Shelves:** Install the engineered wood shelves into the designated slots on the metal frame. Ensure they are properly seated and secured with the provided fasteners.
4. **Assemble the TV Mount Pillar:** Construct the central pillar that supports the TV mount. This pillar also houses the cable management system.
5. **Attach TV Mount to Pillar:** Securely attach the universal swivel TV mount bracket to the top of the central pillar.
6. **Integrate Pillar with Stand:** Connect the assembled TV mount pillar to the main TV stand base. Ensure all connections are stable.
7. **Mount TV Brackets:** Attach the TV mounting brackets to the back of your television.**Note:** *The stand typically does not include screws for attaching the mounting hooks to the back of your TV. You may need to use the screws provided with your television or purchase appropriate VESA-compatible screws separately.*
8. **Hang Television:** With assistance, carefully lift your television and hook the attached brackets onto the TV mount on the stand. Ensure the TV is securely seated and locked into place.
9. **Final Tightening:** Once the entire stand and TV are assembled and positioned, go back and fully tighten all screws and fasteners.

Product Dimensions




Image 4.1: Detailed product dimensions and component measurements for the VECELO 55-inch TV Stand with Mount, including overall height, width, depth, and shelf spacing.

Your browser does not support the video tag.

Video 4.1: Official VECELO assembly video demonstrating the step-by-step installation process for the TV stand and mount. This video provides a visual guide to the assembly steps.

5. OPERATING INSTRUCTIONS


5.1 Swivel Function

The universal TV mount allows for a $\pm 35^\circ$ swivel rotation. To adjust the viewing angle, gently grasp the sides of your television and pivot it left or right to the desired position. Ensure the movement is smooth and does not encounter any obstructions.

5.2 Cable Management

Utilize the integrated cable management system located within the central support pillar. Route your TV and media device cables through the designated openings to keep them organized and out of sight, contributing to a clean and clutter-free entertainment area.

Your TV's Perfect Partner



Universal Fit
for Most TVs

Dynamic $\pm 35^\circ$
Viewing



Hidden Cable
Management



Image 5.1: Diagram illustrating the universal fit for most TVs, dynamic $\pm 35^\circ$ viewing swivel, and hidden cable management features of the TV stand mount.

6. MAINTENANCE

6.1 Cleaning

To clean the TV stand, wipe surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish. Ensure the stand is dry after cleaning.

6.2 Regular Checks

Periodically check all screws and fasteners to ensure they remain tight. Over time, vibrations or movement can cause connections to loosen, potentially affecting the stability of the stand and the safety of your television.

7. TROUBLESHOOTING

- **Stand is Wobbly:** Ensure all screws are fully tightened. Verify the stand is placed on a level surface. Adjust the

leveling feet if present.

- **TV Does Not Fit Mount:** Check your TV's VESA mounting pattern against the mount's specifications. Ensure your TV size is within the recommended 32-75 inch range.
- **Missing Parts:** Refer to the package contents list. If any parts are missing, contact VECELO customer support with your product model and purchase information.
- **Difficulty Assembling:** Review the assembly instructions carefully, paying close attention to diagrams. Ensure components are oriented correctly. Consider having a second person assist.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	VECELO
Model Number	TV Stand with Mount
Color	Matte Black
Size	55"
Item Dimensions (L x W x H)	55 x 15.7 x 56.7 inches
Item Weight	4 pounds
Material Type	Engineered Wood, Metal
TV Size Compatibility	32-75 inches
Swivel Angle	±35°
Assembly Instructions	Easy to follow, clear instructions for assembly
Product Care Instructions	Wipe with Damp Cloth



Image 8.1: Diagram illustrating the adjustable TV mount mechanism and its compatibility with various TV sizes from 32 to 75 inches.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please contact VECELO customer service. Refer to your purchase documentation for specific contact details or visit the official VECELO website.

Online Support: [Visit the VECELO Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question