Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE ULSD316KD02SV2

VASAGLE 63x28 Inch Electric Adjustable Standing Desk Instruction Manual

Model: ULSD316KD02SV2

1. Introduction

Thank you for choosing the VASAGLE Electric Adjustable Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and retain it for future reference.

This electric standing desk features a quiet motor, adjustable height, four memory presets, and a sedentary reminder to promote a healthier work environment. Its robust construction ensures durability and stability for various uses, including home office, gaming, and general computer use.



Image: The VASAGLE 63x28 Inch Electric Adjustable Standing Desk in use.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all components are correctly assembled before connecting to power.
- Do not exceed the maximum static load capacity of 154 lb (70 kg).
- Keep children and pets away from the desk during operation to prevent accidents.
- Ensure there are no obstructions in the desk's path during height adjustment.
- Do not sit or stand on the desk.
- Disconnect power before cleaning or maintenance.
- Use only the provided power adapter.
- If any unusual noise, smell, or smoke occurs, immediately unplug the desk and contact customer support.




Image: The desk undergoing a durability and load test, demonstrating its robust construction.

3. Package Contents

Verify that all parts are present before beginning assembly:

- 1 x Electric Standing Desk (Desktop and Frame)

- 1 x Accessory Kit (Screws, tools, etc.)
- 1 x Instructions Manual

4. Setup and Assembly

Assembly of the VASAGLE Electric Standing Desk is designed to be completed in approximately 30 minutes. Follow these general steps:

1. **Join the Desktop Panels:** Carefully connect the desktop sections if they are provided in multiple pieces.
2. **Assemble the Frame:** Attach the crossbar and side brackets to the lifting columns.
3. **Attach the Legs:** Secure the feet to the bottom of the lifting columns.
4. **Secure the Desktop:** Place the assembled desktop onto the frame and fasten it using the provided screws.
5. **Connect Power:** Plug the power cable into the control box and then into a wall outlet.



Image: Visual guide for the 30-minute assembly process.

5. Operating Instructions

Your VASAGLE Electric Standing Desk offers easy height adjustment and convenient memory functions.

5.1 Height Adjustment

- Use the **Up (^)** and **Down (v)** buttons on the control panel to adjust the desk height.
- The desk can be adjusted smoothly from a minimum height of 28.3 inches (72 cm) to a maximum height of 46.1 inches (118 cm).
- Release the button to stop the desk at your desired height.

5.2 Memory Presets

The desk features four programmable memory presets to save your preferred sitting and standing heights:

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **M** button (or similar memory set button if present, refer to control panel diagram).
3. Press one of the numbered preset buttons (**1, 2, 3, or 4**) within 3 seconds. The display will show 'S-' followed by the number, indicating the height is saved.
4. To recall a saved height, simply press the corresponding numbered button. The desk will automatically move to the saved position.



Image: Illustration of the 4 memory presets for various user heights and activities.

5.3 Sedentary Reminder

The desk includes a built-in sedentary reminder to encourage movement throughout your workday. This feature will gently remind you to change your posture (e.g., stand up) after a set period of inactivity. Consult the full instruction manual for details on activating or customizing this feature.

5.4 Quiet Operation

The desk's motor operates quietly, typically below 50 dB, ensuring minimal disturbance in your workspace.



Image: The desk's quiet operation feature.

5.5 Operational Video

Your browser does not support the video tag.

Video: Demonstrates the assembly and electric adjustment features of the VASAGLE Standing Desk.

6. Maintenance

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Regularly check that all cables are securely connected and not pinched or damaged.
- **Inspection:** Periodically inspect all screws and connections to ensure they are tight. Retighten if necessary.
- **Lubrication:** The lifting mechanism is designed to be maintenance-free. Do not apply lubricants unless specifically instructed by customer support.

7. Troubleshooting

If you encounter issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; overload; motor overheating.	Check power connections. Reduce weight on desk. Allow motor to cool down for 20 minutes.
Desk moves unevenly or makes unusual noise.	Loose connections; uneven weight distribution.	Check all assembly screws. Redistribute weight evenly on the desktop.
Memory presets not working.	Presets not correctly saved.	Re-save the memory presets following the instructions in Section 5.2.
Error code displayed.	Specific system fault.	Refer to the detailed troubleshooting section in the full manual or contact customer support.

If these solutions do not resolve the issue, please contact VASAGLE customer support for further assistance.

8. Specifications

Feature	Detail
Brand	VASAGLE
Model Number	ULSD316KD02SV2
Product Dimensions (D x W x H)	27.6"D x 63"W x 47.2"H (70 cm D x 160 cm W x 120 cm H)
Minimum Height	28.3 inches (72 cm)
Maximum Height	46.1 inches (118 cm)
Color	Rustic Brown
Material Type	Steel, Particleboard, PA Plastic
Item Weight	50.4 pounds (22.86 kg)
Max. Static Load Capacity	154 lb (70 kg)
Special Feature	Electric Height Adjustment, 4 Memory Presets, Sedentary Reminder
UPC	194343827896



Image: Key dimensions and load capacity of the desk.

9. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact VASAGLE customer service. Details can typically be found on the product packaging or the official VASAGLE website. Please have your model number (ULSD316KD02SV2) and proof of purchase ready when contacting support.

© 2023 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HJZ91XVP

More documents and user manuals: **https://manuals.plus/**