Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Walsunny WS-WM-SHX1743-BLU-NA

Walsunny Kitchen Island Cart WS-WM-SHX1743-BLU-NA User Manual

Model: WS-WM-SHX1743-BLU-NA

Introduction

Thank you for choosing the Walsunny Kitchen Island Cart. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new kitchen island cart. Please read these instructions carefully before assembly and retain them for future reference.



Image: The Walsunny Kitchen Island Cart, Model WS-WM-SHX1743-BLU-NA, in a blue finish with a wooden countertop, positioned in a kitchen.

Safety Information

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Keep all assembly hardware out of reach of children.
- Ensure all parts are securely fastened before use.
- Do not overload the shelves or countertop.
- Use on a flat, stable surface.
- Lock casters when the cart is stationary to prevent accidental movement.

Setup and Assembly

Before beginning assembly, ensure all components are present and undamaged. Refer to the included assembly

hardware and instructions for detailed steps.

1. Unpacking and Part Identification

1. Carefully unpack all contents from the packaging.
2. Lay out all parts on a clean, soft surface to prevent scratches.
3. Compare the received parts with the parts list provided in your assembly guide to ensure everything is accounted for.

2. Assembly Steps

Follow the step-by-step instructions provided in the separate assembly hardware manual. Typically, assembly involves:

1. Attaching the casters to the base of the cart.
2. Assembling the main frame and internal shelving.
3. Installing the drawer slides and drawer.
4. Attaching the side panels and magnetic doors.
5. Securing the main countertop and the drop-leaf extension.
6. Installing the metal towel rack.



Image: Detail of the 360° swivel casters with a locking mechanism, essential for mobility and stability.

Operating Instructions

Using the Drop-Leaf Countertop

The kitchen island features a flexible drop-leaf tabletop to expand your workspace or dining area.

- **To Extend:** Gently lift the drop-leaf section until it is level with the main countertop. Ensure the support mechanism underneath is fully extended and locked into place.
- **To Fold:** Release the support mechanism and carefully lower the drop-leaf section until it rests against the side of the cart.



Image: The kitchen island with its drop-leaf extended, providing additional counter space or a small dining area.

Utilizing Storage Features

- **Drawer:** The cart includes one smooth-gliding drawer for utensils or smaller items. Pull the metal handle to open and push to close.
- **Magnetic Doors:** Two doors with magnetic catches provide access to internal shelving for larger items. Pull the metal handles to open and push firmly to close until the magnetic catch engages.
- **Towel Rack:** A metal towel rack is located on the side for convenient access to kitchen towels.



Image: Detailed view of the cart's features, including metal handles, smooth drawer slides, magnetic door catches, and the integrated towel rack.



Image: The interior storage compartments of the kitchen island cart, showcasing its capacity for various kitchen items.

Mobility and Stability

- **Moving the Cart:** Unlock all casters by pressing the lever on each wheel. Gently push the cart to its desired location.
- **Securing the Cart:** Once in position, lock all casters by pressing the lever down on each wheel to prevent unintended movement.

Maintenance and Care

Proper care will extend the life and appearance of your kitchen island cart.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. For the wooden countertop, use a wood-safe cleaner.
- **Spills:** Clean up spills immediately to prevent staining, especially on the wooden countertop.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.

- **Casters:** Keep casters free of debris to ensure smooth rolling.

Troubleshooting

Refer to the following common issues and solutions:

- **Cart is wobbly:**
  - Ensure all assembly screws are securely tightened.
  - Verify the cart is on a level surface. Adjust caster locks if necessary.
- **Drawer does not slide smoothly:**
  - Check for any obstructions in the drawer slides.
  - Ensure the drawer is correctly aligned on its tracks.
  - Lubricate slides with a silicone-based lubricant if needed.
- **Drop-leaf table does not stay extended/folded:**
  - Inspect the support mechanism for damage or misalignment.
  - Ensure the mechanism is fully engaged when extending or folding.
- **Doors do not close properly:**
  - Check if the magnetic catches are aligned and functioning.
  - Ensure hinges are properly tightened and doors are not sagging.

Specifications

Feature	Detail
Product Dimensions (D x W x H)	41.8" x 15.8" x 35.2"
Material	Engineered Wood, Metal
Color	Blue
Number of Shelves	2
Number of Drawers	1
Weight	75 pounds
Model Number	WS-WM-SHX1743-BLU-NA
UPC	850069465186
Included Components	Assembly Hardware

Warranty Information

This product is covered by the manufacturer's standard warranty. Please refer to the warranty card included with your purchase or visit the official Walsunny website for detailed warranty terms and conditions. Keep your proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance with assembly, or encounter any issues not covered in this manual, please contact Walsunny customer support. Contact information can typically be found on the product packaging or the official Walsunny website.

Online Support: Visit the Walsunny Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HMLC6D6R

More documents and user manuals: **https://manuals.plus/**