Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BoxWave bw-1173-66561-8831

BoxWave SlimKeys Bluetooth Keyboard

User Manual

Model: bw-1173-66561-8831

1. Introduction

Thank you for choosing the BoxWave SlimKeys Bluetooth Keyboard. This ultra-thin, portable keyboard is designed to enhance your typing experience on various devices, including the Amazon Alexa Tablet 11 (2026), Android, Windows, and iOS devices. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new keyboard.



Figure 1: Top-down view of the BoxWave SlimKeys Bluetooth Keyboard, showcasing its full QWERTY layout and compact design.

2. Package Contents

Please check the package for the following items:

- SlimKeys Bluetooth Keyboard

3. Product Features

- **Ultra-Thin Design:** Measuring just 3/16 inch thick, the keyboard offers a sleek, compact profile for easy portability.
- **Lightweight and Comfortable:** Features responsive, chiclet-style keys for a tactile typing experience, ideal for extended use.
- **Power-Efficient Functionality:** Built-in on/off switch and Bluetooth 3.0 technology conserve battery life.
- **Fast Bluetooth Pairing:** Ensures quick and reliable connection with your device without lag.

- **Ideal for Travel:** Transforms your mobile device into a portable productivity station.



Figure 2: The SlimKeys Bluetooth Keyboard highlighting its slim and lightweight profile, making it easy to carry.



Figure 3: The keyboard demonstrating its ultra-thin convenience, easily fitting into a bag for travel.



Figure 4: A close-up view of the chiclet-style keys, designed for quiet and comfortable typing.

4. Setup and Pairing

Follow these steps to connect your SlimKeys Bluetooth Keyboard to your device:

1. **Charge the Keyboard:** Before first use, ensure the keyboard is fully charged. Connect a standard Micro-USB charging cable (not included) to the keyboard's charging port and a USB power source. The 'Charge' indicator light will illuminate during charging and turn off when fully charged.
2. **Power On:** Locate the ON/OFF switch on the top right edge of the keyboard. Slide it to the 'ON' position. The 'Power' indicator light will briefly illuminate.
3. **Enter Pairing Mode:** Press the 'Connect' button, usually located near the ON/OFF switch. The 'Connect' indicator light (often blue) will start blinking, indicating the keyboard is in pairing mode.
4. **Enable Bluetooth on Your Device:** On your tablet, smartphone, or computer, go to the Settings menu and enable Bluetooth.
5. **Search for Devices:** Your device will begin searching for nearby Bluetooth devices. Look for 'SlimKeys Keyboard'

or a similar name in the list of available devices.

6. **Pair the Devices:** Select 'SlimKeys Keyboard' from the list. Your device may prompt you to enter a pairing code displayed on your screen. Type this code on the SlimKeys keyboard and press 'Enter'.
7. **Confirmation:** Once paired, the 'Connect' indicator light on the keyboard will stop blinking and turn off, and your device will show the keyboard as connected.

The SlimKeys Bluetooth Keyboard is compatible with Android, Windows, and iOS operating systems.



Figure 5: The keyboard in use, demonstrating its compatibility with Android, Apple (iOS), and Windows devices for comfortable typing.

5. Operating the Keyboard

The SlimKeys Bluetooth Keyboard features a standard QWERTY layout along with specialized function keys to enhance productivity.

Function Keys (F1-F12)

Many keys have secondary functions accessible by pressing the 'Fn' key simultaneously with the desired function key.

Refer to the key labels for specific functions:

- **Esc (Home):** Returns to the home screen.
- **F1 (Search):** Opens the device's search function.
- **F2 (Select All):** Selects all text or items.
- **F3 (Copy):** Copies selected content.
- **F4 (Paste):** Pastes copied content.
- **F5 (Cut):** Cuts selected content.
- **F6 (Skip Back):** Skips to the previous track/media.
- **F7 (Play/Pause):** Plays or pauses media playback.
- **F8 (Skip Forward):** Skips to the next track/media.
- **F9 (Volume Down):** Decreases the device's volume.
- **F10 (Volume Up):** Increases the device's volume.
- **F11 (Brightness Down):** Decreases screen brightness.
- **F12 (Brightness Up):** Increases screen brightness.
- **Delete (Lock):** Locks the device screen.



Figure 6: Detailed view of the specialized function keys (F1-F12) and their corresponding icons for quick access to common device controls.

6. Maintenance

To ensure the longevity and optimal performance of your SlimKeys Bluetooth Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture.
- **Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the keyboard is turned off to conserve battery life.
- **Battery Care:** Recharge the keyboard when the battery is low. Avoid fully depleting the battery frequently, as this can reduce its overall lifespan. If storing for an extended period, charge the battery to about 50% before turning it off.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage to internal components.

7. Troubleshooting

If you encounter issues with your SlimKeys Bluetooth Keyboard, try the following solutions:

- **Keyboard Not Turning On:**
  - Ensure the ON/OFF switch is in the 'ON' position.
  - Charge the keyboard for at least 30 minutes.
- **Keyboard Not Pairing:**
  - Ensure the keyboard is in pairing mode (Connect light blinking).
  - Make sure Bluetooth is enabled on your device.
  - Move the keyboard closer to your device.
  - Forget/remove the keyboard from your device's Bluetooth list and try pairing again.
  - Restart both the keyboard (turn off/on) and your device.
- **Keys Not Responding:**
  - Ensure the keyboard is properly paired and connected.
  - Check the battery level and charge if necessary.
  - Try re-pairing the keyboard with your device.
- **Lag or Disconnections:**
  - Ensure there are no other strong wireless signals interfering (e.g., Wi-Fi routers, other Bluetooth devices).
  - Keep the keyboard within the recommended Bluetooth range of your device.
  - Recharge the keyboard.

8. Specifications

Brand	BoxWave
Model Number	bw-1173-66561-8831
Color	Jet Black
Connectivity	Bluetooth 3.0
Item Weight	8.6 ounces
Included Components	SlimKeys Bluetooth Keyboard

9. Warranty and Support

This BoxWave SlimKeys Bluetooth Keyboard comes with a**90-Day Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For technical support or warranty claims, please contact BoxWave Corporation directly. Refer to your purchase documentation or the BoxWave website for contact information.

© 2026 BoxWave Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HRL2SG2N

More documents and user manuals: **https://manuals.plus/**