

aspire NX30 Rover Kit Mod Built-In Battery



# aspire NX30 Rover Kit Mod Built In Battery User Manual

[Home](#) » [aspire](#) » aspire NX30 Rover Kit Mod Built In Battery User Manual 

## Contents

- 1 [aspire NX30 Rover Kit Mod Built-In Battery](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [FAQ](#)
- 5 [Top Fill Instructions](#)
- 6 [Coil Installation](#)
- 7 [Mod Appearance](#)
- 8 [Specifications](#)
- 9 [NX30 Button Functions](#)
- 10 [Charging](#)
- 11 [Documents / Resources](#)
  - 11.1 [References](#)
- 12 [Related Posts](#)



aspire NX30 Rover Kit Mod Built-In Battery



## **Product Information**

### **Specifications**

- Wattage Range: 1-30W
- Output Voltage Range: 0.50-8.00V
- Resistance Parameters: 0.2ohm to 3.5ohms
- Continuous Fire Time: 10 seconds
- Charging Port: Micro-USB
- Screen: OLED 0.86 inch
- Dimensions: 22.5\*36\*60mm
- Battery Capacity: 2000mAh
- Battery: Built-in Lipo

## **Product Usage Instructions**

### **Top Fill Instructions**

1. Unscrew and remove the top cap.
2. Squirt E-Liquid into the tank.
3. Re-attach the top cap to your tank and begin to vape.

### **Coil Installation**

1. Unscrew the top cap from the tank.
2. Remove the Pyrex tube.
3. Replace the atomizer with a new one.

### **NX30 Button Functions**

- Click fire Button 5 times within 2 seconds to power the NX30 mod ON.
- Click fire Button 3 times quickly to go into or out of stealth mode.
- Press Fire Button + + to select between VW, VV, and Bypass modes.
- Press + and – buttons simultaneously for 2 seconds to rotate the screen.
- Press + / – to either Lock or Unlock the device.
- Press Fire Button + – to increase or decrease Wattage or Voltage.

### **Charging**

Charging is via a Micro-USB charging port. The maximum charging current can reach up to 1A.

1. Connect the mod to your charger. The screen will flash a battery icon.
2. When the charge level reaches 4.2V or when it is fully charged, the mod will stop charging and the screen will turn off.
3. The mod supports pass-through charging. To lengthen the life of the mod, we do not recommend vaping while

charging (pass-through).

## FAQ

### **Q: How do I fill the tank?**

A: To fill the tank, unscrew and remove the top cap, squirt E-Liquid into the tank, and re-attach the top cap.

### **Q: How do I install a new coil?**

A: To install a new coil, unscrew the top cap from the tank, remove the Pyrex tube, and replace the atomizer with a new one.

### **Q: How do I turn on the NX30 mod?**

A: To turn on the NX30 mod, click the fire button 5 times within 2 seconds.

### **Q: Can I vape while charging?**

A: While the mod supports pass-through charging, we do not recommend vaping while charging to lengthen the life of the mod.

- 1\* NX30 Mod
- 1\* Nautilus X Tank
- 1\* 1.8ohm U-Tech Coil (12-16W)
- 1\* Replacement Pyrex
- 1\* Micro-USB Cable
- 1\* Lanyard
- 1\* Warranty Card
- 1\* User Manual

## Top Fill Instructions



1. Unscrew and remove the top cap.
2. Squirt E-Liquid into the tank.
3. Re-attach the top cap to your tank and begin to vape.

## Coil Installation


- Unscrew the top cap from the tank
- Remove the Pyrex tube
- Replace the atomizer with a new one



## WARNING

- When using a new atomizer, let the tank stand for 5 minutes, so the cotton can be saturated with juice before firing.
- Do not let the tank become completely empty. Refill the tank to avoid dry burning or damage to the atomizer.

## Mod Appearance



## Specifications

- Wattage Range: 1-30W
- Output Voltage Range: 0.50-8.00V
- Resistance Parameters: 0.2ohm to 3.5ohms
- Continuous Fire Time 10 seconds
- Charging Port: Micro-USB
- Screen: OLED 0.86 inch
- Dimensions: 22.5\*36\*60mm
- Battery Capacity: 2000mah
- Battery: Built-in Lipo

## NX30 Button Functions


|  |   |
|--|---|
| Click fire Button 5 times within 2 seconds | To power the NX30 mod ON.   |
| Click fire Button 3 times quickly          | To go into or out of stealth mode   |
| Press Fire Button + "+"                    | To select between VW, VV and Bypass modes                                   |
| Press "+" + "-"                            | Press "+" and "-" buttons simultaneously for 2 seconds to rotate the screen |

|  |  |
|--|--|
| Click fire Button 5 times within 2 seconds | To either Lock or Unlock the device        |
| Press "+" / "-"                            | To Increase or decrease Wattage or Voltage |
| Press Fire Button + "-"                    | To Lock or Unlock the mod buttons          |

## Charging

- Charging is via a Micro-USB charging port. Maximum charging current can reach up to 1A.
- Connect the mod to your charger. The screen will flash a battery icon. When the charge level reaches 4.2V or when it is fully charged, the mod will stop charging and a screen will turn off.
- The mod supports pass-through charging. To lengthen the life of the mod, we do not recommend vaping while charging (pass-through).

## Documents / Resources

|   |   |
|---|---|
|  | <p><a href="#">aspire NX30 Rover Kit Mod Built In Battery</a> [pdf] User Manual<br/> NX30 Rover Kit Mod Built In Battery, NX30, Rover Kit Mod Built In Battery, Mod Built In Battery, Built In Battery, Battery</p> |
|---|---|

## References

-  [Manual-Hub.com - Free PDF manuals!](#)
- [User Manual](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.