



---

[Home](#) » [Assorted](#) » **Assorted DW39 Wireless Bluetooth Headset Instruction Manual** 

**Contents** [ [hide](#) ]

- [1 Assorted DW39 Wireless Bluetooth Headset](#)
- [2 OVERVEIW](#)
- [3 INSTALLATION INSTRUCTION](#)
- [4 Simple instructions](#)
- [5 Function definitions](#)
- [6 Warranty](#)
- [7 FCC STATEMENT](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)

## Assorted

### Assorted DW39 Wireless Bluetooth Headset



### **Parameter configuration**

- Real wireless connection, wireless stereo, left and right channel separation, HIFI sound effect, left and right ears have complete Bluetooth function, can be used alone, can also be used in pairs, using dual-hair sharing mode, master/slave switching.

### **Note:**

1. Before using this product, please fully that electricity.
2. This product can be used with devices which has the function of bluetooth devices.  
Connection to use.

### **OVERVEIW**



Touch position

## INSTALLATION INSTRUCTION

### Simple instructions

#### The headset is on/off:

1. Power on: open the cover charge storehouse, remove the headset, automatically switches on.
2. Turn off: charging directly into the warehouse to turn it off.

#### Pairing:

Automatic pairing is performed when the device is powered on. After the pairing is successful, a beep tone is displayed

(**Note:** If there is no pairing, you need to put it back into the charging bay, close the cover, and then open the cover, hear the “beep” pairing success.)

#### S & Andro ID systems connect the headset:

- Open the phone “Settings” – turn on the Bluetooth search – find the “DW39” pairing name, click Connect – display “Connected”. When the phone connection is completed once, use the first point again, and the ear will automatically connect with the phone.

## Function definitions

### Function definition in all states

Telephone answering	Touch either side 1 time
Hang up the phone	Touch either side 1 time
Call rejection	Press and hold either side for 2 seconds when an incoming call is placed

### Function definition in music state

Play \ pause	Touch either side 1 time
Previous song	Touch left ear 2 times
Next song	Touch right ear 2 times
Add volume	Touch left ear 3 times
Reduce the volume	Touch right ear 3 times

### Voice assistant

Apple system	Wake up siri' : Press and hold any edge for 2 seconds
Android system	Support to wake up the voice assistant, long press any edge for 2 seconds

### Charging bin definition and parameters

<b>Product status</b>	<b>Indicator light display</b>
Bin charge state	The display is on and the number is blinking
Bin full charge	Show 100%
Low battery	Show 0%
Headphone storage	Cabinet display blue light,earphone red light is steady on
Earphone charging state	Headphone red light is steady on
Headphones fully charged	All lightes goes off
Ears pairing status	Red and blue light in left ear alternate flash, The secondary ear light is off
Headset working condition	All lights go out
Disconnect status.	Red and blue light in main ear alternate flash, The secondary ear light is off

<b>Function</b>	<b>Describe</b>
Charging bay capacity	200mAh
Headphone capacity	30mAh(single)
Charging voltage \ current	DC 5V 300mA
Charging bay charging time	About 60 minutes
Endurance	About 3 times (charging in both ears)

### **Matters needing attention**

1. Do not use violence against the product, do not squeeze it with heavy objects, and stay away from high temperatures and humidity environment.
2. Stay away from WIFI, routers, and other high-frequency transmitting equipment, which will affect the signal reception of the machine, resulting in the sound card breaking and disconnection.
3. Please use this product in an effective environment (10 meters), and there is no physical barrier (such as wall, etc.) between the Bluetooth device and the headset.
4. If the product is not used for a long time, charge the headset and base (within one month).

### **Warranty**

#### **Warranty card**

Dear customer, thank you for buying our products. In order to better serve you, after the purchase of products, please carefully read, fill in, and properly keep this warranty card.

Customer name		Contact person	
Product name		Product model	
Date of purchase		Factory number	

Maintenance record	Date	Cause of failure and treatment

### Warranty specification

1. Please keep the warranty card for maintenance.
2. This product is guaranteed for 6 months from the date of purchase.
3. warranty equipment during the maintenance period, in the case of normal use and maintenance, if the machine itself has functional problems, failure, verified, the company provides free maintenance services;
4. During the warranty period, if the following matters occur, the Company has the right to refuse service or charge materials and service fees as appropriate.
  1. Unable to provide this guarantee and valid proof of purchase.
  2. Product failure and damage caused by improper use by the user;
  3. Man-made or abnormal damage;
  4. Damage caused by disassembly and repair not authorized by our company;
  5. Failure and damage caused by natural disasters or other force majeure factors;
  6. other people intentionally damage;
5. The Company reserves the right to modify and interpret all contents.

## FCC STATEMENT

### FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0cm between the radiator and your body.

## FAQ

- **Q:** Can I modify the device without approval from the manufacturer?
- **A:** No, any changes or modifications not explicitly approved by the manufacturer could void your authority to operate the equipment.
- **Q:** What are the compliance conditions for this device?
- **A:** The device must not cause harmful interference and must accept any received interference as per FCC Part 15 rules.

## Documents / Resources

	<a href="#">Assorted DW39 Wireless Bluetooth Headset [pdf]</a> Instruction Manual DW39, DW39 Wireless Bluetooth Headset, Wireless Bluetooth Headset, Bluetooth Headset, Headset
---	--

## References

- [User Manual](#)

Assorted  
Assorted, Bluetooth Headset, DW39, DW39 Wireless Bluetooth Headset, Headset, Wireless Bluetooth Headset

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email



Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.