

# asTech Connect Application User Guide

Home » asTech » asTech Connect Application User Guide 🖔




Connect Application User Guide

#### Contents

- 1 Create an asTech account
- 2 Download the new asTech App
- 3 Plug your asTech device into a vehicle
- **4 Enable Bluetooth**
- 5 Launch the asTech App
- 6 Documents / Resources
- 7 Related Posts

Create an asTech account



Register your as Tech account via the email you received from noreply@astech.com with the subject line "You've been added to an as Tech account".

**Note:** To request another registration email go to <a href="www.astech.com/registration">www.astech.com/registration</a>.

## Download the new asTech App



Ensure your device is connected to the internet. Then go to the App Store. Search "asTech App" to find and install the app.


## Plug your asTech device into a vehicle



Plug your asTech Device into a vehicle place the ignition in On/Run, engine off. An IP Address, VIN, and "Connected & Waiting" should appear on the device screen. The device is now ready to use.


**Note:** The vehicle needs to be battery supported. Connecting a battery support device to the vehicle is recommended.

#### **Enable Bluetooth**



Enable Bluetooth on your mobile device.

## Launch the asTech App




On the device, tap the asTech icon to launch the app.. On the login screen, type your username and password created for your asTech account.

That's it! You are ready to scan a vehicle.

You can reach Customer Service at: 1-888-486-1166 or customerservice@astech.com

### **Documents / Resources**



Manuals+,