



AstroAI AESB47 Extendable Snow Broom User Manual

[Home](#) » [AstroAI](#) » AstroAI AESB47 Extendable Snow Broom User Manual 

AstroAI AESB47 Extendable Snow Broom User Manual



Contents

- [1 INTRODUCTION](#)
- [2 DIAGRAM](#)
- [3 ASSEMBLY INSTRUCTIONS](#)
- [4 DISASSEMBLY INSTRUCTIONS](#)
- [5 PRODUCT SIZE](#)
- [6 PACKAGE INCLUDES](#)
- [7 RECYCLING](#)
- [8 WARRANTY PERIOD](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

INTRODUCTION

Thank you for purchasing the Astral snow broom. This product is designed to remove snow.

For the best performance and safety, please read and follow the instructions before use. Please keep these instructions for future reference. We hope you enjoy your new snow brush! Thank you again for choosing Astral, if you have any questions or concerns regarding your product, please contact us via support@astroai.com




Please fully read and follow this manual before using the product; keep this manual for future reference.

WARNING

- Store the product in a dry place out of direct sunlight.
- Keep the product away from fire, corrosive liquids and strong acids.
- Avoid putting heavy objects on the product, doing so may bend or deform it.


DIAGRAM




1. Head
2. Angle Button
3. Buckle
4. Length Button
5. Grip
6. Buckle
7. Ice Scraper
8. Hook Hole

ASSEMBLY INSTRUCTIONS


1. Align the buckle end of the grip with the snow broom head, push the two pieces together to secure them.




2. Align the non-buckle end of the grip with the ice scraper, push the two pieces together to secure them.



3. Press the length button and slide it to a suitable length, release the button to lock the position.




4. Press the angle button and rotate the head to the desired angle, release the button to lock the position.




DISASSEMBLY INSTRUCTIONS

1. Press the buckle button on the snow broom head and pull out the grip.



2. Press the buckle button on the ice scraper and pull out the grip.



PRODUCT SIZE

Unfolded length (Not extended) 36.6 in/93 cm

Maximum length (Extended) 47.2 in/120 cm

PACKAGE INCLUDES

Snow broom x1

RECYCLING

You may dispose of the product when its service life has ended, please recycle any recyclable parts according to local guidelines.

WARRANTY PERIOD

2-Year Limited Warranty From Astral

Each Astral snow broom will be free from defects in material and workmanship.

This warranty does not cover damage from neglect, misuse, contamination, alteration, accident, or abnormal conditions of operation or handling.


This warranty covers the original purchaser only and is not transferable.

Web: www.astroai.com

E-mail: support@astroai.com

AstroAI

Documents / Resources

 The image shows the cover of the user manual for the AstroAI AESB47 Extendable Snow Broom. It features the AstroAI logo at the top, a photograph of the snow broom, and the text 'AESB47 EXTENDABLE SNOW BROOM USER MANUAL' at the bottom.	<p>AstroAI AESB47 Extendable Snow Broom [pdf] User Manual AESB47 Extendable Snow Broom, AESB47, Extendable Snow Broom, Snow Broom, Broom</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.