



AT T S20-BLK Portable Wireless Speaker User Manual

[Home](#) » [AT&T](#) » AT T S20-BLK Portable Wireless Speaker User Manual 

Contents

- [1 AT T S20-BLK Portable Wireless Speaker](#)
- [2 Introduction](#)
- [3 Safety Information](#)
- [4 Getting Started](#)
- [5 Operational Instructions](#)
- [6 Operational Instructions](#)
- [7 Troubleshooting](#)
- [8 SPECIFICATIONS](#)
- [9 Warranty Information](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



AT T S20-BLK Portable Wireless Speaker




Introduction

Features


- High powered Wireless speaker
- Wireless streaming through Bluetooth® enabled devices
- Built-in microphone
- Auxiliary input to play music from any device
- Automatically connects to any paired devices

What's included

Unpack the speaker system and make sure all accessories are put aside so they will not be lost.



Micro USB cable



COM 801

Safety Information

Warning!

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO DRIPPING OR SPLASHING LIQUIDS.



THE LIGHTING FLASH and arrowhead symbol within the triangle is a warning sign alerting you of “dangerous voltage” inside the product.



WARNING: To reduce the risk of electric shock, do not remove the cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.



The exclamation point within the triangle is a warning sign alerting you of important instructions accompanying the product.

Important Safety Instructions


When used in a directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in this user's manual and on the unit.

1. **Cleaning** – Unplug the unit from the wall outlet before cleaning. Clean the unit using a damp cloth; do not use liquid or aerosol cleaners.
2. **Attachments** – Do not use attachments that are not recommended by the manufacturer.
3. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
4. **Placement** – Do not place the unit on an unstable table, stand, tripod, or bracket. This may result in serious personal injuries and damage to the unit.
5. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug, or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as ventilation openings.
6. **For periods of Non-use** – time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
7. **Objects and Liquid Entry** – Care should be taken so that external objects do not fall into and liquids are not spilled onto any openings or vents located on the product.
8. **Power Source** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the unit. If you are not sure, please consult the dealer or local power company.
9. **Power Cord Protection** – The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against them. It is always better to have a clear area from where the cable exits the unit to where it is plugged into an AC outlet.
10. **Lightning** – Unplug the unit from the wall outlet and disconnect the antenna unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
11. **Overloading** – Do not overload wall outlets, extension cords, or integral
12. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves and other appliances that produce heat.
13. **Damage Requiring Service** – The unit should be serviced by a qualified service personnel when:
 - A. the power supply cable or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled onto the enclosure.

- C. the unit has been exposed to rain.
- D. the unit has been dropped or the enclosure damaged.
- E. the unit exhibits a marked change in performance or does not operate normally.
14. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's manual. Opening or removing covers will expose you to dangerous voltage and other hazards, service method is not covered in the user's manual should be referred to qualified service personnel.
15. **Safety Check** – Upon completion of any service or repair to the unit, ask the service technician to perform safety checks to determine that the product is in proper working condition.
16. **Built-in Battery Care** – This device contains a rechargeable Lithium-ion battery. The battery can be charged and discharged hundreds of times. Unplug the charger from the electrical outlet and product when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery.

Getting Started

Location of Main Unit Controls



Buttons & Interface View:

1. Power Button
2. Play/Pause Music & Answer /End Call/TWS function
3. Decrease Volume – | Skip to the previous track
4. Increase Volume + | Skip to next track
5. Micro USB charging port & LED light – Power Indicator and Bluetooth Indicator
6. 3.5mm Aux input

Charging the COM 801

1. Connect a Micro USB charging cable to the charging port on the COM 801.
2. Connect the USB end of the Micro USB cable to your computer's USB port or an AC USB adapter.
3. When the speaker is charging, the LED indicator light located on the Micro charger interface of the speaker will turn red.
4. Once the speaker is fully charged, the LED light indicator is turned off.

LED Status Indicator

Wireless LED Indicator

- Blinking Blue LED: Wireless on with no connection. (Ready to pair)
- Solid Blue LED: Wireless paired and connected.

Powering ON/OFF

1. To power the speaker on, press and hold the power button until you hear an ascending audible tone and the Wireless LED light starts blinking.
2. To power the speaker off, press hold and hold the power button until you hear a descending audible tone. The Wireless LED light will turn off.

Operational Instructions

Wireless Operation

The COM 801 connects with most Bluetooth devices including iPad® devices, iPhone® devices, and iPod® touch devices, and most smartphones, laptops, and tablets.

Setting Up Your COM 801 for Pairing

1. Turn on the COM 801 wireless speaker 2.
2. The blue LED light will start to flash indicating that the COM 801 is now ready to be paired with your Bluetooth device.

Pairing a Bluetooth Device for the First Time

1. Navigate to the Bluetooth manager on your Bluetooth device
2. Search Bluetooth devices and select ' COM 801 ' to start connecting.
3. Once paired, the COM 801 will beep and the Bluetooth LED light will turn solid blue
4. Your Bluetooth device is now paired, connected, and ready to stream audio to the speaker system.

TWS Pairing Operation for two speakers

1. Turn on both COM 801 wireless speakers.
2. Press and hold the button, on both speakers at the same time. Both COM 801peak ers will beep once connected.

3. To cancel press and hold the button

Operational Instructions

Using the Auxiliary Input Connection (3.5mm)

You can connect the audio output of an external device, such as a MP3 player or smartphone, to the COM 801 for listening to the audio of that device through the speaker system.

1. Use a standard stereo Aux (3.5 mm) cable to connect the “audio line-out” of the device to the aux-in jack of this speaker system.
2. Turn on the speaker system and the external device (eg. MP3 player or smartphone).
3. Make sure the speaker system is not connected to any Bluetooth devices.
4. Start playback of the external device and adjust the volume by pressing the | + | or | – | button.
5. Remember to switch off the speaker system when you are finished using the external device.

Button Controls

- **Lower volume**

Press and hold the | – | button to decrease the volume level

- **Increase volume**

Press and hold the | + | button to increase the volume level

- **Skip backward**

Press the | – | button to skip to the previous track

- **Skip forward**

Press the | + | button to skip to the next track

Call Function

- To answer any incoming calls, press the || button.
- To end the call, press the || button.
- To reject call, Press and hold t h e || button.
- To redial the last called number, double-click the || button.

Troubleshooting

Symptom	Solution
Music is not streaming over Wireless	<ul style="list-style-type: none"> – Check if both devices are paired and connected over Wireless – Make sure there isn't a 3.5mm cable connected to the aux input on the back of the speaker. – Restart the COM 801 to auto-connect with your Bluetooth device.
No power	<ul style="list-style-type: none"> – Recharge your speaker using included cable. If the problem cable.
Battery is not charging	<ul style="list-style-type: none"> – Verify COM 801 is plugged in properly and into a proper power source.

SPECIFICATIONS

- **Power Output:** 5W X 1
- **Playtime:** Up to 4 hours
- **Impedance:** 4 5w
- **Rechargeable Battery:** 3.7V/1200mAh (Built-In) Battery charging time: 2 hours

Remarks: If troubleshooting does not eliminate the problem, disconnect the DC IN

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Warranty Information

Limited Warranty

The AT&T brands are used under license. Any repair, replacement, or warranty service, and all questions about this product should be directed to Concept 101 LLC at www.att.com/electronics or call 1 (888) 920-8680 from the USA or Canada.

Concept 101 LLC warrants to the original purchaser that the product will be free from defects in material, parts and workmanship for the period designated for this product. The warranty commences the day the product is purchased and covers up to a period of one (1) year. Concept 101 LLC agrees that it will, at its option, replace the defective product with either a new or remanufactured headset equivalent to your original purchase during the warranty period. Should the Parts warranty period exceed the Labor warranty period, Concept 101 LLC will supply at no charge for the remainder of the Parts warranty, any new or remanufactured replacement parts as required by the product. During this period all labor and service charges will become the responsibility of the customer.

Exclusions:

This warranty does not apply to the appearance or exterior of the product which may have been damaged or defaced, altered or modified in design or construction. This warranty does not apply if the serial number is altered

or removed, or if there is any damage due to a power line surge, user damage to the AC power cord, connection to an improper voltage source, general misuse, accidents, or repair attempts by unauthorized service agents. Other exclusions include earpads, and rechargeable, and non-rechargeable batteries.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER; Concept 101 LLC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THE WARRANTY.


Some states do not allow the exclusion or limitations of incidental or consequential damages, or limitations on how long the warranty lasts. In these cases the above exclusions or limitations may not apply to you. rights which vary from state to state.

Obtaining Service:

To obtain service, product literature, supplies or accessories please call 1 888-920-8680, or visit our website, www.att.com/electronics, to create a ticket for exchange/repair. Please make sure to provide the date of purchase, model number and a brief description of the problem. Our customer service representative will contact you or send detailed return instructions

Concept 101 LLC does not warrant that the unit will work properly in all environmental conditions, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose other than the purpose identified within this user’s manual. Concept 101 LLC has made every effort to ensure that this user’s manual is accurate and disclaims liability for any inaccuracies or omissions that may have occurred. Information in this user’s manual is subject to change without notice and does not represent a commitment on the part of Concept 101 LLC. Concept 101 LLC reserves the right to make improvements to this user’s manual and/or to the products described in this user’s manual at any time without notice. If you find information in this manual that is incorrect, misleading, or incomplete, please contact us through our website.

Documents / Resources

	AT T S20-BLK Portable Wireless Speaker [pdf] User Manual COM0S20, 2AIPW-COM0S20, 2AIPWCOM0S20, S20-BLK Portable Wireless Speaker, Portabl e Wireless Speaker
---	--

References

- [AT&T electronics | Shop](#)