



ATEFR Floor Lamp with APP and Remote Control User Guide

[Home](#) » [ATEFR](#) » ATEFR Floor Lamp with APP and Remote Control User Guide 

Contents

- [1 ATEFR Floor Lamp with APP and Remote Control](#)
- [2 APP Connection and Usage](#)
- [3 Important Note](#)
- [4 Warning & Cautions](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)


ATEFR Floor

ATEFR Floor Lamp with APP and Remote Control





APP Connection and Usage













1. Scan the QR code on the right with your mobile phone to download our APP: Lampsmart pro

- Turn on the Bluetooth function on your mobile phone, then enter the APP, click  to enter the lamp name naming page.
- Name the lamp in the naming column, select the usage scene, and click the “confirm” button to complete the setting.



- After the lighting is named, click on the main interface of the APP to enter the lamp interface.
- Disconnect the lamp from the power supply and connect it again. Turn on the lamp, click the bluetooth pairing button  within 3 seconds, the light bulb will flash once, means the pairing is successful, and you can use the APP to control the lamp now. If fails, and the light does not flash within 10 seconds, please repeat this operation: Power off, re-plug the power, turn on the light, and click the bluetooth pairing button within 3 seconds after turning on the light.



	Cold white light		Warm light		Natural white light
	Night light mode		Invalid function		Timer
	Invalid function		Bluetooth pairing button		Color temperature adjustment
	Dimming		Power ON/OFF		Voice control (for English only)

Important Note


- The working range of the remote control is 20 meters.
- 2* AAA batteries are required for the remote control(Not included).

3. If you don't use it for a long time, please take out the batteries.

Warning & Cautions

1. Place the lamp on a flat and horizontal surface.
2. To avoid breakdown and short circuit, please do not place the lamp in a hot or humid environment.
3. Do not look directly into the light beam.
4. Do not attempt to open, repair or replace any part of the lamp. This includes all components, power supply and electric cable.
5. Do not cover the lamp with flammable material.
6. Do not spray any liquid on the lamp.

Documents / Resources

	<p>ATEFR Floor Lamp with APP and Remote Control [pdf] User Guide</p> <p>Floor Lamp with APP and Remote Control, Floor, Lamp with APP and Remote Control, APP and Remote Control, Remote Control, Control</p>
--	--

References

- [User Manual](#)

[Manuals+ Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.