



ATEQ VT56 Universal TPMS Diagnostic Toolv User Guide

[Home](#) » [ATEQ](#) » ATEQ VT56 Universal TPMS Diagnostic Toolv User Guide 

ATEQ VT56 Universal TPMS Diagnostic Toolv




Contents

- [1 RELEARN INSTRUCTIONS](#)
- [2 UPDATING THE TOOL](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

RELEARN INSTRUCTIONS


1. Select “TPMS” then select the vehicle’s Make, Model, and Year.



2. Scan each sensor on the vehicle, starting with the left front sensor.



3. First, plug the OBD Quick Connect cable into the tool then into the vehicle.



4. Select the “Relearn” Icon and press OK. The tool will display “successful Relearn” when the process is complete.




UPDATING THE TOOL

1. Visit: webvt.atdq-tpms.com to download the WebVT update software

2. Open the WebVT.exe installation file. Follow the installation instructions
3. Connect the tool to your PC with the power ON




4. Open the WebVT software. Once the software loads, a pop-up will appear. Select “update Tool”



5. The software will begin the update process. This process may take several minutes. **DO NOT** unplug or turn off the tool during this process.

Once the update is complete, a pop-up will appear that your tool is now up to date.



Documents / Resources

QUICKSTART GUIDE RELEARN INSTRUCTIONS 1. Select "TPMS" from the menu, select the vehicle's Make, Model, and Year. 2. Scan each sensor on the vehicle starting with the left front sensor. 3. First, plug the OBD Quick Connect cable into the tool, then into the vehicle. 4. Select the "Release" button and press OK. The tool will display "Successful Release" when the process is complete.	ATEQ VT56 Universal TPMS Diagnostic Tool [pdf] User Guide VT56, Universal TPMS Diagnostic Tool
---	--