

**ATLANTA  
Sweep  
Alarm  
Clock**



## ATLANTA Sweep Alarm Clock Instructions

[Home](#) » [ATLANTA](#) » ATLANTA Sweep Alarm Clock Instructions 

### Contents

- [1 ATLANTA Sweep Alarm Clock](#)
- [2 Product Usage Instructions](#)
- [3 OPERATING INSTRUCTIONS](#)
- [4 Battery return](#)
- [5 FAQ](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

# ATLANTA

**ATLANTA Sweep Alarm Clock**



### Specifications:

- **Manufacturer:** PARAGON Uhren-Vertriebs GmbH
- **Model:** Atlanta Sweep Alarm Clock
- **Battery Type:** AA/LR6/1.5V alkaline battery

### Product Usage Instructions

#### Inserting the Battery:

Remove the alarm clock battery cover and insert an AA/LR6/1.5V alkaline battery, ensuring correct polarity. Close the battery cover securely.

#### Setting the Time:

Adjust the exact time by turning the time setting knob on the clock.

#### Setting the Alarm:

Turn the alarm setting knob to set your desired alarm time.

#### Activating the Alarm:

Switch the alarm switch to ON or upwards to activate the alarm time.

#### Snooze Function:

When the alarm sounds, press the snooze button (LIGHT/SNOOZE) to activate the snooze function. The alarm will sound again after about 4 minutes. The snooze button can be pressed multiple times.

#### Turning Off the Alarm:

To completely turn off the alarm, set the alarm switch to OFF or down.

#### Illumination:

- Press the SNOOZE/LIGHT button to illuminate the dial or alarm clock.
- **Battery Disposal:** Please dispose of batteries properly in accordance with local regulations and guidelines.

## OPERATING INSTRUCTIONS

1. Remove the alarm clock battery cover to insert the battery. Make sure the polarity is correct. To enjoy your alarm for a long time, please use an AA/LR6/1.5V alkaline battery. Then close the battery cover again.
2. Set the exact time using the time setting knob.
3. Turn the alarm setting knob to set the desired alarm time.
4. To activate the alarm time, set the alarm switch to ON or upwards.
5. To activate the snooze function, press the snooze button (LIGHT/SNOOZE) when the alarm sounds. After about 4 minutes, the alarm will sound again. This snooze button can be pressed several times.
6. To turn off the alarm completely, set the alarm switch to OFF or down.
7. Illumination: Press the SNOOZE/LIGHT button to illuminate the dial or alarm clock.

### Copyright: –

These operating instructions are the intellectual property of PARAGON Uhren-Vertriebs GmbH. Copying, duplicating or placing on the market – in particular for third-party products or purposes – is prohibited or only permitted with the express permission of PARAGON Uhren-Vertriebs GmbH.

### Manufactures' s Marking / Distributor:

PARAGON Uhren-Vertriebs GmbH, Maybachstr. 6, 71299 Wimsheim, Germany.

### Battery return

Batteries must not be disposed of with household waste.

The consumer is legally obliged to dispose of batteries in accordance with use, e.g. in the public sector, collection points or where such batteries are sold.

Batteries containing harmful substances are marked with the symbol "crossed out dustbin" and one of the chemical symbols



Cd(= battery contains cadmium), Hg(= battery contains mercury) or Pb(= battery contains lead).

### FAQ

#### Q: What type of battery should I use for the Atlanta Sweep Alarm Clock?

A: It is recommended to use an AA/LR6/1.5V alkaline battery for optimal performance.


#### Q: How do I activate the snooze function on the alarm?

A: Press the snooze button (LIGHT/SNOOZE) when the alarm sounds to activate the snooze function. The alarm will sound again after about 4 minutes.

#### Q: Can I illuminate the dial or alarm clock?

A: Yes, you can press the SNOOZE/LIGHT button to illuminate the dial or alarm clock.

### Documents / Resources



- User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.