

[Home](#) » [Atone MountainLtd](#) » **Atone MountainLtd BluSkye Remote Speaker Microphone User Guide** 

## Contents [ [hide](#) ]

- [1 Stone Mountain BluSkye Remote Speaker Microphone](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)



## Stone Mountain BluSkye Remote Speaker Microphone



## Specifications

- Manufacturer: Stone Mountain, Ltd.
- Model: Celrado SM

- Features: NFC, Bluetooth, PTT functionality
- Country of Origin: USA

## **Product Usage Instructions**

1. For the most up-to-date app settings and configurations, visit [www.cleverdevices.com/products/celrado/](http://www.cleverdevices.com/products/celrado/).
2. Press the power button on the Celrado SM for 6 seconds. The device will beep twice at 3 seconds and twice again at 6 seconds. The LED will alternate between blue and red.
3. For devices equipped with NFC:
  1. Navigate to Settings > Connected Devices > Connection Preferences.
  2. Toggle NFC to on.
4. For devices without NFC:
  1. Navigate to Settings > Connected Devices > Pair New Device.
  2. Select BluSkye BT.
5. Once paired, the SM will beep twice, and the LED will blink blue.
6. Launch the Celrado app and tap the username bar 10 times.
  1. Select the Settings button that appears in the upper-right corner.
  2. Save your login credentials.
7. To connect to the app for PTT functionality:
  1. The RSM will automatically connect to the app.
  2. Tap the Speakerphone button on the PTT screen to route audio to the RSM.


## **BluSkye® Android Quick Start Guide for Celrado**

For the most up-to-date app settings and configurations, check [www.cleverdevices.com/products/celrado/](http://www.cleverdevices.com/products/celrado/).

1. Ensure your BluSkye® Speaker Microphone (SM) is powered off.  
Press the power button for 6 seconds. The SM will beep twice at 3 seconds, and twice again at 6 seconds. The LED will begin to alternate between blue and red.






2. For devices equipped with NFC, navigate to Settings > Connected Devices > Connection Preferences and toggle NFC on. For devices without NFC, skip to step 4.



3. Slowly move your BluSkye® across the back of your device until a pairing dialog appears. Follow the prompts and select “Pair” to complete pairing. Skip step 4.



4. For devices without NFC, navigate to Settings > Connected Devices > Pair New Device. Select BluSkye BT.
5. Once paired, the SM will beep twice, and the LED will begin to blink blue.
6. Launch Celrado and tap the username bar 10 times. Select the Settings button that appears in the upper-right corner and save your login credentials.



7. The RSM will automatically connect to the app for PTT. Tap the Speakerphone button on the PTT screen to route audio to the RSM.

### **Recommended Settings:**

- Set Missed Heartbeat Threshold to 3.
- Enable Talkgroup Announcement on device sleep and device active.

### **Instructional Videos:** Pairing BluSkye

### **Innovation... Quality... Passion**

Designed, Assembled, Tested and Supported with Pride in the USA, at Stone Mountain we strive to provide our customers with innovative products of the highest quality, reliability and value. We welcome and appreciate your input – Feel free to contact us.

Stone Mountain, Ltd. 1597 Eagle Point Road Huddleston, VA 24104

- **Customer Support:** 540.297.6434
- [www.stonemountainltd.com](http://www.stonemountainltd.com)

### **Frequently Asked Questions**

- **Q: How do I reset the Celrado SM to factory settings?**

A: To reset the Celrado SM to factory settings, navigate to Settings > System > Reset Options and select Factory Reset. Confirm the action, and the device will reset to its original state.

- **Q: Can I use the Celrado SM with other Bluetooth devices?**

A: Yes, you can pair the Celrado SM with other Bluetooth-enabled devices by following the standard Bluetooth pairing procedure on those devices.

- **Q: What is the warranty period for the Celrado SM?**

A: The Celrado SM comes with a standard 1-year limited warranty. For details on warranty coverage and terms, please refer to the warranty information provided with the product.

## **Documents / Resources**



[Atone MountainLtd BluSkye Remote Speaker Microphone \[pdf\]](#) User Guide  
e  
v2, BluSkye, BluSkye Remote Speaker Microphone, BluSkye, Remote Sp  
eaker Microphone, Speaker Microphone, Microphone

## References

- [User Manual](#)

■ Atone MountainLtd

◆ Atone MountainLtd, BluSkye, BluSkye Remote Speaker Microphone, Microphone, Remote Speaker Microphone, Speaker Microphone, V2

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

[Post Comment](#)

## Search:

[Search](#)

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.