



ATUVOS AT2101 Key Finder Locator Tracker Device Instruction Manual

[Home](#) » [ATUVOS](#) » ATUVOS AT2101 Key Finder Locator Tracker Device Instruction Manual 







ATUVOS TAG

AT2101 Key Finder Locator Tracker Device
Instruction Manual


Contents

- [1 Disassembly & Replacement of Battery
Instruction](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Disassembly & Replacement of Battery Instruction

	
<p>1. Use your fingernails or insert a smaller tool into the small gap at this position. (Note: The panel with the logo is facing down.)</p>	<p>2. Slide left along the gap to the edge.</p>
	
<p>3. Then slide the other side along the gap to the edge.</p>	<p>4. Pull up and open the battery cover in the back of the ATUVOS TAG. Take out Renewed</p>
	
<p>5. Use a paperclip to remove the battery and then replace a new one placing the battery positive side up.</p>	<p>6. Close the battery cover by aligning the top hole on both lids.</p>

ATUVOS TAG

<div><p>ATUVOS TAG</p><p>Disassembly & Preparation of Battery instruction</p></div>	<p>ATUVOS AT2101 Key Finder Locator Tracker Device [pdf] Instruction Manual</p> <p>AT2101, Key Finder Locator Tracker Device, AT2101 Key Finder Locator Tracker Device</p>
--	--