





AUDIENT iD24 Audio Interface User Guide

[Home](#) » [AUDIENT](#) » AUDIENT iD24 Audio Interface User Guide 

AUDIENT

audient.com



iD24 Quick Start Guide


Contents

- [1 iD24 Audio Interface](#)
- [2 System requirements:](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

iD24 Audio Interface

Welcome to your new Audient iD24 Audio Interface

Please read this quick guide to help get you started. For more information on operating your iD24, please download the full user manual from: audient.com/iD24/downloads



Windows

1. Download the ide application for Windows from audient.com/iD24/downloads
2. Open the installer and follow the instructions shown on screen.
3. Connect the iD24 to the computer using the included USB-C cable. A third-party USB-C to A cable can also be used if required. Requires a connection to a USB 3.0 port or greater. It can sometimes take a few moments for Windows to finalize the drivers before the unit is recognized.
4. Run the ide application from your Start menu. To ensure your interface has the latest features, you may be asked to install a firmware update, follow the on-screen steps to do this.
5. A registration screen will appear allowing you to register your product with Audient ARC to receive product updates as well as exclusive plugins and software. This can also be done later if required.

System requirements:

Windows 10 or Later
Intel Core 2 @ 1.6Ghz, or AMD equivalent
1GB RAM




MacOS

1. Download the ide application for Mac from audient.com/iD24/downloads
2. Open the downloaded file and drag the ide icon into the Applications folder.
3. Connect the iD24 to the Mac using the included USB-C cable. A third-party USB-C to A cable can also be used if required. Requires a connection to a USB 3.0 port or greater.
4. Run the ide application from your Applications folder. To ensure your interface has the latest features, you may be asked to install a firmware update, follow the on-screen steps to do this.
5. A registration screen will appear allowing you to register your product with Audient ARC to receive updates for your product as well as exclusive plugins and software. This can also be done later if required.

System requirements:


OSX: 10.13.x (High Sierra) or later
Intel CPU or Apple Silicon
1GB RAM Minimum



Once installed, the ide application will run in the background. The ide Mixer can be opened by going to the OS menu bar and clicking the ide icon.

AUDIENT

Documents / Resources

	AUDIENT iD24 Audio Interface [pdf] User Guide iD24 Audio Interface, iD24, Audio Interface, Interface
---	---

References

-  [Downloads - Audient](#)