



# AUDIENT iD24 USB-C Audio Interface User Guide

[Home](#) » [AUDIENT](#) » AUDIENT iD24 USB-C Audio Interface User Guide 



### Contents

- 1 Quick Start Guide
  - 1.1 Welcome to your new Audient iD24 Audio Interface
  - Windows
  - 1.2 Windows
  - 1.3 MacOS
- 2 Documents / Resources
  - 2.1 References
- 3 Related Posts

### Quick Start Guide



1. Optical In + Out


2. USB-C Connection
3. Word Clock Output
4. 2 x Speaker Outputs
5. Insert 2 Send + Return
6. Mic/Line Input 2
7. Insert 1 Send + Return
8. Mic/Line Input 1



1. Instrument Input
2. Dual Headphone Outputs

Welcome to your new Audient iD24 Audio Interface Windows

Please read this quick guide to help get you started. For more information on operating your iD24, please download the full user manual from: [audient.com/iD24/downloads](https://audient.com/iD24/downloads)



1. Channel 2 (Mic/Line Input)
2. Main Meters
3. Volume Control
4. Headphone Volume Control



5. Function Keys
6. MonitorDim + Cut
7. ID Button
8. High Pass Filter
9. -10dB Pad
10. 48V
11. Channel 1 (Mic/Line Input)

## Windows

1. Download the iD application for Windows from [audient.com/iD24/downloads](https://audient.com/iD24/downloads)
2. Open the installer and follow the instructions shown on screen.
3. Connect the iD24 to the computer using the included USB-C cable. A third-party USB-C to A cable can also be used if required. Requires a connection to a USB 3.0 port or greater. It can sometimes take a few moments for Windows to finalise the drivers before the unit is recognised.
4. Run the iD application from your Start menu. To ensure your interface has the latest features, you may be asked to install a firmware update, follow the on-screen steps to do this.
5. A registration screen will appear allowing you to register your product with Audient ARC to receive product updates as well as exclusive plugins and software. This can also be done later if required.

## System requirements:

Windows 10 or Later  
Intel Core 2 @ 1.6Ghz, or AMD equivalent  
1GB RAM





Once installed, the iD application will run in the background. The iD Mixer can be opened by going to the system tray and clicking the iD icon.

## MacOS

1. Download the iD application for Mac from [audient.com/iD24/downloads](https://audient.com/iD24/downloads)
2. Open the downloaded file and drag the iD icon into the Applications folder.
3. Connect the iD24 to the Mac using the included USB-C cable. A third-party USB-C to A cable can also be used if required. Requires a connection to a USB 3.0 port or greater.
4. Run the iD application from your Applications folder. To ensure your interface has the latest features, you may be asked to install a firmware update, follow the on-screen steps to do this.
5. A registration screen will appear allowing you to register your product with Audient ARC to receive updates for your product as well as exclusive plugins and software. This can also be done later if required.

## System requirements:

OSX: 10.11.6 (El Capitan) or later  
Intel CPU or Apple Silicon  
1GB RAM Minimum



Once installed, the iD application will run in the background. The iD Mixer can be opened by going to the OS menu bar and clicking the iD icon.

**AUDIENT**  
[audient.com](https://audient.com)

Documents / Resources

|   |  |
|---|--|
|  | <a href="#">AUDIENT iD24 USB-C Audio Interface</a> [pdf] User Guide<br>iD24 USB-C Audio Interface, iD24, USB-C Audio Interface, Audio Interface, Interface |
|---|--|

References

-  [Downloads - Audient](#)