


Audio Array AM-W13 Wireless Microphone Instruction Manual

Home » AUDIO ARRAY » Audio Array AM-W13 Wireless Microphone Instruction Manual







AM-W13 INSTRUCTION MANUAL WIRELESS MICROPHONE


Contents

- 1 ACCESSORIES
- **2 INSTRUCTIONS**
- 3 SPECIFICA
- 4 Documents /


Resources

- **4.1 References**
- **5 Related Posts**

ACCESSORIES



INSTRUCTIONS



1. Microphone head Section:

Including Microphone Cover Net and Microphone Cartiridge Module.


2. Display Screen:

Display working channels, battery power, frequency.

3. Switch button:

Press for 3 seconds on/off the microphone.

4. Frequency adjust button.



- 1. POWER BUTTON
- 2. USB CHARGING PORT
- 3. SIGNALANTENNA
- 4. BATTERY INDICATOR
- 5. RF LIGHT

LIGHT INSTUCTION

Battery indicator®	Turns red and flashes quickly	The power of the receiver is in a low battery status.
	Stays on	The receiver is in charging model.
	Turns off	The receiver is fully charged.
RF light 0	Flashes slowly	The receiver is not connected to the microphone.
	Stays on	The receiver and microphone are successfully connected.
	Flashes quickly	The receiver and microphone are successfully conne cted, and the microphone is transmitting audio signal s.

SPECIFICA

Type: Dynamic


Frequency Response: 50Hz-16KHz

Polar Pattern: Cardioid Output Impedance: 6000 Sensitivity: -52dBt1.5dB SIN Ratio: 96dB

Input Sample Rate: 48KHz

Bit Rate: 24bit THD+N: 0.05%

NOTES





Documents / Resources



<u>Audio Array AM-W13 Wireless Microphone</u> [pdf] Instruction Manual AM-W13 Wireless Microphone, AM-W13, Wireless Microphone, Microphone

References

• User Manual

Manuals+,