

Contents [[hide](#)]

- [1 audio pro A28 Bookshelf Speaker](#)
- [2 Product Usage Instructions](#)
- [3 CONNECT TO POWER](#)
- [4 SPECIFICATIONS](#)
- [5 FAQs](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



audio pro A28 Bookshelf Speaker



Product Usage Instructions

1. Ensure power input is within the range of 100-240V and 50- 60Hz.
2. Connect the device to your WiFi network for multi-room setup.
3. Download and install the necessary smartphone apps for streaming services.

4. Explore and play audio from streaming services or your own music library.
5. If no WiFi network is available, use Bluetooth or a cable connection.
6. Adjust volume and input settings using the controls provided
7. For Bluetooth pairing, follow the instructions in the manual.

WELCOME TO WIRELESS HIFI.

- Audio Pro wireless HiFi products lets you enjoy your favourite audio in a multiroom setup everywhere around your home.
- Our new generation of products uses
- Audio Pro wireless technology, Google Cast, AirPlay 2,
- Spotify Connect and Tidal Connect.
- By utilizing your WiFi network & smartphone apps
- you can explore and play audio from streaming services and your own music library.
- If you don't have a WiFi network, you can use Bluetooth or connect your audio equipment via cable.
- The legendary Audio Pro sound quality is included.

Scan the QR code.



- (audiopro.com/info)

The Spotify Software is subject to third party licenses found here:



www.spotify.com/connect/third-party-licenses.

•



Google, Google Play, Google Cast and other related marks are trademarks of Google LLC. Google Cast may require subscription(s). The Google Assistant requires an internet connection and is not available in certain countries and languages. Availability and react of certain features and services are device, service, and network-dependent and may not be available in all areas. Controlling certain devices in your home requires compatible smart devices. Subscriptions for services and applications may be required and additional terms, conditions and/or charges may apply.



The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by AUDIO PRO AB, is under license. Other trademarks and trade names are those of thier respective owners.



Apple Home

© Apple, the Apple logo, AirPlay, iPad, iPhone, and iPod touch are trade-marks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

- © AUDIO PRO AB, SWEDEN. ALL RIGHTS RESERVED.
- TRADEMARKS ARE THE PROPERTY OF AUDIO PRO AB, SWEDEN.
- Audio Pro AB, Garnisonsgatan 52 SE-254 66 Helsingborg, Sweden
- Audio Pro®, the Audio Pro logotype, the 'a' symbol, and ace-bass® are all registered trademarks of Audio Pro AB, Sweden.
- All rights reserved. Audio Pro follows a policy of continuous advancement in

development. Specifications may be changed without notice.

- All other products and services mentioned may be trademarks or service marks of their respective owners.
- THIS DOCUMENT CONTAINS INFORMATION THAT IS SUBJECT TO CHANGE WITHOUT NOTICE.

MODEL: A28. FCC ID: 2AGNC-A38

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.
2. 2. any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

COMPLIANCE WITH 2014/53/EU RADIO EQUIPMENT DIRECTIVE (RED):

In accordance with Article 10.8(a) and 10.8(b) of the RED, the following provides information on the frequency bands used and the maximum RF transmit power of the

product for sale in the EU:

- Bluetooth transmitter frequency range: 2.402-2.480 GHz
- Bluetooth transmitter power: ≤ 20 dBm (EIRP)
- 2.4G Wi-Fi transmitter frequency range: 2.412 – 2.472 GHz (2.4GHz ISM Band, USA and Canada 11 Channels, Europe and others 13 Channels)
- 2.4G Wi-Fi transmitter power: ≤ 20 dBm (EIRP)
- 5G Wi-Fi transmitter frequency range: 5.150-5.350 GHz, 5.470 – 5.725 GHz, 5.725 – 5.825 GHz

5G Wi-Fi transmitter power: ≤ 23 dBm (EIRP) for 5.150 – 5.725 GHz, ≤ 13.98 dBm (EIRP) for 5.725 – 5.825 GHz

NATIONAL RESTRICTIONS:

	AT	BE	BG	CH	CY	CZ	DE	DK
	EE	EL	ES	FI	FR	HR	HU	IE
	IS	IT	LI	LT	LU	LV	MT	NL
	NO	PL	PT	RO	SE	SI	SK	UK

When operating in the 5.15-5.35 GHz frequency range, the device is restricted to indoor use only for all EU member states and EFTA countries

EU Compliance Information:

Audio Pro hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2011/65/EU and (EU)2015/863. The original EU declaration of conformity may be found at

- <https://www.audiopro.com/doc/>.

IC WARNING

This device contains licence-exempt transmit-ter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:


1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

FCC/ IC Radiation Exposure Statement


This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

5150-5250 Mhz is restricted to indoor use only.


REAR VIEW




CONTROLS



LED INDICATOR





- White
- Red
- Blue
- Green
- Purple
- WiFi
- Optical
- Bluetooth
- LINE
- ARC (TV)



CONNECTING TO THE NETWORK

YOU NEED THIS



Character set UTF-8 for password is supported.

KEY REQUIREMENTS

NETWORK


- Your network must have a high-speed internet connection, as the Audio Pro system is designed to utilise free, online software updates.
- Audio Pro speakers communicate via a 2.4 GHz / 5 GHz home network with support for 802.11 b/g/n/ac wireless technology.

ROUTER

- High-speed DSL/cable modem, or fibre-to-the-home broadband connection for proper playback of internet-based music services.

- Different routers provide different levels of performance. Please use a good wireless router to achieve the best possible performance.

CONNECT TO POWER



100-240V
50-60Hz



30-60 s




Scan the QR code.

(audiopro.com/info)

MAKING A PRESET

CONTROLS



IN THE APP

PRODUCT
INFO.
CUSTOMER
SUPPORT.
MANUALS.




Scan the QR code.

audiopro.com/info

RESTREAMING

- Connected devices sound can be played to more speakers wirelessly. Choose master speaker in group to play.



PLAYING FROM SPOTIFY

- Use your phone, tablet or computer as a remote control for Spotify.
- Go to spotify.com/connect to learn how.

AIRPLAY / GOOGLE CAST

- Tap AirPlay, and choose a speaker.



WIFI FAQ

PRODUCT
INFO.
CUSTOMER
SUPPORT.
MANUALS.




Scan the QR code.

(audiopro.com/info)

BLUETOOTH


PAIR




PLAYING FROM CONNECTED DEVICES

1.

Connect using a cable.



2.



ARC (AUDIO RETURN CHANNEL)

- Control TV audio with your regular TV remote. If your TV supports ARC, depending on brand, you may have to activate this feature in your TV settings.

SPECIFICATIONS

- **Type:** Powered stereo speaker system with bass reflex
- **Amplifier:** Digital Class D amplifier, 2×75 W
- **Tweeter:** 1" textile dome tweeter
- **Woofers:** 4.5"
- **Frequency range:** 45-20,000 Hz
- **Crossover frequency:** 2800 Hz
- **Dimensions** HxWxD: 238x150x200 mm
- **Inputs:** WiFi, Bluetooth 4.2, 1 x Line in
 - 1 x TOSLINK optical digital (only PCM), 1 x ARC/TV.
- **Outputs:** 1 x Sub Out

- **Power consumption STBY/ON:** 1.85 W/5.20 W (standby activated after >20 minutes idle)
- **Wireless network compatibility:** 802.11 b/g/n/ac, 2.4 GHz/5 GHz
- **Supported audio formats:** MP3, WMA, AAC, FLAC, Apple Lossless.

CAUTION

- RISK OF ELECTRIC SHOCK
- DO NOT OPEN



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

- To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Caution:

- To reduce the risk of electric shock, do not remove covers or panels. No user-serviceable parts inside. Refer servicing to qualified service personnel.

CAUTION!

This equipment is capable of delivering sound pressure levels in excess of 85 dB, which may cause permanent hearing damage.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this product near water.
6. Clean only with dry cloth.
7. Operating temperature (°C) 5–40 Humidity (%) no condensation 30–90
8. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
9. Minimum distances around the product for sufficient ventilation, 10 cm.
10. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
11. Do not install near any heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
13. Only use attachments/accessories specified by the manufacturer.
14. Unplug this product during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

16. Damage Requiring Service

Unplug the product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power supply cord or plug is damaged,
- If liquid has been spilled, or objects have fallen into the product,
- If the product has been exposed to rain or water,
- If the product does not operate normally by following the operating instructions.


Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

- If the product has been dropped or damaged in any way, and
- When the product exhibits a distinct change in performance this indicates a need for service.

17. Object and Liquid Entry

Never push objects of any kind into the product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases shall be placed on the product. No naked flame sources such as lighted candles etc., should never be placed on the product.

18. Make sure that there is adequate ventilation if you install the product in confined spaces, such as bookshelves or racks. Leave a distance of 20 cm above and on both sides of the product and 10 cm behind it. The back end of a shelf or board closest to the top of the product should be pushed forward to give a gap of about 10 cm behind. In this way an exuding channel is formed where heated air can flow up.
19. The power supply and power cord for this product is intended for indoor use only.
20. Use only the supplied power cord/adaptor.


 (AC symbol, Alternating current)



(Class II product – Double Insulated) The mains plug is used as the disconnect device, the disconnect device shall remain readily operable. The socket outlet shall be installed near the equipment and shall be easily accessible.

REMOTE CONTROL BATTERY INFORMATION

- Do not ingest battery, Chemical Burn Hazard.
- This product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



FAQS

Q: What should I do if I encounter interference issues?

A: Ensure the device is not causing interference and try adjusting its placement. Refer to the manual for more guidance.

Q: Can I use the product outdoors?

A: The device is recommended for indoor use only. Operating in outdoor environments may affect performance.


Q: How do I reset the device?

A: Use the provided screw (M6*20mm) for the reset service as indicated in the manual.





Q: What do the different inputs on the device signify?



A: The device supports various inputs like Line, Optical, and TV. Select the appropriate input based on your audio source.

Documents / Resources

	audio pro A28 Bookshelf Speaker [pdf] User Manual A28 Bookshelf Speaker, A28, Bookshelf Speaker, Speaker
---	---

References

-  [Getting started](#)
-  [Spotify - Web Player: Music for everyone](#)
-  [Magasins Darty : Électroménager, high-tech, cuisine sur mesure, réparation](#)
-  [SAV Darty : Comment utiliser, entretenir et réparer son produit](#)
- [User Manual](#)

 audio  A28, A28 Bookshelf Speaker, audio pro, Bookshelf Speaker, pro speaker

—Previous Post

[audio pro C20 Multi Talented Wireless Speaker User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.